

AUINMX



10.1" Digital Calendar Day Clock

User Manual

Model #: DC-101A

E-mail: [support@auinmx.com](mailto:support@auinmx.com)

## **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - - Reorient or relocate the receiving antenna. - - Increase the separation between the equipment and receiver. - - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - - Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## **RF Exposure Statement**

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

## **Contents**

Notices

Package List

Specifications

Shortcuts on Homepage

Connecting to the Power

How to Connect to Wi-Fi

How to Set Alarm

How to Set Medication Reminder

How to Set Event Reminder

Troubleshooting

## Notices

- Before initiating the setup process for this digital calendar day clock, it is essential to thoroughly read the accompanying user manual enclosed within the package.
- To mitigate the risk of fire or electrical shock, ensure that this digital calendar day clock is never subjected to rain or any form of moisture.
- Avoid attempting to open the casing of this digital calendar day clock.
- Prior to operating this digital calendar day clock, confirm that the power cable is properly connected and free from any damage.
- Minimize exposure to dust, humidity, temperature extremes, and uneven surfaces.
- Do not insert objects or spill any liquids into the slots on the casing of this digital calendar day clock.
- This unit is exclusively intended for indoor use.
- Ensure children are supervised to prevent them from playing with the unit.
- In case of technical issues with this digital calendar day clock, kindly reach out to our technical support promptly.

## **Package List**

Digital Calendar Day Clock x 1

Power Adapter x 1 (5V/2A)

Support Pole x 1

Spare Screws x 2 (Wall-Mounting)

Instruction Manual x 1

## Specifications

<b>Product Name</b>	Digital Calendar Day Clock
<b>Screen Size</b>	10.1 Inch
<b>Screen Type</b>	IPS
<b>Aspect Ratio</b>	16:10
<b>Resolution</b>	1280*800
<b>Contrast</b>	1000:1
<b>Brightness</b>	280 cd/m2
<b>Speaker</b>	Built-in Speakers(2W*2)
<b>AC Power Adapter</b>	Input 100-240V
<b>AC Output DC</b>	5V-2A
<b>Dimension</b>	10.04*7.09*1.18 inch
<b>Net Weight</b>	1.21 lbs

## **Shortcuts on Homepage**

- Swipe Left - open the calendar, you can click on a specific date to set an event reminder.
- Swipe Right - access the settings interface for each section.
- Swipe Down - enter the settings interface for sound and brightness.
- Long press - hear the current time announced through voice.

## Connecting to the Power

1. Connect the power adapter to the unit, and then plug into the mains socket.
2. After connecting to power, the device will automatically start. Follow the on-screen instructions for the first-time setup.

Note: The Power Button on the back of the device is only used to turn off the display for sleep purposes. The device will still function normally for alarms and medication reminders.

***Attention: This clock does not come with a built-in battery. Ordinary AA batteries cannot sustain prolonged screen operation. The device must be connected to a power source for continuous and proper functionality.***

## **How to Connect to Wi-Fi**

### **Method One:**

STEP:

1. Connect the power adapter to start the device.
2. Follow the on-screen instructions for the first-time setup.

### **Method Two:**

STEP:

1. Go to MENU, then Settings - Wi-Fi.
2. Select the Wi-Fi connection option.
3. Choose the correct Wi-Fi network.
4. Enter the Wi-Fi password.
5. Confirm successful connection by checking for the green checkmark icon.

## How to Set Alarm

### Editing an Existing Alarm:

1. Go to MENU.
2. Click on Alarms section.
3. Select the alarm to modify.
4. Choose alarm time, repeat days and choose a ringtone. Or click "Add Voice" to record personalized voice reminder, time limited 5s.
5. Select preset displayed & announced content.
6. Add custom content if desired. (Note: Custom content cannot be announced by voice, only displayed as text.)
7. Click "Confirm" to save changes.

### Adding a New Alarm:

1. Navigate to Alarms section.
2. Click "Add alarm clock."
3. Follow above instructions to create new alarm.
  - ◆ ***Custom content length should not exceed 200 characters.***
  - ◆ ***Custom content cannot be announced by voice, only displayed as text.***

## How to Set Medication Reminder

### Editing an Existing Medication Reminder:

1. Go to MENU.
2. Select Medication Reminder section.
3. Choose the reminder to modify.
4. Set reminder time, repeat days and choose a ringtone. Or click "Add Voice" to record personalized voice reminder, time limited 5s.
5. Select preset displayed & announced content.
6. Add new content if needed (Note: Custom content cannot be announced by voice, only displayed as text.)
7. Click "Confirm" to save.

### Adding a New Medication Reminder:

1. Navigate to Medication Reminder section.
2. Click "Add other medication times."
3. Follow above instructions to create new reminder.

  

- ◆ ***Custom content length should not exceed 200 characters.***
- ◆ ***Custom content cannot be announced by voice, only displayed as text.***

## **How to Set an Event Reminder**

### **Add an Event Reminder:**

1. Swipe left to enter the calendar page.
2. Tap on the desired date.
3. Click the "+ Add Event" to add an event.
4. Select a preset display text or add your own custom text.  
*(Note: Custom content won't be announced).*
5. Set the reminder time, repeat mode and choose a ringtone.
6. Click "Confirm" to save.

### **How to Delete an Event:**

1. Swipe left to enter the calendar page.
2. Tap on the date with a dot in the upper right corner.
3. Select the event you wish to delete from the list on the right side, which will
4. automatically take you to the edit screen.
5. Tap the delete button in the upper right corner to remove the current event.

***Note: Default holiday reminders cannot be edited.***

## Troubleshooting

Problem 1: The clock won't power on.

Solution 1: Ensure that the clock is properly connected to a power source with 5V/2A output. Ensure the power cable is not damaged, or try using a USB-C cable to connect the power and start the device.

Problem 2: The time is inaccurate.

Solution 2: Verify that the network connection is stable. Ensure the correct time zone is selected.

***Note: Due to network latency, the second hand may have a delay of a few seconds.***

Problem 3: The brightness is either too high or too low.

Solution 3: Touch the screen to access the menu, select the brightness section, and adjust the brightness using the slider. You can also activate the sleep mode for automatic brightness adjustment.

Problem 4: The volume is too loud or too soft.

Solution 4: Touch the screen to access the menu, select the sound section, and adjust the volume using the slider.