

10\*14.5CM

#### BLUETOOTH FUNCTION OPERATION

- Turn on the radio, push the band button to USB. The unit will speak "BLUETOOTH MODE" then turn on the Bluetooth of mobile phone or other device with Bluetooth function, start to search a Bluetooth named "D-216" and connect with it. Now mobile phone or other device can play by music through Bluetooth on D-216 radio. You can select, play and pause the music by pressing NEXT/PREV/PLAY buttons on radio or mobile phone or other devices. If you want to stop using Bluetooth function, you can turn off the Bluetooth in mobile phone or other devices.
- Under Bluetooth mode, fast press P/P key twice for TWS function, connect another machine, fast press the machine as the master (left channel), the other connected machine as a deputy(right channel). When the main machine is connected to the TWS of the secondary machine, the playback light of the main machine blinks, and the secondary machine is long on. When the main machine is connected to the mobile phone, the playback light of the two machines does not flash; When the machine plays a song, the player light on both machine does not flash.

#### USING RECHARGEABLE BATTERY

- The built-in rechargeable battery, please note that the first time should to charge with AC power for about 8 hours.
- Normally, if the rechargeable battery is no power, we should recharge 3-5 hours.

#### TECHNICAL SPECIFICATIONS

##### RECEIVER FREQUENCY

- AM:530-1710KHz
- FM:88-108MHz
- SW: 7.0-16MHz

##### POWER SUPPLY

- AC POWER
- DC Voltage:3V(UN-1×2pcs, Battery Not Include())

##### AUDIO SECTION

- Earphone Jack (3.5mm)
- DC 5V IN JACK

##### PACKAGE INCLUDE

- D-216 Radio x1
- Rechargeable Battery x1
- AC Power Cord x1
- English Manual x1

#### CONTACT

- Email:Wenpzeray@163.com

Thank you for your support and understanding.  
If you have any further question, please feel free to contact us.

FC CE RoHS MADE IN CHINA

Wenpzeray

—D-216—

## USER MANUAL

#### AM/FM/SW RADIO USB/TF/ MP3 AND WIRELESS BT PLAY

Thank you for purchasing D-216 radio. In order to get the best from radio, please read this manual carefully before using it



#### RADIO OPERATION

- Press RADIO button to select "OFF", "MP3" or "RADIO" station. When you listen to the radio, press the button to "RADIO" mode.
- Extend the telescopic antenna to its full length when listening to FM band, please note that the antenna just can be rotated 180°, please use slowly.
- Turn the volume knob to adjust to the desired and comfortable sound level.
- Select the preferred radio station frequency by turning the TUNING knob. The pointer in the TUNING FREQUENCY DISPLAY WINDOW shows the selected radio frequency.

#### Play by USB Drive/TF Card

During radio program playing, insert USB/TF card, it will automatically switch to Play from USB/TF card. You can press NEXT & PREV buttons to select your favourite music and enjoy it.

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.