


USER'S MANUAL

How to install and debug projector quickly Installation and commissioning

Image focal length adjustment

According to the fuzziness of the projection picture, Press the focus button on the remote control Until the picture is in perfect sharpness




Important safety precautions

Announcements


Thank you for purchasing this digital projector series. Please read through this manual for proper use of this product. After reading, please put this manual together with the warranty card in a safe place for reference. Please read this instruction manual if you need to know something or have any problems.

NOTICE

To prevent electric shock, do not open the chassis. There are no parts in the machine that the customer can repair. Please entrust qualified professional maintenance personnel to carry out maintenance.



This sign reminds the user that great care must be taken in operation and repair, therefore, it must be read carefully to prevent any failures.



This sign warns the user that uninsulated voltages in the unit may cause electric shock from the surface magnetic field, and therefore it is dangerous to contact any part of the unit.

WARNING

To prevent fire or electric shock, do not expose the unit to rain or moisture. Do not open the case.





Warning: Do not look directly at or stare at the light beam from the lens. Strong light may cause eye discomfort or damage. Parents should supervise and educate children to use it properly.




Suitable for altitude less than 2000 m and non-hot climate

Important safety instructions


Please read this manual before you operate your projector. save it for future reference.



Do not look straight at the projector lens during operation. The intense light beam may damage your eyes.




The lamp becomes extremely hot during operation. Allow the projector to cool for approximately 45 minutes prior to removing the lamp assembly for replacement.



Do not block the projection lens with any objects when the projector is under operation as this could cause the objects to become heated and deformed or even cause a fire. To temporarily turn off the lamp, use the blank function.

Check before use Bluetooth remote control




* Remote control shall be working within 5m distance from projector.

* Paring method(Bluetooth connection)

1. Press and hold the left & right direction buttons at the same time for 3-5 seconds until the red light flashes.
2. Open "Settings" - "Bluetooth & Remotes", click the name of the remote to connect.

Check before use Use of remote control



Normal version with infrared remote control


Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

The data are for reference only Projection distance and dimension




*The screen size is for reference only, please refer to the actual type.

Design tolerance error +/-8%. This chart is measured at the front and center of the lens and assumes that the projector is placed horizontally (the front and rear adjuster are fully drawn out).

How to install and debug projector quickly Set projection screen trapezoidal scale and projection mode

1. Select "Trapezoidal Correction" on the home page.
2. Select function keys based on the projection scenario.



How to install and debug projector quickly Setting up wifi Connection

1. Open the Settings menu on the remote control or the Settings on the home page.
2. On the WLAN network connection page, enable Wireless and Network as shown in the figure.
3. Select the home wifi signal network, enter the wifi password, and connect.



By pressing the home menu, you can now go online and enjoy your home theater.