

Opening Rmarks

Thank you very much for your support!

You can learn to use and operate on this projector by reading this manual.

This handheld projection device has powerful features like compact, convenient etc. It is specifically designed for home, entertainment, business and other applicationenvironments. The projector let you enjoy the fun of the big screen reality anytime and anywhere, and you are also welcome to share your fun and opinions with us.

If you have any questions about this product, please contact our after-sales department. we are happy to service for you.

Important safety precautions

For best effects, it is recommended that you use this product in a dark room.

1. DO NOT install the machine where directly blown by the air conditioner, the water condensed or high temperature may cause machine failure.
2. Make sure that there is sufficient ventilation and the ventilation is not blocked, so as to avoid the accumulation of hot air in the machine
3. Prevent clips or paper falling into the machine, and do not put any metal objects into machine. If accidentally happens, please turn off the power immediately and let qualified personnel fix it.
4. Due to avoid the risk of leakage, do not place any liquid on the machine.
5. When transporting the projector, please use soft packaging materials to protect the lens from scratches Please install the lens protection cover, non violent during transporting.
6. During or after the projection, the vicinity of the exhaust vent will become hot, non touch with your hands.
7. DO NOT look into the lens while the machine is powered on, it may cause serious damage to your eyes.

NOTICE ⚠ DO NOT open the case. Please entrust qualified professional maintenance personnel to perform maintenance.
⚠ This mark warns there is an uninsulated voltage in the unit, which may cause electric shock due to the surface magnetic field. It is very dangerous to touch any parts inside the machine.
NOTICE ⚠ To prevent fire or electric shock, do not expose this machine to rain or moisture.

Cleaning Method

Before cleaning, you must make sure that you have unplugged the power plug.

Do not use insecticides or other volatile chemicals on the projector or lens. Do not use rubber or vinyl products to touch the projector. This can damage or cause coating peel off.

Clean the Projector

Wipe with a soft dry cotton cloth. use a soft cloth dipped in a diluted neutral detergent to wipe it, then with a dry cloth. If you use chemical fiber cloth, please follow the precautions.

Do not use thinner, benzene or other solvents to avoid quality degradation or peeling of the spray coating.

When cleaning the dirt, you can insert a brush in the front of the vacuum cleaner, avoid directly use the vacuum cleaner without any connectors or the nozzle, avoid scratches.

Dust cleaning of lens

Use the same method to clean the camera lens, use the professional hair dryer for the camera or the cleaning paper for the glasses lens. Be careful not to scratch the lens.

Dust cleaning at suction and outlet

The dust in the air inlet and outlet prevents ventilation, which will increase the internal temperature and cause malfunctions. Cleaning guidelines: at least clean once use every 10,000 hours.

Turn off the projector, disconnect the power.

Clean the exterior with an electric vacuum cleaner, and install a brush head adapter on the vacuum cleaner. Please be careful not to use a vacuum cleaner without an adapter or brush head.

USER'S MANUAL


Thanks for reading!

Enjoy your time with this projector!




Packing list

*PS: Thank you very much for purchasing our company's products. Please check the products you have received, Whether the physical object is consistent with the list; If the products and accessories you receive do not match the list, please Contact the purchasing platform promptly.




*PS: Due to different model versions, there may be certain differences in appearance and functionality. Please refer to the actual product for accuracy.

Projector component and functions




*PS
·Do not place objects within 20cm near the heat dissipation holes.
·If lifting, please use screws of the specified specifications and choose a suitable bracket.
·Please do not look directly at the lens.

Common external devices




Warning:
Running this device in a residential environment may cause radio interference.

Safety notice



Remote control

PS:
Please pair the Bluetooth remote control first to facilitate the use of the remote control and mouse functions.
1. After turning on the machine, press the V- and F- buttons on the remote control at the same time, and the remote control indicator light will enter a flashing state.
2. Use the remote control to operate the projector to enter the setting interface and enter the Bluetooth interface to search.
3. Search for the name: BT Keyboard, and click Connect. It can be used after the connection is successful.
4. If you cannot search for the relevant name, please repeat steps 1 and 2.



Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.