

Piano Dreams Start Here

POP self-learning smart keyboard instructions



Please read carefully before proceeding

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuits, damages, fire, or other hazards.

Caution

- All operating instructions should be read before using this equipment.
- To reduce the risk of electrical shock, do not open the unit. There are no user replaceable parts inside. Please refer to a qualified service technician. Do not attempt to return this equipment to your dealer. Do not expose this unit to direct sunlight to a heat source such as radiator or stove.
- Do not attempt to clean the unit with chemical solvents as this might damage the finishing. This unit should be cleaned with a damp cloth.
- When moving this equipment, it should be placed in its original carton and packaging. This will reduce the risk of damage during transit.
- Do not expose this unit to water or heat.
- Do not use cleaning products or lubricants on the controls or switches.

Precautions

- Read Instructions: All the safety and operating instructions should be read before the product is operated.
- Retain Instructions: All the safety and operating instructions should be read before the product is operated.
- Head Warnings: All warnings on the product in the operating instructions should be adhered to.
- Follow Instructions: All operating and instructions should be followed.
- Cleaning: The product should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzene, insecticides or other volatile liquids since they may corrode the cabinet. . Water and Moisture: Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink, laundry tub; in a wet basement; or near the swimming pool; and the like.
- Do Not Open: Do not open the device or attempt to disassemble the internal parts or modify them in any way. The device contains no user-serviceable parts. If it appears to be malfunctioning, discontinue use immediately and have it inspected by qualified service personnel.
- Replacement Parts: When replacements are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions result in fire, electric shock, or other hazards.
- Location: To avoid toppling the device causing damage to the internal components, be sure to keep the device stable.
- Functions: When transporting the device, we always use the original carton. Before moving the device, remove all connected cables.
- Do not expose the device to excessive or vibrations, or extreme cold or heat (such as in direct sunlight or near a heater) to prevent the possibility of panel disfigurement or damage to the internal components.
- Do not place the device in an unstable position where it may accidentally fall over.

Product introduction

Technical Specifications

Net weight: 0.45KG Port: Type-C Bluetooth version: 5.0 Voltage: 5V

Battery: 3.7v 320mAh polymerlithium battery

Size: 321mm*141mm*24mm

APP: POP Piano can be searched and downloaded in Apple Store/Google Play



MP228 rear view

① Power indicator

② Type-C port

③ Power switch

① ② ③




Magnetic attraction splicing

The additional keyboard is expanded through horizontal splicing of magnetic connectors on both sides of the keyboard. After the splicing is successful, the keyboard will flash blue light three times and share a Bluetooth port.

After the splicing is successful, the keyboard will automatically merge into a Bluetooth, and the blue light will flash three times on the machine.

You can connect two or three keyboards together to create a new 48/72 keyboard.

The splicing keyboard has a wider playing range, which can adapt to playing more favorite tracks. The unique magnetic splicing design helps you gradually master the piano playing skills.




Download POP Piano

Scan the QR code to download the POP Piano APP

Support mobile devices such as mobile phones and Pads

Support iOS 12.0+ and Android 6.0+ versions




Scan the QR code to download



Register an account


After opening the POP Piano APP, you can register POP Piano through your mobile phone number, or you can log in directly through social accounts.



Connect POP Piano via bluetooth

1. Confirm that the Bluetooth of the mobile phone and the keyboard are both turned on. Some Android mobile phones need to turn on the mobile phone positioning function.
2. In the POP Piano APP, click the button in the upper left corner of the "Learning" page, and then select your own keyboard from the piano list.

Note: Do not connect the keyboard in the Bluetooth settings of the mobile phone system.



Introduction to learning methods

When playing, you need to refer to the virtual keyboard position of the bubble piano to find the correct key to play.

The learning method of Bubble Piano has certain requirements for correct playing. When playing incorrectly, a red X will appear on the virtual keyboard. At the same time, the score in the upper right corner will be lower.

It is recommended to start with a difficulty level 1 piece in order to adapt to the learning method of bubble piano.



Numbers indicate fingering
1 for thumb, 2 for index finger,
and so on

A screenshot of the Bubble Piano app interface. The top bar shows a back arrow, the title 'For Elise(Simple version)', a headphones icon, the score '1/16', and a settings gear icon. The main area displays a piece of sheet music with blue numbered boxes above the notes (2, 5, 4, 5, 4, 5, 2) indicating fingerings. To the right is a virtual keyboard with a hand icon showing finger placement. The bottom shows a piano keyboard with keys labeled C2, C3, C4, C5, C6, and C7.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.