


单击左右耳机：  
播放/暂停  
来电时短按：接电话  
来电时长按：拒接电话



双击左边耳机：降低音量  
长按左边耳机3秒：上一曲  
三击左边耳机：唤醒语音助手

双击右边耳机：降低音量  
长按右边耳机3秒：下一曲  
三击右边耳机：末号回拨

**产品规格**

使用距离：≥10米  
使用时间：4小时  
充电时间：1.5小时  
耳机电池容量：30mAh  
充电仓电池容量：350mAh  
驱动单元：10mm 32Ω

**耳机如何连接蓝牙设备**

- 从充电仓把耳机取出，耳机自动开机配对
- 打开蓝牙设备，搜索配对名“ZW-T33”点击连接
- 连接成功后耳机即可使用

**如何使用耳机**

**音乐模式：**

- 单击左/右边耳机：暂停/播放音乐
- 双击左边耳机：降低音量  
双击右边耳机：增加音量
- 长按左边耳机3秒：上一曲  
长按右边耳机3秒：下一曲

**通话模式：**


- 单击左/右边耳机：来电接听/挂断电话
- 三击左边耳机：唤醒语音助手  
三击右边耳机：末号回拨

**如何充电**

- 把耳机放回充电仓内，耳机自动关机并开始充电，充电时耳机红灯长亮
- 用配送的Type-C充电线给充电仓充电，充电时充电仓的指示灯亮蓝灯，充满后蓝灯长亮

**温馨提示！**

- 在使用中请选择适当的音量，保护耳朵，以防对耳朵造成伤害
- 长时间未使用的耳机，请先将耳机进行一次充电后再使用




**精灵TWS  
无线耳机**

**ZW-T33**

**操作说明书**

Click left/right earphone:  
Pause/play music  
Click the left/right earphone  
to answer/hang up the call



Double click the left earbud  
to decrease the volume  
Long press the left earbud for  
3 seconds: previous song  
Click the left earphone three  
times:wake up the voice  
assistant

Double click the right earbud  
to increase the volume  
Long press right earbud for 3  
seconds: Next track  
Click the right earphone three  
times:dial back the last number

**Specification**

Service distance: ≥10 meters  
Using time: 4 hours  
Charging time: 1.5 hours  
Headphone battery capacity: 30mAh  
Battery capacity: 350mAh  
Speaker: 10mm 32Ω

**How do the TWS earphone connect to bluetooth devices**

- Take out the earphones from the charging box, and the earphones will be automatically turned on and paired
- Turn on the Bluetooth device, search for "ZW-T33" and click Connect
- The earbuds can be used after the connection is successful

**How To Use The Earbuds**

**Music mode:**


- Click left/right earphone: Pause/play music
- Double click the left earbud to decrease the volume  
Double click the right earbud to increase the volume
- Long press the left earbud for 3 seconds: previous song  
Long press right earbud for 3 seconds: Next track
- Click the left/right earphone to answer/hang up the call
- Click the left earphone three times: wake up the voice assistant  
Click the right earphone three times:dial back the last number

**How to charge**

- Put the earphone back in the charging compartment. The earphone will automatically power off and start charging
- Charge the charging case with the Type-C charging cable. When charging, the indicator of the charging case will light up blue, and the blue light will keep on after it is full

**Warm tips!**

- In use, please choose the appropriate volume to protect the ear, in case of injury to the ear
- If the earphone has not been used for a long time, please charge the earphone once before use



**Fairy Ear TWS  
True Wireless Earbuds**

**ZW-T33**

**User Guide**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction