



**Fametek Wireless Speaker**

**USER GUIDE**

Applicable models: 692001

**Features:**

- Officially licensed BBC™ TARDIS™ collectible
- Sound Clips: Materialize, Dematerialize, Cloister Bell, Flight
- Top LED flashes white when powered On/Off
- Windows illuminate when connected to device
- Auxiliary in for direct connection
- Multi-Function interface for Volume / Play / Pause / >> / << / Power
- Precision tuned ported speaker enclosure
- Mil spec PCB with SMD parts for amplification
- Built-in noise rejection circuitry
- USB Rechargeable lithium-ion battery
- Skip Sound FX by pressing any button
- Battery indicator display / voice battery low indicator

**Specifications:**

- Connectivity: Wireless Bluetooth™
- Wireless Range: 33 Feet / 10 meters minimum
- Dimensions: 5.89" H x 2.98" W x 2.98" D
- Battery Life: 4hr. (varies upon volume and connection)
- Battery: Rechargeable Lithium-ion via Type-C
- Speakers: High power 36mm low distortion speaker
- Direct Connect: 3.5mm Auxiliary Input
- USB Port: Type-C DC5V/3A
- Frequency: 150Hz - 20KHz
- S/N: >80dB

**Packing Lists:**

- Unit x1, USB cable x1, AUX cable x1,
- User guide x1, Warranty card x1,


**Button Interface:**

**Volume up / Next**  
Press + button = volume up  
Press and hold + button = next song

**Volume down / Previous**  
Press - button = volume down  
Press and hold - button = previous song

**Play or Pause / Power ON or OFF**  
Press button = play or pause  
Press and hold button = power ON or OFF  
(if no Bluetooth connection is detected within 15 minutes the device will auto turn off)

**Skip Sound FX**  
Press any button



**Window LED Indicator:**  
Flashes white continuously = Looking for Bluetooth Connection  
White LED stays lit = Paired to device  
White LED stays lit = Auxiliary connection

**Roof Lamp LED Indicator:**  
The LED will flash white when powered on  
The LED will flash white when powered off  
(Hold down power button)

**Voice Indication:**  
Power ON: Materialize  
Power OFF: Dematerialize  
Bluetooth Connected: Cloister Bell  
Aux In Mode: Flight noise

**Base LED Indicator:**  
White LED stays lit = Unit is charging  
Green LED starts lit = Unit is fully charged

**Bluetooth Pairing:**  
The Bluetooth name is "TARDIS"  
Turn on speaker, it will search for the last paired device and auto-pair to it  
If no device can be auto-paired, the speaker will wait for a new device to connect

**Charging:**  
We recommend turning off the TARDIS before charging  
Connect TARDIS and power source via Type-C cable the LED will be white while charging  
The LED will be green when charging is completed

**Auto Power Off:**  
If no Bluetooth connection within 15 minutes, device auto power off  
When the battery is too low, the device will auto power off

**1 HEARING DISTORTION:**

A. Lower the volume on your BAD WOLF TARDIS and/or phone/device.  
B. Make sure it's charged up. Check for low battery, then charge Tardis via USB.

**2 NOT LOUD ENOUGH?**

A. Turn up the volume on your phone/device or your BAD WOLF TARDIS.  
B. Make sure it's charged up.

C. Try plugging your BAD WOLF TARDIS into your phone/device via 3.5mm cable.

**3 UNABLE TO PAIR WITH BLUETOOTH® DEVICE?**

A. Confirm that your phone/device is Bluetooth® compatible.  
B. Follow Bluetooth pairing instructions in this guide  
C. Visit [www.masseiveaudio.com/support](http://www.masseiveaudio.com/support)

**4 EXPERIENCING SIGNAL LOSS OR DROPOUTS VIA BLUETOOTH?**

A. Move BAD WOLF TARDIS closer to your phone/device.  
B. Make sure it's charged up.  
C. Turn off your BAD WOLF TARDIS and phone/device, then power up and reconnect.

**WARNING**  
Please read these safety warnings & cautions carefully to ensure your personal safety and prevent property damage.

**Fire and Electric Shock Hazard**

- Do not expose your Fametek Speaker to liquid, moisture, humidity, or rain. Do not use the Fametek speaker near a bathtub, sink, sauna, pool, or steam room. Exposure of the Fametek speaker to moisture could result in electric shock.
- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into the Fametek speaker; such actions could result in electric shock.
- Only clean the Fametek Speaker with a dry cloth.
- Do not use the speaker in extremely high or low temperatures.
- Do not leave your Fametek Speaker in direct sunlight for extended periods of time.
- Do not leave your Fametek Speaker near open flames such as cooking burners, candles, or fireplaces.
- Do not block any ventilation openings.

**Battery/Charger Hazard**

- Do not dispose of your Fametek Speaker in a fire. The battery could explode causing injury, death or paradox.
- Only charge the battery in accordance with the user instructions supplied with the Fametek Speaker.
- Do not attempt to dismantle the Fametek Speaker charger or force open the built-in battery because this may result in electric shock.
- Do not charge the Fametek Speaker in demo areas or in extremely high or low temperatures because this could result in electric shock.
- Do not leave the Fametek Speaker when it is being charged. Always unplug the charger first before cleaning the speaker.

**Automobile Accident Hazard**

- Do not leave or store the Fametek Speaker near or over your automobile's air bag because serious injury may result when an air bag deploys.
- Do not place the Fametek Speaker on high surfaces such as shelves. During music playback the speaker may fall.

**CAUTION**  
The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying the device. Read these instructions before operation. Keep these instructions for future reference. Follow all instructions for installation, use and maintenance of the device. To avoid risk of damage, place the device on a flat and hard surface. To protect the device, turn off the device, unplug the power cord and clean with soft and dry cloth. Do not expose the device to extreme temperatures recommended by the manufacturer. When the device is suddenly moved from cold to warm surroundings, condensation may form in the housing of the device. Before use, leave the device in the warm environment until the moisture has completely evaporated. Do not use accessories that are not recommended by the manufacturer. Do not attempt to replace your Fametek Speaker battery, it is built-in and is not rechargeable.

Keep out of the reach of children under 6 years old to prevent choking on small removable parts.

Use a certified, recommended, suggested charger for your Fametek Speaker. Other chargers could result in electric shock and damage to the speaker.

Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.

Turn off your Fametek Speaker prior to boarding an aircraft. Do not use the Fametek Speaker inside an aircraft unless allowed by your airline.

Dispose of the speaker and the speaker's battery in accordance with local regulations. Do not dispose of the battery with your household waste.

Any damage to the leads or terminals (such as terminals on speaker grill) to the device, without prior authorization from the manufacturer, may void your warranty and authority to operate the device.

**ROHS COMPLIANCE**  
This product is in compliance with Directive 2011/65/EU of the European Parliament and of the Council of June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

**WEEE NOTICE**  
The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 13th February 2003, resulted in a major change in the treatment of end of life. The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycle or other forms of recovery of waste electrical and electronic equipment. The WEEE Directive also sets out the basic indication for collection and treatment of electrical and electronic waste, consisting of a crossed-out wheelie bin symbol above the text "WEEE". This product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical Waste equipment by relocating over to the specified collection point for recycling of such items. Please contact your local authority for details of the collection point. Alternatively, you may return the item to the place of purchase. The collection and treatment of electrical and electronic waste equipment will allow us to help conserve natural resources. Moreover proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local city center, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.



CE This product is compliant with the CE directive. All returns must be made to the original place of purchase.



**GET FAMETEK SUPPORT**

VISIT [www.fametek.com](http://www.fametek.com)

CALL 1-323-262-2226

**PURCHASE** Other great Doctor Who™ products at [www.fametek.com](http://www.fametek.com)

Become a fan of FAMETEK on Facebook & Instagram

VISIT [WWW.FACEBOOK.COM/TARDISPEAKERS](http://WWW.FACEBOOK.COM/TARDISPEAKERS)

VISIT [WWW.FACEBOOK.COM/FAMETEKELECTRONICS](http://WWW.FACEBOOK.COM/FAMETEKELECTRONICS)

VISIT [WWW.INSTAGRAM/FAME\\_TEK](http://WWW.INSTAGRAM/FAME_TEK)

PDF created with pdfFactory Pro trial version [www.pdffactory.com](http://www.pdffactory.com)

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

\*RF warning :

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 0 centimeters from the device surface at all times, except for non-repetitive patterns with transient time intervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.