



# 英文


**Selfie Stick Tripod Stabilizer with Face Tracking**




**Product Instruction**




**Product Instruction**



**Stabilizing**



**Selfie Stick Mode**




1. open phone clamp and put your phone in center position  
2. long press power button to power on motor, enter stabilizer mode  
3. long press  button to power on remote, search and pair with "SelfieCom" in BT. at this point, the motor position can be fixed so that it no longer rotates. it can be used as a regular selfie stick.  
2. Remember not to lock the equipment when the motor is turned on. Otherwise, it is easy to cause damage to the motor.

● LED indicates Blue

4. press  button once to switch vertical or horizontal  
Double click: Jump Inception  
Long press: Clockwise Inception  
5. short press  button to enter POV mode(first person view)  
Double click: 260 degree Inception  
Long press: Counterclockwise Inception

**Face Tracking**




1. fold the arm as left image  
2. install your phone on landscape  
3. power on the motor, the camera will be activated

4. then it will start tracking your face and rotate with your movement

● LED indicates Green if it is not green, short press the power button to switch mode

**Gesture Control**



During the face tracking process, you can use gestures to control the motor to start or pause

**PALM GESTURE** ● Pause the tracking  
LED indicates Blue

**OK GESTURE** ● Start the tracking  
LED indicates Green

**Information to User**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**WARNING**


INGESTION HAZARD: This product contains a button cell or coin battery. DEATH or serious injury can occur if ingested. A swallowed button cell can cause internal chemical burns in as little as 2 hours. KEEP new and used batteries OUT OF REACH OF CHILDREN Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.	
---	---

# 中文


**单轴稳定器自拍杆 人脸追踪**



**产品介绍**



**产品介绍**



**稳定器使用**



1. 打开手机夹, 将手机放入居中位置  
2. 长按开关机, 进入稳定模式  
3. 长按遥控器  键开机, 打开蓝牙搜索配对"SelfieCom"配对成功后, 短按  键可遥控拍照或者录像  
2. 切记不要在电机开机状态锁设备。否则容易烧坏电机。

● 指示灯显示蓝色

4. 单击  键, 切换横拍竖拍  
双击: 跳跃式盗梦空间  
长按: 顺时针盗梦空间  
5. 单击  键, 进入POV模式(第一人称视角)  
双击: 260度盗梦空间  
长按: 逆时针盗梦空间

**自拍杆模式**



1. 如图所示将设备折叠  
2. 将手机水平姿势安装好  
3. 将电机开机, 自动激活摄像头。

4. 此时设备开启人脸追踪模式, 镜头自动跟随人物左右移动旋转。


● 指示灯显示绿色, 如果看到指示灯是蓝色, 需短按一下开关键切换模式

**人脸追踪**



在人脸追踪过程中, 可以通过手势远程操控电机暂停/启动追踪

**手势控制**



手掌手势 ● 暂停追踪  
指示灯显示蓝色

OK 手势 ● 启动追踪  
指示灯显示绿色

**Information to User**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**WARNING**

INGESTION HAZARD: This product contains a button cell or coin battery. DEATH or serious injury can occur if ingested. A swallowed button cell can cause internal chemical burns in as little as 2 hours. KEEP new and used batteries OUT OF REACH OF CHILDREN Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.	
---	---