


USER MANUAL



THE FIRST TIME

- Press the button of the Find My Accessory for 1 time; you will hear consecutive ringtones.

WORKING WITH APPLE FIND MY APP

For iOS device users, add your device to the Find My app, which is pre-installed on iOS systems. It enables tracking with the help of millions of Apple devices worldwide, ensuring privacy protection.

****What You Need:****

- An iPhone, iPad, or iPod touch with iOS 14.5 or later, with two-factor authentication enabled.
- Find My and Bluetooth enabled.
- A strong Wi-Fi or cellular connection.
- Location Services turned on: `Settings > Privacy&Security > Location Services`.
- For Precision Finding, enable Location Access for Find My: `Settings > Privacy&Security > Location Services`, scroll and tap on Find My, choose While Using the App / Widgets, then enable Precision Location.

Add Your Device:

1. Open the Find My app, go to the Items tab, select Add Item > Other Supported Item.
2. Press the button of the Find My Accessory for 1 time, you will hear consecutive ringtones.
3. Choose the accessory name and enter a custom name for your Find My Accessory, choose an emoji, then tap Continue.
4. To link the Find My Accessory with your Apple ID, tap Agree.
5. Tap Finish. Now you can attach your Find My Accessory to your item and track it in the Find My app.

If you can't set up your Find My Accessory:

- Ensure your Find My Accessory is ready for setup.
- If setting up multiple Find My Accessory, keep only one near your device at a time.
- If your Find My Accessory still won't connect, try resetting it.

If your Find My Accessory is connected to another Apple ID:

- If you plan to use another Apple ID, make sure to remove this Find My Accessory from the Find My app beforehand.

****Perform Serial Number Lookup:****

1. Launch the "Find My" app on your iPhone.
2. Scroll to the bottom of the "Items" tab, then tap "Identify Found Item".
3. Keep the Find My accessory near the iPhone. Once the iPhone has detected the accessory, select it from the list of found items, tap "Continue".
4. You will be taken to a page where you can learn about the item.
5. Locate the button on the front of the Findpro card. Press the button once. A confirmation beep will sound.

6. Once connected to the Find My accessory, tap "**Continue On Website**" to see if the owner has left a Lost Mode message and view the item's serial number.

Disable Find My Network

- Located the button on the front of the Findpro card.
- Press and hold the button for 6 seconds. A confirmation chime will sound. (**Tip:** You can hold the button until you hear two 'Di-Di' sounds, then release; after releasing, a long 'Di~~' sound indicates it is turned off.)

RESET

1. Press the button quickly 5 times within 5 seconds, then hold the button for 6 seconds; you will hear a confirmation ring.
2. Your Find My accessory has been successfully reset.
(**Tip:** Quickly press the button 5 times, you will hear 'Di-Di-Di' three sounds, then immediately hold for 6 seconds, After hearing two "Di-Di" sounds, indicating the operation was successful.)

How to switch between **Nearby**, **Separated** and **Disconnect**:

Nearby:

Connection Status Disconnected.

Separated:

Nearby status timeout.

power cycle

Disconnect:

Turn off mobile Bluetooth.

TCP005 Max Connection

2

whether the accessory will respond with an invalid state error or not respond at all if the Firmware Update characteristic is written to while the accessory is connected to a non-owner?

No response at

NOTICE

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.