


Sleep Headphones with Bluetooth



Speakers are found inside the headband and can be adjusted over your ears by moving the materials around the speaker.



Button Functions:

- **Power on:** Hold Down the ▷|| button for 3 Seconds
- **Power off:** Hold Down the ▷|| button for 3 Seconds
- **Increase Volume:** short press + Button
- **Decrease volume:** short press - Button
- **Previous Music:** Hold press the - Button
- **Next Music:** Hold press the + button
- **Play Music:** Short press ▷|| button
- **Pause Music:** Short press ▷|| button

1. How to Charge:

1. Turn the headband inside out and find the charging port #5 in diagram at the opening.
2. Connect USB charging cable provided to the charging port and the other side of the cable to a power source (Computer or Power Socket).
3. LED light on the front of the headband will turn red while charging and change to blue when fully charged.

2. Battery Note:

- It will take approximately 2 hours to be fully charged.
- Charging cannot be done at the same time as listening to sounds.
- Reset for operation can be done while charging if required.
- Battery when fully charged will last approximately up to 9 hours.
- Red light will flash 5 times if the battery is low.

3. LED Indicator Chart:

STATUS	INDICATOR
Bluetooth Pairing Mode	Red and blue light flash alternately
Bluetooth Connected	Blue light flashes slowly
Charging	Solid red light
Charging Complete	Solid blue light

4. Pair with Bluetooth Device:

1. Hold Down the ▷|| button for 3 Seconds until Status light #4 starts flashing red and blue.
2. Turn the Bluetooth function on the device to be paired.
3. Select, on a paired device, the device name “Musical Eye Mask” from the list of found devices.
4. The passcode is 0000 if asked.
5. Blue light will flash slowly if successfully paired with the headband.

5. Play Music with Bluetooth Pairing:

1. Hold down the Play button quickly to start music or pause.
 2. Adjust Volume by pressing + Up or – Down with a short press of a button.
- Note:

After successfully pairing your mobile phone, you will need to open a music player on your phone to play music.

6. Troubleshooting:

1. Ensure the product is fully charged, switched on , paired, or connected to the memory card.
2. If using Bluetooth, make sure your device is 10 meters/33 feed in range and no obstructions between devices.
3. Turn off all past Bluetooth devices that were previously connected to the device.

7. Washing Guidelines:

Please use the inside pouch/opening on the back of the headband to access and remove the electronic parts before hand washing the product.

	Wash with cold water		DO NOT dry clean
	Hand wash ONLY		DO NOT bleach
	DO NOT tumble dry		DO NOT iron

8. Specifications:

- Bluetooth Version: V5.2
- Frequency: 2.402 GHz – 2.480GHz
- Transmission Range: 20M/66FT
- Rated Power: RMS 10mWx 2
- Speaker Unit: 32Ω x 20mm
- Battery: 3.7V 300mAh Rechargeable Li-Polymer Battery
- Charge Time: 2 Hours
- Battery Length: Approx 35 Hours

⚠ Dangers of Injury:

- Keep the product and the package away from children and animals, as they can swallow small parts.
- Supervise children using the product . It is not a toy.
- Always maintain a gap of at least 10 cm between the headphones and a pacemaker or an implantable cardioverter defibrillator (ICD) as the product generates magnetic fields.

⚠ Danger of Fire:

- **Caution!** Don't expose the headphones to any high temperatures over 70 degrees Celsius (Like hair dryers, heating, prolonged sunlight etc..). The battery inside the headphones may overheat.
- Only charge the headphones in an ambient temperature area from 10 degrees Celsius to 40 degrees Celsius.
- Do not crush or pierce the battery! Do not expose the battery to high pressure, as this may cause an internal short-circuit and overheating.


Customer Support:

Please contact info@mywaves.tech if you have further questions.

Casque de sommeil avec Bluetooth



Les haut-parleurs se trouvent à l'intérieur du bandeau et peuvent être ajustés sur vos oreilles en déplaçant la metiere autour des haut-parleurs.



Fonctions des boutons:

- **Allumer:** Maintenez le bouton ▷|| enfoncé pendant 3 secondes
- **Éteindre:** Maintenez le bouton ▷|| enfoncé pendant 3 secondes
- **Augmenter le volume:** Appuyez brièvement sur le bouton +
- **Diminuer le volume:** Appuyez brièvement sur le bouton -
- **Musique précédente:** Maintenez le bouton - enfoncé
- **Musique suivante:** Maintenez le bouton + enfoncé
- **Lire la musique:** Appuyez brièvement sur le bouton ▷||
- **Mettre en pause la musique:** Appuyez brièvement sur le bouton ▷||

1. Comment charger:

1. Retournez le bandeau et trouvez le port de chargement (#5 dans le diagramme à l'ouverture).
2. Connectez le câble de chargement USB fourni au port de chargement et l'autre côté du câble à une source d'alimentation (ordinateur ou prise électrique).
3. Le voyant LED à l'avant du bandeau devient rouge pendant le chargement et passe au bleu une fois complètement chargé.

2. Remarque sur la batterie:

- Il faut environ 2 heures pour une charge complète.
- Le chargement ne peut pas être effectué en même temps que l'écoute des sons.
- La réinitialisation de l'opération peut être effectuée pendant le chargement si nécessaire
- La batterie, une fois complètement chargée, dure environ 9 heures.
- Le voyant rouge clignote 5 fois si la batterie est faible.

3. Tableau des indicateurs LED:

STATUT	INDICATEUR
Mode appairage Bluetooth	Lumière rouge et bleue clignote en alternance
Bluetooth connecté	Lumière bleue clignote lentement
En charge	Lumière rouge fixe
Charge complète	Lumière bleue fixe

4. Appairage avec un appareil Bluetooth:

1. Maintenez le bouton ▷|| enfoncé pendant 3 secondes jusqu'à ce que le voyant de statut (#4) clignote en rouge et bleu.
2. Activez la fonction Bluetooth sur l'appareil à appairer.
3. Sélectionnez le nom de l'appareil "Masque musical" dans la liste des appareils trouvés.
4. Le code d'accès est 0000 si demandé.
5. La lumière bleue clignotera lentement si le bandeau est correctement appairé.

5. Écouter de la musique avec l'appairage Bluetooth:

1. Maintenez le bouton ▷|| enfoncé rapidement pour démarrer la musique ou la mettre en pause.
 2. Ajustez le volume en appuyant brièvement sur les boutons + ou -.
- Remarque:

Après avoir appairé votre téléphone mobile, vous devrez peut-être ouvrir un lecteur de musique sur votre téléphone pour commencer à lire de la musique.

6. Dépannage:

1. Assurez-vous que le produit est complètement chargé, allumé, appairé ou connecté à la carte mémoire.
2. Si vous utilisez Bluetooth, assurez-vous que votre appareil est à moins de 10 mètres/33 pieds de portée et qu'il n'y a pas d'obstructions entre les appareils.
3. Éteignez tous les anciens appareils Bluetooth qui étaient précédemment connectés à l'appareil.

7. Instructions de lavage:

Utilisez la pochette intérieure/ouverture à l'arrière du bandeau pour accéder et retirer les composants électroniques avant de laver le produit à la main.

	Laver à l'eau froide		NE PAS nettoyer à sec
	Lavage à la main UNIQUEMENT		NE PAS blanchir
	NE PAS sécher au sèche-linge		NE PAS repasser

8. Spécifications:

- Version Bluetooth: V5.2
- Fréquence: 2.402 GHZ – 2.480GHz
- Portée de transmission: 20M/66FT
- Puissance nominale: RMS 10mWx 2
- Unité de haut-parleur: 32Ω x 20mm
- Batterie: Batterie Li-Polymer rechargeable de 3.7V 300mAh
- Temps de charge: 2 heures
- Durée de la batterie: Environ 35 heures

⚠ Risques de blessure:

- Gardez le produit et l'emballage hors de portée des enfants et des animaux, car ils peuvent avaler de petites pièces.
- Surveillez les enfants utilisant le produit. Ce n'est pas un jouet.
- Maintenez toujours une distance d'au moins 10 cm entre les écouteurs et un stimulateur cardiaque ou un défibrillateur cardiovertteur implantable (DCI) car le produit génère des champs magnétiques.

⚠ Risques d'incendie:

- **Attention!** N'exposez pas les écouteurs à des températures élevées supérieures à 70 degrés Celsius (comme les sèche-cheveux, le chauffage, l'exposition prolongée au soleil, etc.). La batterie à l'intérieur des écouteurs peut surchauffer.
- Chargez uniquement les écouteurs dans une zone à température ambiante de 10 à 40 degrés Celsius.
- Ne pas écraser ou percer la batterie ! Ne pas exposer la batterie à une pression élevée, car cela pourrait provoquer un court-circuit interne et une surchauffe.

Support client:

Veuillez contacter info@mywaves.tech si vous avez d'autres questions.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction