

G-TIDE
USER MANUAL

1. Multi-functional Touch Key

2. LCD Touch Screen


3. USB Type-C Charging Port

4. Speaker

5. Microphone

6. Charging Pin

DWS1



Warranty

G-TIDE OFFICIAL SERVICE TEAM MAILBOX: service@g-tide.com
Official Website: www.g-tide.com



Please contact us at
cservice@g-tide.com or
with your order ID and issue details.



Subscribe to our Facebook account to get
the latest information about G-TIDE.
<https://www.facebook.com/gtide.fans>

EN English

Product parameters

-Model: DWS1
-Wireless version: 5.3
-Working range: barrier-free 10 meters
-Wireless frequency: 2,402-2,480GHz
-Charging box capacity: 3.7V,300mAh
-Charging input: DC5V-500mA
-Charging time: about 1 hours
-Earphone built-in battery: 3.7V, 30mAh*2
-Play music: about 4.5 hours (80% volume)
-Talk time: about 4 hours (80% volume)
-Number of times the charging case charges the earphones: About 4 times
-Charge and discharge cycle: ≥300 times
-Charging port: Type-C

Figure 1-Warning label (IEC 60417-0044)



Operation Method-Earphones

-Power on: Open the charging case cover, the headphones will automatically turn on, wait for Wireless connection
-Power off: Put the earphones into the charging case, And close the charging case cover
-Pairing mode: The earphones automatically enter pairing mode when turned on
-Pause/Play: Click on the left or right earphones
-Answer incoming calls: Click on the left or right earphones
-Hang up the phone: Double click on the left or right earphones
-Call rejection: Long press the left or right earphones for 2 seconds
-Next song :Double click on the right ear

-Previous song: Double click on the left ear
-Volume -: Swipe down the left/right earphones to decrease volume
-Volume+: Slide up the left/right earphones to increase volume
-Voice Assistant: Long press the left earbud for 3 seconds.
-ANC Mode: Long press the right earbud for 3 seconds.

Operation method -charging case color screen

-Pause/Play/Up/Down Song: Center icon "Play" and "Pause", left icon for previous song, right icon for next song
-Volume+/-: Left icon reduces volume, right icon increases volume
-Noise reduction interface: Off mode, Noise reduction mode, Transparent mode
-Equalizer interface: Click on the left or right icons to switch sound effects
-Set alarm clock: can be set for 5 minutes, 10 minutes, 30 minutes, 60 minutes
-Adjusting screen brightness: The left icon reduces brightness, while the right icon increases brightness (increasing brightness consumes more power)
-Language switching: Click on the left/right icon to switch between Chinese and English
-Set lock screen wallpaper: Click on the left/right icon to replace the lock screen wallpaper
Find headphones: Click on L/R, the interface will appear, click on start, the corresponding L/R headphones will emit sound, click on stop to end
Time setting: You can manually change the time and save it (if the charging case is not used for a long time, the time will be automatically updated when the headphones are connected to the phone)
Video like function: Click on the heart-shaped icon in the middle to like the video, click on the left/right icon to switch to the previous or next video playback (iOS phones need to enable touch assist in the touch assist function)
Photo control function: First, turn on the camera on the phone, then click on the take photo icon on the color screen to control the phone to take photos
On/off lighting: Click to turn on, the screen emits white light, then click on the screen to turn off the lighting

Charging

-Reminder of low headphone battery: When the battery voltage is below 3.3V, remind every 1 minute
-Earphone charging: Put the earphones into the charging case, close the lid, and automatically charge them. It takes about 1.5 hours to fully charge them
-Low battery reminder for charging case: When the battery level is below 10%, the charging case icon displays red (When the voltage of the charging case is below 3.4V, the charging case will automatically shut down at the red color screen will not display)
-Charging case charging: The color screen displays the charging icon, which goes off after 30 seconds and takes about 3 hours to fully charge

Universal wireless connection operation

1. Please put the wireless headset and mobile phone (or other connected devices) together;
2. Ensure that the earphones are charged, open the charging case cover, and the left and right earphones are connected to each other. The earphones can enter pairing mode;
3. Turn on the Wireless function of the user's mobile phone (or other Wireless device), and search or scan. At this time, the mobile phone will search for all nearby Wireless devices. Click the corresponding Wireless model name to connect. After successfully pairing and connecting, you can make a headset call., Listening to songs, etc.

Considerations when connecting wirelessly

1. Please control the distance between the wireless headset and the mobile phone (or other connected equipment) within 1 meter, the closer the better;
2. Open the charging case cover to connect;
3. When connecting, make sure that the left and right earphones are interconnected and in the on state;
4. The charging box needs to have enough power. If the headphones cannot be turned on when the cover is opened, put the headphones in the charging box, close the cover of the charging box and plug in the charger to charge for at least one hour;

Precautions

1.Never use corrosive cleaning agents to clean this product;
2. Do not allow this product to heat or come close to fire sources, such as cooking stoves;
3. Do not expose this product to direct sunlight for a long time to avoid high temperature;
4. Do not dispose of this product in fire to avoid explosion;
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components;
6. Do not use this product in the rain;
7. If you do not plan to use this product for a long period of time, please store it in a dry environment.And charge the headset at least once a month to extend the life and avoid extreme temperatures and dust.
8.Special Note: Storage Mode
8.1 Entering the storage (shutdown) mode: headset into the storage and close the cover, quickly press the storage button 2 times to enter the shutdown/reset operation interface, click the shutdown menu.
8.2 Release the storage (power off) mode: 1. Bin plugged into the USB charging for 2 seconds, 2, or long press the button for 6 seconds to restart (the screen lights up at about the 8th second)

ES español

Parámetros del producto

-Modelo: DWS1
-Versión inalámbrica: 5.3
-Alcance: 10 metros sin barreras
-Frecuencia inalámbrica:2,402-2,480GHZ
-Capacidad de la caja de carga:3.7V,300mAh
-Entrada de carga:DC5V-500mA
-Tiempo de carga: alrededor de 1 horas
-Batería integrada de los auriculares: 3.7 V,30mAh*2
-Reproducción de música: unas 4,5 horas (80% volumen)
-Tiempo de conversación: unas 4 horas (80% volumen)

Figure 1-Warning label (IEC 60417-0044)



-Tiempo de carga de la caja de carga a los auriculares: unas 4 veces
Ciclo de carga/descarga:>300 veces
-Puerto de carga: Tipo-C
Nota: Las especificaciones del producto son datos de prueba de laboratorio, diferentes entornos serán diferentes; los productos se actualizan y mejoran constantemente, las características específicas y las imágenes del producto pueden ser ligeramente diferentes de la cosa real, por favor prevalecer en especie.

Modo de funcionamiento de los auriculares

-Encendido: Abra la tapa del estuche de carga, los auriculares se encenderán automáticamente y esperarán la conexión Bluetooth.
-Apagado: Coloca el auricular en la caja de carga y cierra la tapa de la caja de carga.
-Modo de emparejamiento: El auricular entra automáticamente en el modo de emparejamiento cuando se enciende.
-Pausar/Reproducir: Pulsa el auricular izquierdo o derecho.
-Responder a una llamada entrante: haz clic en el auricular izquierdo o derecho.
-Colgar: haz doble clic en el auricular izquierdo o derecho.
-Rechazo de llamada: mantenga pulsado el auricular izquierdo o derecho durante 2 segundos.
-Siguiente canción: doble pulsación en la oreja derecha
-Canción anterior: doble clic en la oreja izquierda
-Volumen -:Destiza hacia abajo el auricular izquierdo/derecho para reducir el volumen.
-Volumen +:Destilza hacia arriba el auricular izquierdo/derecho para subir el volumen.
-Asistente de Voz: Mantén presionado el auricular izquierdo durante 3 segundos.
-Modo ANC: Mantén presionado el auricular derecho durante 3 segundos.

Modo de funcionamiento - Pantalla en color del compartimento de carga

-Pausa/reproducir/arriba/abajo: icono central "reproducir", "pausa", icono izquierdo cancelación anterior, icono derecho cancelar siguiente.
-Volumen +/-: icono izquierdo bajar volumen, icono derecho subir volumen.
-Interfaz de reducción de ruido: modo desactivado, modo de reducción de ruido, modo de transparencia.

-Interfaz del equalizador: haga clic en el icono izquierdo/derecho para cambiar el efecto de sonido.
-Ajuste de la alarma: puede ajustar 5 minutos, 10 minutos, 30 minutos, 60 minutos.
-Ajustar el brillo de la pantalla: icono izquierdo para reducir el brillo, icono derecho para aumentar el brillo (a mayor brillo, mayor consumo de energía).
-Cambio de idioma: pulse el icono izquierdo/derecho para cambiar entre inglés y chino.
-Ajuste del fondo de pantalla de bloqueo: pulse el icono izquierdo/derecho para cambiar el fondo de pantalla de bloqueo.
-Buscar auriculares: haga clic en L/R, aparece la interfaz, haga clic en iniciar, los auriculares L/R correspondientes emitirán un sonido, haga clic en detener fin
-Ajuste de la hora: puede cambiar manualmente la hora y guardarla (si el compartimento de carga no se utiliza durante mucho tiempo y la hora no es exacta, la hora se actualizará automáticamente cuando los auriculares se conecten al teléfono móvil).
-Vídeo como función: haga clic en el icono central en forma de corazón para el vídeo como, haga clic en el icono de la izquierda / derecha para cambiar a la reproducción de vídeo anterior o siguiente (teléfonos móviles iOS necesitan de abrir las funciones auxiliares en la función táctil asistida) para tomar fotos para controlar la función: primero encienda la cámara en el teléfono móvil, y luego haga clic en la pantalla a color en el icono de la foto, se puede controlar el teléfono móvil para tomar fotos
-Interruptor de luces: haga clic para abrir, la pantalla emite luz blanca, y luego haga clic en la pantalla para cerrar.

Carga

-Recordatorio de batería baja de los auriculares: cuando el voltaje de la batería es inferior a 3.3 V, se lo recordará cada 1 minuto.
-Carga de los auriculares: introduzca los auriculares en el estuche de carga, cierre la tapa y se cargarán automáticamente, en aproximadamente 1.5 horas.
-Recordatorio de batería baja de la caja de carga: cuando la batería es inferior al 10%, el icono de la caja de carga se mostrará en rojo (cuando el voltaje de la caja de carga es inferior a 3.4 V, la caja de carga se apagará automáticamente y no se mostrará la pantalla en color).
-Carga del compartimento de carga: la pantalla en color muestra el icono de carga,

[illegible]

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.