





71137 - MANUAL CJ Tech Earbuds - BLACK

FRONT ENGLISH

 <p>Item 71137 TWS BLUETOOTH EARBUDS</p> <p>USER MANUAL - ENGLISH</p> <p>PRODUCT PARAMETERS</p> <p>EARPHONES</p> <ul style="list-style-type: none"> • Model: Wireless Stereo Headphones • Transmission power: Level 2 • Frequency range: 2.402ghz-2.480ghz • Talk time: 4-5 hours (full charge) • Playing time: 4-5 hours (full charge) • Battery: Li-ion polymer 3.7V>50mA • Charging time: 1-2 hours • Support files: support HFP 1.7, HSP 1.2, A2DP1, AVRCP 1.6 SPP 1.2 and PBAP 1.0 <p>CHARGING CASE</p> <ul style="list-style-type: none"> • Input: 5V ==1A • Output: 5V ==1A 	<p>LEFT EARPHONES</p>  <p>Long Press for 1.5 secs: The Previous song</p> <p>Double Clicks: Volume -</p> <p>RIGHT EARPHONES</p>  <p>Long Press for 1.5 secs: The Next song</p> <p>Double Clicks: Volume +</p> <p>CONNECTION METHOD</p> <p>The headset starts automatically and pairs automatically. Take out the two earphones from the charging case, you can see that the two earphones flash alternately for about 2-3 seconds, and the left and right earphones turn into red and blue lights respectively. The headset prompts "pairing successful", and the headset is ready to use. When the red and blue lights flash slowly, double-click (left) the earphone to decrease the volume, and double-click (right) the earphone to increase the volume.</p> <p>MOBILE PHONE CONNECTION OPERATION</p> <p>Open the mobile phone bluetooth search, click the searched device name "CJ Tech TWS Earbuds". You will see your phone display: "Connected". At the same time, the left earphone (L) prompts "Connected". That is to say, the headset and mobile phone link have been successfully paired and can be used at this time.</p>	<p>PREVIOUS/NEXT SONG OPERATION</p> <p>Long press the main earphone (L) for 1.5 seconds to play the previous song. Press and hold the pair of headphones (R) for 1.5 seconds to play the next song.</p> <p>ANSWERING AND HANGING UP INCOMING CALLS</p> <p>When an incoming call comes in, press the earphones button to answer it. After the call is over, press the headset button again to hang up the call.</p> <p>REJECT INCOMING CALLS</p> <p>Long press the headset button for 2 seconds to reject incoming calls.</p> <p>POWER OFF OR SHUT DOWN</p> <p>Put the headset directly back into the charging case, the earphones will be automatically disconnected from the mobile phone, or press and hold the headset button for 3-5 seconds, the headset indicator will flash red 3 times, turn it off afterwards.</p> <p>MORE THAN 2 TIMES OF USE</p> <p>Turn on the bluetooth of the mobile phone with the connected mobile phone, and take out the earphone in the charging box at the same time, without any operation, it will automatically link with the mobile phone. If you use a different phone, you need to shut down and reconnect before you can use it.</p> <p>USE ALONE</p> <p>Use the earphone (L) or earphone (R) alone, power on, turn on the phone's bluetooth and search for the "CJ Tech TWS Earbuds", after the device flashes red and blue, click to open the connection and use it.</p>	<p>LED INDICATOR STATUS</p> <ul style="list-style-type: none"> • Pairing status: red and blue lights flash alternately • Pairing is successful: the red and blue lights are off • Charging status: red light is always on • Charging is complete: the red light is off <p>EARPHONE CHARGING</p> <p>The headset comes with a non-removable built-in rechargeable battery. When using the device for the first time, make sure the battery is fully charged. Connect the charging cable to the charging port of the headset and plug the charging cable into a standard USB 5V socket.</p> <p>While charging, the indicator light will turn red. When the device is fully charged, the light will change from red to blue or off. Then unplug the charging cable from the USB outlet and the earphones. Use only certified charging adapters. Unapproved or non-standard USB 5V sockets can cause damage to the earphones or explode in extreme conditions and void the product warranty.</p> <p>Repeated charging and discharging of earphones can degrade battery performance over time. This is normal for any rechargeable battery.</p> <p>PRECAUTIONS</p> <ul style="list-style-type: none"> • Do not drop, bump, scratch, twist, knock, squeeze, etc. • Keep the earphones away from magnets, electrical appliances and speakers when in use. • Avoid exposing the headset to extreme temperatures (normal working environment -10°C~45°C) • Avoid exposing the headset to moisture when the headset battery is low, the headset will repeat the voice message "battery low, 	<p>please charge". While indicating the light will flash red. If the headset runs out of power during a call, the call will automatically be transferred back to the phone.</p> <p>KINDTIPS</p> <ul style="list-style-type: none"> • Do not make or receive calls while the phone is charging. To answer a call, be sure to unplug the charging cable first. • To save energy, please take off the earphones to charge when you are not using them. Because the travel charger has no power, please unplug the charging cable from the socket before disconnecting the power during use. The charging cable should be close to the socket. <p>The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by CJ Global is under license. Other trademarks and trade names are those of their respective owners.</p> <p>CJ Tech is distributed by CJ Global Inc. 2010 Maple Ave Fair Lawn NJ 07410, All rights reserved.</p> <p>MADE IN CHINA</p>
---	---	---	---	--

BACK FRENCH

 <p>Article 71137 TWS ÉCOUTEURS BLUETOOTH</p> <p>MANUEL D'UTILISATION FRANÇAIS</p> <p>PRODUCT PARAMETERS</p> <p>EARPHONES</p> <ul style="list-style-type: none"> • Modèle : Écouteurs stéréo sans fil • Puissance de transmission : Niveau 2 • Gamme de fréquences : 2,402 GHz - 2,480 GHz • Durée de conversation : 4-5 heures (pleine charge) • Durée de lecture : 4-5 heures (pleine charge) • Batterie : Li-ion polymère 3,7 V > 50 mA • Temps de charge : 1-2 heures • Fichiers supportés : HFP 1.7, HSP 1.2, A2DP1, AVRCP 1.6, SPP 1.2 et PBAP 1.0 <p>BOÎTIER DE CHARGE</p> <ul style="list-style-type: none"> • Entrée : 5V ==1A • Sortie : 5V ==1A 	<p>ÉCOUTEUR GAUCHE</p>  <p>Appuyez longuement pendant 1,5 seconde : La chanson précédente</p> <p>Double-clics : Volume -</p> <p>ÉCOUTEUR DROITS</p>  <p>Appuyez longuement pendant 1,5 seconde : La chanson suivante</p> <p>Double-clics : Volume +</p> <p>MÉTHODE DE CONNEXION</p> <p>Les écouteurs s'allument automatiquement et se jumellent automatiquement. Sortez les deux écouteurs du boîtier de charge, vous verrez que les deux écouteurs clignotent alternativement pendant environ 2-3 secondes, et les écouteurs gauche et droit passent respectivement en lumière rouge et bleue. Les écouteurs indiquent "appairage réussi", et les écouteurs sont prêts à l'emploi. Lorsque les lumières rouges et bleues clignotent lentement, double-cliquez (gauche) sur l'écouteur pour diminuer le volume, et double-cliquez (droite) sur l'écouteur pour augmenter le volume.</p> <p>OPÉRATION DE CONNEXION AU TÉLÉPHONE PORTABLE</p> <p>Ouvrez la recherche Bluetooth de votre téléphone portable, cliquez sur le nom de l'appareil recherché "CJ Tech TWS Earbuds". Vous verrez que votre téléphone affiche : "Connecté". En même temps, l'écouteur gauche (L) indique "Connecté". Cela signifie que le lien entre les écouteurs et le téléphone portable a été correctement jumelé et peut être utilisé à ce moment-là.</p>	<p>OPÉRATION CHANSON PRÉCÉDENTE/SUIVANTE</p> <p>Appuyez longuement sur l'écouteur principal (L) pendant 1,5 seconde pour lire la chanson précédente. Appuyez longuement sur la paire d'écouteurs (R) pendant 1,5 seconde pour lire la chanson suivante.</p> <p>RÉPONDRE ET RACCROCHER LES APPELS ENTRANTS</p> <p>Lorsqu'un appel entrant arrive, appuyez sur le bouton des écouteurs pour y répondre. Après la fin de l'appel, appuyez de nouveau sur le bouton des écouteurs pour raccrocher l'appel.</p> <p>REJETER LES APPELS ENTRANTS</p> <p>Appuyez longuement sur le bouton des écouteurs pendant 2 secondes pour rejeter les appels entrants.</p> <p>ÉTEINDRE OU FERMER</p> <p>Remettez directement les écouteurs dans le boîtier de charge, les écouteurs seront automatiquement déconnectés du téléphone portable, ou appuyez longuement sur le bouton des écouteurs pendant 3-5 secondes, l'indicateur des écouteurs clignotera en rouge 3 fois, puis s'éteindra.</p> <p>PLUS DE 2 FOIS D'UTILISATION</p> <p>Activez le Bluetooth du téléphone portable avec le téléphone connecté et sortez les écouteurs du boîtier de charge en même temps, sans aucune opération, ils se connecteront automatiquement au téléphone portable. Si vous utilisez un téléphone différent, vous devez éteindre et reconnecter avant de pouvoir l'utiliser.</p>	<p>UTILISATION EN SOLO</p> <p>Utilisez l'écouteur (L) ou l'écouteur (R) seul, allumez-le, activez le Bluetooth du téléphone et recherchez "CJ Tech TWS Earbuds", après que l'appareil ait clignoté en rouge et bleu, cliquez pour ouvrir la connexion et l'utiliser.</p> <p>STATUT DE L'INDICATEUR LED</p> <ul style="list-style-type: none"> • Statut de l'appareil : les lumières rouges et bleues clignotent alternativement • Appairage réussi : les lumières rouges et bleues sont éteintes • Statut de charge : la lumière rouge est allumée en continu • Charge terminée : la lumière rouge est éteinte <p>CHARGE DES ÉCOUTEURS</p> <p>Les écouteurs sont équipés d'une batterie rechargeable intégrée non amovible. Lors de la première utilisation de l'appareil, assurez-vous que la batterie est complètement chargée. Connectez le câble de charge au port de charge des écouteurs et branchez le câble de charge dans une prise USB 5V standard. Pendant la charge, le voyant lumineux deviendra rouge. Lorsque l'appareil est complètement chargé, le voyant passera de rouge à bleu ou s'éteindra. Ensuite, débranchez le câble de charge de la prise USB et des écouteurs.</p> <p>Utilisez uniquement des adaptateurs de charge certifiés. Les prises USB 5V non approuvées ou non standard peuvent endommager les écouteurs ou exploser dans des conditions extrêmes et annuler la garantie du produit. Les charges et décharges répétées des écouteurs peuvent dégrader les performances de la batterie au fil du temps. Cela est normal pour toute batterie rechargeable.</p>	<p>PRÉCAUTIONS</p> <ul style="list-style-type: none"> • Ne pas laisser tomber, heurter, rayer, tordre, frapper, presser, etc. • Tenez les écouteurs éloignés des aimants, des appareils électriques et des haut-parleurs pendant leur utilisation. • Évitez d'exposer les écouteurs à des températures extrêmes (environnement de travail normal -10°C~45°C). • Évitez d'exposer les écouteurs à l'humidité. Lorsque la batterie des écouteurs est faible, les écouteurs répéteront le message vocal "batterie faible, veuillez charger". Pendant ce temps, le voyant lumineux clignotera en rouge. Si les écouteurs s'épuisent pendant un appel, l'appel sera automatiquement transféré au téléphone. <p>CONSEILS UTILES</p> <ul style="list-style-type: none"> • Ne passez pas d'appels ni ne recevez d'appels pendant que le téléphone est en charge. Pour répondre à un appel, assurez-vous de débrancher d'abord le câble de charge. • Pour économiser de l'énergie, veuillez retirer les écouteurs pour les charger lorsque vous ne les utilisez pas. Comme le chargeur de voyage n'a pas de puissance, veuillez débrancher le câble de charge de la prise avant de déconnecter l'alimentation pendant l'utilisation. Le câble de charge doit être proche de la prise. <p>Le nom de marque et les logos Bluetooth® sont des marques déposées appartenant à Bluetooth SIG, Inc. et toute utilisation de ces marques par CJ Global est sous licence.</p> <p>CJ Tech is distributed by CJ Global Inc. 2010 Maple Ave Fair Lawn NJ 07410. All rights reserved.</p> <p>FABRIQUÉ EN CHINE</p>
---	---	--	---	--

65x92mm / 325x92mm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction