

T3 Art Projector User Manual

SketchBear



Caydo

Craft Anything You Dream Of

www.caydo.com



WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years.

INS1680

Customer Service Instructions

Thank you for choosing Caydo. We stand behind our products and provide comprehensive customer service for our customers. If you encounter any problems or have any suggestions or doubts about the products, please don't hesitate to contact us and we will respond to your email within 24 hours.

Contact Customer Service:
Email: support@caydo.com

WARNING

This product is not suitable for children aged 3 and under.

Do not look directly at the projector lens when the product is in operation to avoid eye burns.

Always handle the product with care and avoid touching the lens. Before retracting the projector stand, ensure the lens is fully retracted to avoid damage.

Handle Strap: The handle strap is not a toy and should not be used for other purposes.

Power Adapter:

Use only the original power adapter provided;

Do not use the adapter to power other products.

Remote Control:

Remove the batteries (not included) if not in use for an extended period.

Cleaning Instructions: Unplug the power supply before cleaning. Wipe the surface gently with a dry cloth to remove dust or stains.

Component Inspection: Regularly check the Remote Control, Power Adapter, Casing, Stand and other components for damage.

Disassembly Prohibition: Do not disassemble the product by any means.

For any questions, contact customer service promptly.

In The Box

Projector × 1

Remote Control × 1 (Batteries are not included)


Power Adapter × 1

User Manual × 1

Handle Strap × 1

Product Overview


Projector



Specifications

Native Resolution	720P
Projection Screen Aspect Ratio	16:9
Throw Ratio	0.88:1
Adapter	12V ==
Input Voltage	12V == 2A
Image Format	JPEG .PNG .BMP .GIF
Audio Format	FLAC .MP3 .OGG .WAV
Video Format	3gp .avi .mkv .mov .mp4 .mpg .
Focusing Method	Manual
Keystone Correction	Manual & Auto (Desktop Mode: horizontal $\pm 10^\circ$, Wall Mode: vertical $\pm 10^\circ$)

Remote Control




FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Product Installation



Take the projector out of the packaging box and place it on a suitable table.

1



Hold the top of the projector steady and lift the top by pulling it from front to back.

Screen Mirroring

1.Wired Screen Mirroring

Note: This function is only for iOS devices.

Step 1: Go to Home - Screen Mirroring - Wired Screen Mirroring and press the confirm button.

Step 2: Insert one end of the USB data cable (not included as standard) into the projector and the other end into your Apple mobile phone. Follow the on-screen instructions to connect, and the content on the mobile phone will be displayed on the projector.

2.Wireless Screen Mirroring

Note: This function is for iOS and Android devices.

Step 1: Ensure that the projector and your device are connected to the same Wi-Fi;

Step 2: Go to Home - Screen Mirroring - Wireless Screen Mirroring and press the confirm button, and follow the on-screen instructions to operate and connect.

For more settings options, please go to Homepage - Settings to view and configure them.

Wi-Fi Connection

Go to Homepage - Wi-Fi to turn on it, choose the network and type the password that you want to connect to.

Bluetooth Connection

Go to Homepage - Settings - Bluetooth Mode, press the confirm button, and follow the on-screen instructions to operate.

[Connect the projector to an external Bluetooth speaker]

Step 1: Turn on your Bluetooth device(Bluetooth earphones or speakers)and make sure it is discoverable.

Step 2: Go to Homepage-Settings -Bluetooth- Bluetooth Transmit Mode- to turn on it, click Search for Bluetooth devices(Bluetooth earphones or speakers)and pair the device that you want to connect to.

[Use the projector as a Bluetooth speaker]


After clicking Bluetooth Receive Mode, turn on the Bluetooth function of your device, search for "Projector_BT" and connect. The sound from the device will be played through the projector.

2




Hold the top of the projector steady and push from the back to the front until the stand is upright.

3



Adjust the stand height.

4




Connect the power supply

Warning: Please use the original power adapter provided

Note: When powered on, the power indicator light will show blue, then turn red after 2 seconds, and the device will enter standby mode;


5



Pull out the paper presser to stabilize the main unit.

8

Control Buttons



Manual Focus

When the projector is powered on, you can hold the camera steady, and gently rotate the focus ring at a uniform speed with your hand until the image becomes clear.

Warning: Do not rotate the focus ring rapidly with excessive force.

Keystone Correction

When the projector is powered on, it will automatically correct the keystone distortion.

Note: The auto keystone range: Desktop Mode: horizontal $\pm 10^\circ$, Wall Mode: vertical $\pm 10^\circ$

If you find the image is not square, please go to Homepage - Settings - Projection - Keystone Correct and follow the on-screen instructions to perform manual keystone correction.

Projector Connection And Input Source

HDMI Connection: insert the hdmi cable, then go to homepage -hdmi and click it, then to locate and play the file.

USB Connection: insert the usb flash drive, then go to homepage -usb and click it, then to locate and play the file.

Note: HDMI cables and USB drives are not included as standard.

13

Product Usage


Method 1: Projector Standalone Drawing Mode

After powering on, go to the homepage and launch the Art Drawing APP. Select an interesting theme, then press the "OK" button on the device or remote control to enter the image template. Press the "OK" button again to start the "Step-by-Step Guidance" for tracing drawing.

Method 2: Assisted Drawing via Caydo Art Design App


1. Connect your device and the projector to the same Wi-Fi network first.
2. Download and install the Caydo Art Design App:
 - 2.1 For iOS users: Search and download from the App Store.
 - 2.2 For Android users: Search and download from Google Play.
3. On the homepage of the Caydo Art Design App, select the "T3 Art Projector" and follow the prompts to connect to the projector.
4. Once your device and projector are successfully connected, you can choose materials from the App or select an image from your device to trace.
5. Tracing an image:
 - 5.1 Tap the camera button (you will need to enable permissions to access the camera and photos).
 - 5.2 Select an image from your device's photo library or take a photo using the App's built-in camera.
 - 5.3 Choose a filter effect.
 - 5.4 Tap the "Confirm" button to transfer the image to the T3 Art Projector.
 - 5.5 Start tracing the image on paper.

6



Press the power button to turn on the projector, and the indicator light will change from red to blue.


7



Rotate to focus until the image becomes clear.


Product Storage

1




Rotate the focus ring to ensure the lens is fully retracted.

2




Hold the device with one hand and push the ball-shaped handle backward with the other hand.

3



Hold the hinge with one hand and push the ball-shaped handle forward with the other hand.

4



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***RF warning for Mobile device:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.