


注意事项：

- 1.餐后30分钟才可使用。
- 2.女性妊娠期或者生理期不宜使用。
- 3.电子产品不可以水洗，可以用抹布擦拭。
- 4.机器电池没电后及时充电，防止电池亏电。
- 5.使用过程感觉身体不适应立即停止使用。
- 6.使用时建议佩戴拳击套。
- 7.禁止私自拆卸产品。



4

YP-001 使用说明书



使用前请仔细阅读说明书

FCC Warning


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Gloves Operation(If included):



Caution:

1. Don't use until 30minutes after a meal
2. It should not be used during pregnancy or menstruation
3. Electronic products can not be washed, can be wiped with a rag.
4. The machine battery is out of power after timely charging, to prevent battery loss.
5. Stop using immediately if you feel that your body is not used to it
6. It is recommended to wear boxing gloves when using
7. It is prohibited to disassemble the product without permission.

4

产品介绍：


拳击是一种格斗运动, 由两个体格和能力相当的对对手用手套盖住拳头互相 搏斗, 它既是一项业余的,也是一项职业的运动项目, 在进行拳击训练时, 通常会使用拳击靶来对选手的速度和力度进行训练。

由于拳击比赛对手的空档稍纵即逝, 相较于力量训练, 更重要的是选手的进攻以及防守的反应能力, 产品通过电子控制灯光指引来训练人的反应能力, 通过音效提示是否准确的击打目标点上, 从而高效的锻炼人的整体协调能力和感应能力。

产品参数：


输入电压：DC3.7V 功率：7.4W
工作电压： 3.7V
产品尺寸： 40*40*5.5cm
产品毛重： 2kg

续航电池容量：



2

操作说明：



充电说明：

使用手机充电器(5v1A-2A)通过配的从电线链接充电。

安装说明：

第一种安装方式（如下图），撕开机器背后的贴纸直接安装在想要安装的墙壁等位置，注意充电口离插座距离不超过1.8米。



3

Introduction:


Boxing is a combat sport in which two opponents of equal size and ability cover their fists with gloves,Fighting each other, it is both an usually used to train the speed and strength of the players during amateur and a professional sport. In boxing, boxing targets are boxing training. Since the opponent's gap in boxing matches is so short, speed is more important than strength training,hand offensive and defensive reflexes, the product uses electronically controlled light guidance to train people's ability to respond by sound signals to accurately hit the target point, thus efficient forging exercise one's overall coordination and sensitivity.

Technical Data:

Input : DC 3.7V Power :7.4W Working Voltage :3.7V
Carton : 40x40x5.5cm N.W/G.W : 1.5kg/2kg
Battery : 2000mA

Charging:

Use the mobile phone charger (5V/1A-2A) to charge via the attached cable link. Mounting Boxing Pro should be considered close to the wall socket position



USB


2

Operation:



On/off : Long press to Power on and Power off.
: Bluetooth,press On/Off button to power on or power off bluetooth.
Speed : Press it to adjust the speed, displaying H01-H09, Flashing faster accordingly.Default speed level H01
Mode : Press it to adjust mode, displaying P01-P09.Each mode has different speed and difficulty level.

Assembly:



1. Peel off the transparent film behind the black adhesive tape and attach it to the back of the Boxing Pro.(Figure 1)

3