Liddle Speaker® Pro Bluetooth Speaker



HD-M12-Pro User Manual

Thank you for choosing the Liddle Speaker® Pro. developed in collaboration with MiLi design and engineering. We are excited to share the convenience and benefits of our innovative smart lifestyle gadgets with you.

As mobile devices become more integral to daily life, we are committed to adopting the latest technology to enhance your experience.

Remember to register your product by contacting us at connect@LiddleSpeaker.com to activate your warranty!

Please take the time to read the instructions and safety warnings carefully before using the product. Proper use ensures the longevity of the device and helps prevent injury. The manual provides essential guidance for correct and safe operation. Note that product and accessory images are for reference only; actual items may vary.

- 01

Important Safety Information

Please follow these safety instructions to ensure the safe and reliable use of this

- Adhere to all warnings and guidance provided on the product.
- •Use charging equipment that supplies a 5V output voltage to avoid potential
- The product uses a built-in polymer lithium battery. Please power off the device when not in use.

/ Caution

Removing the built-in battery will void the warranty and may damage the product.



Rechargeable batteries have a limited number of charge cycles. Battery life and number of cycles vary by use and settings.

- 02 -

- Never operate when the product is wet, or spill any liquid on the product.
- Never place the product close to high temperature heat source, or dry or blow the product at high temperature.
- Never apply great pressure on the

Product Specification

Product Model: HD-M12-PRO Bluetooth version: 5.3+EDR Input: 5V=0.8A Loudspeaker: 5W Wireless Bluetooth Range: 10m Time of use: 6~8hours(80% volume)

Charging time: 2hours Case material: ABS+PC Capacity: 1100mAh Weight: 98g

- 03 -

What's in the box




USB-C Cable*1








Product Configuration



How to Use This Product



Type-C Microphone Power button / Indicator

Charging the Built-in Battery

The speaker is powered by a built-in rechargeable battery.

Note:

- ·Before using the speaker, charge it using the included USB-C cable. The Pro speaker also supports wireless charging with compatible chargers.
- •When powered on, the device will automatically turn off if the Bluetooth - 05 -

connection is interrupted or disconnected for 5 minutes

Press and hold the power button for 3 seconds to turn the device on or off. indicated by a voice alert. Use the same method to connect or disconnect

- · While music is playing, press the power button once to pause or play.
- · After a successful Bluetooth connection, the speaker's power status will be displayed on your phone's screen.

·How to Enter TWS Mode for Two Speakers

- 1. Power on one speaker and connect it to your phone via Bluetooth.
- 2. Power on the second speaker, then double-click the power button to enter (or exit) TWS mode.

- 06 -

thoroughly before using the product.

Misuse may damage the product and

Note: In TWS mode, your phone only needs to connect to one speaker via

Tips: If you power on both speakers at the same time before properly connecting via Bluetooth, turn off one speaker and follow the steps above to enter TWS mode.

Note: When the battery level drops below 10%, the indicator will flash blue, and the device will automatically shut down, followed by a "power off" voice alert.

Use Bluetooth Devices

The Liddle Speaker® Pro allows you to make voice and video calls, listen to music, and enjoy audio books. Simply connect the Bluetooth speaker to your phone, tablet, or computer,

Note:

•The operational range between this

- 07 -

product and a Bluetooth device is approximately 10 meters (30 feet).

- Any obstacle between this product and a Bluetooth device can reduce the operational range.
- Keep away from any other electronic device that may cause interference.

Connect a device

- •On your device, search for available Bluetooth devices. From the list, select "Liddle Speaker® Pro." The speaker will prompt you with a voice notification once the connection is successfully established.
- Connecting is ok when connection is established.

Disconnecting a Device

- 1. On your device, turn off the Bluetooth connection to this speaker.
- 2. You will hear the voice prompt "Bluetooth Power Off" when the speaker disconnects.

Note: Before connecting a different

- 08 -

Bluetooth device, make sure to disconnect the current one.

Reconnecting a Device

- •For a paired Bluetooth device with automatic re-connection enabled, this speaker will reconnect automatically once detected.
- For devices that do not support automatic re-connection, you will need to reconnect manually.

Playing Audio via Bluetooth

Note: If you receive a call, a notifiction will sound through the speaker. Answer the call on your phone, and when prompted, select whether you'd like to continue the conversation using the Liddle Speaker® Pro or your phone.

Troubleshooting

Note: To keep your warranty valid, do not attempt to repair the product yourself.

If you experience issues while using this

- 09

device, check the following points before requesting service. If these steps don't resolve the problem, you may be eligible for a replacement or repair once the issue (not caused by user error) has been inspected and confirmed.

No power

Recharge vour speaker.

No sound

- Adjust the volume on the speaker.
- Adjust the volume on the connected
- •Ensure your Bluetooth device is within the effective operational range.

No Response from the Speaker

Restart the speaker.

About Bluetooth Device

 Poor Audio Quality After Connection Move the device closer to the speaker or

- 10 -

remove any obstacles between them.

 Unable to Connect to the Device The speaker may be connected to another

Bluetooth device. Disconnect that device, then try connecting again.





Attach speaker to the magnetic Used as a stand charging area on phone or phone case

Newer phones feature built-in magnetic charging capabilities. You can attach the Liddle Speaker directly to the magnetic charging area on the phone or to a phone case that has a magnetic charging circle built into the phone or phone case.

Note: The box includes two metal adhesive rings. Peel off the adhesive backing to attach the Liddle Speaker to surfaces like wood. plastic, glass, or any non-metal surface. The - 11 -

discretion:

speaker will magnetically connect to the metal ring wherever it's placed.

Do Not Attach the adhesive metal ring to your phone or phone case. Do Not apply the adhesive side of the metal

ring to the speaker, as this will interfere with the magnet's functionality. Manufacturer's Product Warranty

1-Year Limited Warranty The manufacturer warranty for product is limited to the terms outlined below: Manufacture warrants its products against defects in materials and workmanship for a period of one year from the original purchase date ("Warranty Period"). To qualify for this one-year warranty, all products must be registered online within 90 days of purchase. If a defect arises and a valid claim is submitted to manufacture within the Warranty Period, manufacturer will, at its

- Repair the product at no cost using new or refurbished replacement parts.
- Replace the product with a new unit.

- 12 -

 The shipping costs for product returns will be shared between manufacturer and the customer. The customer is responsible for the shipping costs to the factory, while manufacturer will cover the return shipping to the customer. For any maintenance or repairs outside the warranty coverage, the customer will be responsible for all shipping fees and any related charges.

Exclusions and Limitations We are excited to bring you the convenience and benefits of Liddle Speaker cutting-edge lifestyle technology. As mobile devices play a larger role in daily life, the Liddle Speaker company is committed to incorporating the latest innovations to enhance your experience. Don't forget to register your product to activate your warranty.

Register your product by contacting us at connect@LiddleSpeaker.com to activate your warranty! Please read the

instructions and safety warnings

- 13 -

cause harm. The manual provides essential information for proper and safe use—please review it carefully. Please note that product and accessory images are for reference only. Actual items may vary.

Contact Us!

If you have any questions or issues with your product, feel free to reach out to our Customer Support team:

Email: connect@LiddleSpeaker.com Website: www.LiddleSpeaker.com

FCC Statement

1.This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two

(1)This device may not cause harmful interference. (2)This device must accept any interference received, including interference that maycause undesired operation. 2.Changes or modifications not expressly

- 14 -

approved by the party responsible forcompliance could void the user's authority to operate the

Note:This equipment has been tested and found to comply with the limits for a class Bdigital device, pursuant to Part 15 of the FCC Rules. These limits are designed to providereasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communica tions However there is no quarantee that interfer ence will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

•Reorient or relocate the receiving antenna. •Increase the separation between the equipment

and receiver ·Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected

 Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RE

exposure requirement. The device can be used in portable exposure condition without restriction.

- 15 -