

Learn about your new
NOISE AIRWAVE MAX 5


PACKAGE CONTENTS



Noise Airwave Max 5 x 1
User manual x 1
Warranty card x 1

Charging cable x 1
Audio cable x 1


PRODUCT OVERVIEW




1 Volume Up/Next Track
2 Multi-function Button
3 ANC Button
4 USB-C Port
5 Ventilation Tuning Hole
6 Volume Down/ Previous Track
7 Bluetooth Indicator
8 Microphone for Noise Cancellation/Call
9 Charging Indicator
10 Microphone for Noise Cancellation

FORCE PAIRING

When power on, short press the  for 3 times to force the headphone into pairing mode. The white bluetooth indicator will flash quickly.



VOLUME BUTTON/POWER BUTTON CONTROLS



| | | | |
|---|---------------------|---|----------------------------|
|  | Short press |  | Play/Pause/Answer/End call |
|  | Short press twice |  | Activate voice assistant |
|  | Press & hold for 1s |  | Reject call |
|  | Short press thrice |  | Enter pairing mode |

WEAR & ADJUST




Adjust the headphone to properly fit your head, and match L/R earcups with your L/R respectively.

PAIRING

After powering on, it will automatically enter pairing mode, and the white indicator on the right headphone will flash quickly. Search for "Noise Airwave Max 5" for a match, and when the connection is successful, the light will turn on for 1 second and off for 1 second.

Note: the headphone will automatically power off if the connection is not complete within 10 minutes.




SPECIFICATIONS

| | |
|--------------------------|---|
| Product Name | Noise Airwave Max 5 |
| Bluetooth Version | 5.4 |
| Frequency Band | 2400MHz-2483.5MHz |
| Max. RF Output Power | 4dBm |
| Transmission Distance | 10m/33ft Max (no blocking) |
| Bluetooth Profile | HFP/A2DP/A2DP/BLE/SPP |
| Codecs | AAC/SBC |
| Frequency Response | 20Hz-40kHz |
| Charging Port | Type-C |
| Battery Type | Polymer lithium-ion battery |
| Battery Capacity | 600mAh 3.7V (2.22Wh) |
| Limited Charging Voltage | 6.2 V |
| Charging Input | 5V 600mA |
| Charging Time | About 1.5 hours |
| Operating Time | About 80 hours (ANC OFF) About 50 hours (ANC ON) |

RESET

Turn it off: Press and hold the  power button for 3 seconds.

Resetting: Press and hold the power button for 10 seconds. The red/white indicator would be on for 3 seconds, indicating the resetting is completed.




CONNECT TO A NEW DEVICE (DUAL CONNECTION)

Turn on your first phone's bluetooth, search for "Noise Airwave Max 5" and make a pair connection.

Note: The headphone can only play music from one device at a time. There may be momentary delay when switching devices due to different brands/versions and their compatibility.


If one of the devices disconnects after dual connections, the headphones will remain connected to the other device and will attempt to reconnect to the disconnected device within 10 minutes.



CHARGING

1.5 hours to fully charge.

Note: low power mode is red light 1 sec on, please charge in time.



POWER ON

Press and hold  for 2 seconds till the white indicator turns on for 1 second.

POWER OFF


Press and hold  for 3 seconds till the red indicator turns on for 1 second.

ANC BUTTON CONTROLS

Short Press: Cycle through "ANC off/ANC on/Ambient"

Press and Hold for 1 second: Switch between music & gaming mode (powering off or charging will restore the headphones to the default music mode).

Adaptive noise reduction mode: In the noise reduction mode, press the ANC button and volume up (+) for 1 second at the same time to enable/disable the adaptive noise reduction mode, and finally return to the default noise reduction mode.



WARRANTY

The warranty covers your Noise product, including accessories, against manufacturing defects (if any) for 1 year from the date of purchase.

REGISTER YOUR WARRANTY

www.gonoise.com/pages/warranty-registration

 SUPPORT AND SERVICE
 1 YEAR LIMITED WARRANTY

 SCAN ME

CUSTOMER QUERY

For any assistance, please reach out to us at support.gonoise.in

SAFETY FOR YOU AND YOUR NOISE AIRWAVE MAX 5

Follow these tips to get the best out of your new Noise Airwave Max 5:

-  Do not expose the headphones to liquids, moisture, or humidity as they have electronics and batteries inside.
-  Avoid dropping the headphones. There are no user-serviceable parts inside it.
-  Avoid dropping the headphones and keeping them away from sharp objects such as keys in your pockets.
-  Only charge your headphones from 5V/1A ports such as phones and laptops or PC chargers.
-  Avoid listening to music at a high volume or you may permanently damage your hearing.

正面

反面