

# USER MANUAL

Press and Hold [VOL-] key and [  ] key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.



## Pairing New Remote method:

1. Press [Power] Key to turn on the [TV]
2. Press and Hold [VOL-] key and [  ] key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.

## Connected new remote with a Paired Remote:

1. Press the [Home] key, then select [Setting – Remotes & accessories]
2. Select [Add accessory], then Press [OK] key to confirm to pair.
3. Press and Hold [VOL-] key and [  ] key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.

## Trouble shooting: Remote do not work

- (1) Remember to change brand new alkaline AAA battery
- (2) Replace the battery, need to pay attention to the battery polarities (+/-). Indicated on the remote battery area.
- (3) If still not work, please Turn off and Turn on your TV, remove and install back the battery of remote firstly, and then Re-pair again follow the above Pairing method.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.