

使用说明书

幻彩LED无线音响



LED



BT 5.4



Live




K song



TF



TWS




产品基本信息：

- ★产品型号：BW905
- ★输出功率：15W (Max)
- ★充电功率：TYPE-C 5V 1A
- ★蓝牙：距离20米 版本5.4
- ★连接方式：无线/TF卡/AUX/FM
- ★频率范围：50Hz-18KHz
- ★执行标准：GB-T9254.1-2021
- ★电池容量：锂电池（参考产品底部）
- ★灯光模式：RGB LED幻彩变化


常见问题处理：

- 1：无法开机：请检查电量是否足够，接入电源查看充电指示灯是否亮起。
- 2：无法充电：低电量的情况长期超过6个月不充电可能会损坏电池或无法逆转降低电池性能，请尽量将电池充满后长期保存。
- 3：无线无法连接：请检查M键是否切换正确模式，连接设备距离是否在合理范围内。
- 4：噪音过大：请检查近距离是否存在其它设备信号干扰。


功能介绍：



- 1：轻按一下切换上一曲/长按减少音量。
- 2：切换音频输入模式：无线/ FM收音机模式/TF卡模式/AUX模式。（注意：长按2秒激活TWS实现两台音响在无线模式下对联播放）
- 3：长按两秒开机和关机/短按一下暂停和播放音乐。
- 4：长按两秒关闭灯光/短按一下切换RGB LED灯光变化。
- 5：轻按一下切换下一曲/长按增大音量。



- 1：插入TF内存卡后可以自动识别歌曲MP3格式，并播放音乐。
- 2：使用音频线AUX接入后播放音乐。
- 3：Type-c 充电接口，接受输入最大功率电压5V 1A，充电过程中指示灯会常亮，充满之后指示灯熄灭。（注意：充电器电压支持5V，电流1A~10A都可以使用）。



温馨提示！
音响底部低音震动膜
请勿长期大力按压避免损坏



User Manual

Mini Karaoke Speaker



LED



BT 5.4



Live




K song



TF



TWS




Features

- ★Model:BW905(Wireless Name)
- ★Charging power:TYPE-C 5V 1A
- ★Battery :Lithium battery (refer to the bottom of the speaker)
- ★Input audio:Bluetooth/TF/AUX/FM
- ★Frequency:90Hz-18KHz
- ★Output power:15W(Max)
- ★Wireless:20 meters, version 5.4
- ★Lighting Mode: RGB LED color change


Questions and Answer:

- ★Q:Unable to turn on?
A:Please check the battery, and check if the charging indicator is on when charging.
- ★Q:Wireless to connect?
A:Please check whether the M button is in the proper mode and confirm the device range(less than 20 meters).
- ★Q:Noise?
A: Check whether there is signal interference from other devices in the near distance.


How to use:



- ★①:Tap to change to last track, and long press it to turn down the volume.
- ★②: Audio input mode: Wireless /FM radio /TF card /AUX. (Note: Press and hold for 2 seconds to activate TWS)
- ★③: Long press to turn on and off the speaker, and short press to pause and play.
- ★④: Long press to turn off the RGB light, and short press to change the light.
- ★⑤: Tap to change to next track, and long press to turn up the volume.



- ★①: TF Card Input: automatically recognize Mp3 format and play if you insert a TF card.
- ★②: Aux Output: use AUX cable to play music.
- ★③: Power Input: type-c charging, accept input maximum power voltage 5V 1A. charging indicator lights on when charging and goes off when full charged.
- ★(Note: voltage support 5V, current 1A~10A)



- ★**Special reminder:**
- ★The bass vibration film at the bottom of the stereo should not be pressed too hard for a long time to avoid damage.
- ★Low power conditions for longer than 6 months without charging may damage the battery. Please try to keep the battery full if not used for a long time.



ユーザーマニュアル

RGB LED 無線 スピーカー



LED



BT 5.4



Live




K song



TF



TWS




特徴

- ★モデル：BW905（無線）
- ★出力電力：15W（最大）
- ★充電電力：Type-C 5V 1A
- ★無線：20メートルバージョン5.4
- ★バッテリー：リチウムバッテリー（スピーカーの底を参照）
- ★入力オーディオ：無線/TF/AUX/FM
- ★照明モード：RGB LED色の変更
- ★周波数：90Hz-18kHz


質問と答え：

- ★Q：電源を入れることができませんか？
A：バッテリーをチェックして、充電時に充電インジケータがオンかどうかを確認してください。
- ★充電できない：充電なしで6か月以上の充電条件が低い条件は、バッテリーに損傷を与えるか、不可逆的に減少する可能性があります
- ★Q：無線接続できませんか？
A：Mボタンが適切なモードであるかどうかを確認し、デバイスの範囲（10メートル未満）を確認してください。
- ★Q：ノイズ？
A：他のデバイスからの信号干渉が距離にあるかどうかを確認します。


使い方：



- ★①：タップして最後のトラックに変更し、それを長く押してボリュームを下げます。
- ★②：オーディオ入力モード：無線/FM Radio /TF Card /Aux。（注：TWSをアクティブにするために2秒間押し続ける）
- ★③：スピーカーをオンとオフにするためにロングプレス押し、短いプレスして一時停止してプレイします。
- ★④：RGBライトをオフにするためにロングプレス押し、短いプレスして光を変更します。
- ★⑤：タップして次のトラックに変更し、ボリュームを上げるためにロングプレスを押します。



- ★①：TFカード入力：TFカードを挿入した場合、MP3形式を自動的に認識し、再生します。
- ★②：aux出力：auxケーブルを使用して音楽を再生します。
- ★③：電源入力：Type-C充電、入力を受け入れる最大電力電圧5V 1a、充電インジケータライトは充電時に点灯し
- ★（注：充電器電圧は5Vをサポートし、電流は1A〜10Aで使用できます）。



- ★**特別なリマインダー**
- ★ステレオの下部にある低音振動フィルムは、ダメージを避けるために長い間強く押されてはなりません。
- ★充電なしで6か月以上の低電力条件は、バッテリーに損傷を与える可能性があります。長い間使用しない場合は



사용자 매뉴얼

미니 가라오케 스피커



LED



BT 5.4



Live




K song



TF



TWS




특징

- ★ 모델：BW905（무선 이름）
- ★ 출력 전원：15W（최대）
- ★ 충전 전력：Type-C 5V 1A
- ★ 무선：20 미터, 버전 5.4
- ★ 배터리：리튬 배터리（스피커 하단 참조）
- ★ 입력 오디오：무선 /TF/AUX/FM
- ★ 조명 모드：RGB LED 색상 변경
- ★ 주파수：90Hz-18kHz


문제 해결

- ★ Q：켜질 수 있습니까?
A：배터리를 확인하고 충전 시점이 켜져 있는지 확인하십시오.
- ★ 충전 할 수 없음：충전없이 6 개월 이상 낮은 충전 조건은 배터리가 손상되거나 돌이킬 수 없을 정도로 감소 할 수 있습니다.
- ★ Q：무선 가 연결할 수 있습니까?
A：M 버튼이 적절한 모드인지 확인하고 장치 범위（20 미터 미만）를 확인하십시오.
- ★ Q：소음?
A：가까운 거리에 다른 장치의 신호 간섭이 있는지 확인하십시오.


사용하는 방법：



- ★ ①：마지막 트랙으로 변경하려면 탭하고 Long 을 눌러 볼륨을 낮추십시오.
- ★ ②：오디오 입력 모드：무선 /FM Radio /TF Card /Aux.（참고：2 초 동안 누르고 고정하여 TWS를 활성화하십시오）
- ★ ③：스피커를 켜고 끄는 긴 눌러 잠시 멈추고 일시 중지하고 재생합니다.
- ★ ④：긴 눌러 RGB 라이트를 끄고 짧은 눌러 빛을 바꾸십시오.
- ★ ⑤：다음 트랙으로 변경하려면 탭하고 Long Press를 눌러 볼륨을 높이십시오.



- ★ ①：TF 카드 입력：MP3 형식을 자동으로 인식하고 TF 카드를 삽입하면 재생합니다.
- ★ ②：Aux 출력：Aux 케이블을 사용하여 음악을 재생하십시오.
- ★ ③：전력 입력：유형 C 충전, 입력 수용 최대전력 전압 5V 1A, 충전시 표시 조명을 충전하고 충전 할 때 꺼집니다.
- ★（참고：전압 지원 5V, 현재 1A ~ 10A）



- ★ **특별 알림**
- ★ 스테레오 바닥에있는베이스 진동 필름은 손상을 피하기 위해 오랫동안 너무 세게 눌러서는 안됩니다.
- ★ 충전없이 6 개월 이상 저전력 조건은 배터리가 손상 될 수 있습니다. 오랫동안 사용하지 않으면 배터리를 가득 채우십시오.



FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.