


ANC 说明书：128克铜版，双面单色，折页，

单页尺寸：65X86MM, 展开尺寸：455X86MM

正



ACTIVE NOISE CANCELLING PREMIUM HEADPHONES

USER MANUAL

SPECIFICATIONS

Bluetooth	V5.4	Battery	5000 mAh
Operating Distance	> 10M	Battery Type	Li-Polymer
Driver Unit	40mm	Play Time	12 Hours
Impedance	32Ω	Input	5V 1A Type-C USB
Sensitivity	100dB	Frequency	20-20000 Hz

CONTENTS: 1 x Headphone, 1 x AUX Audio Cable, 1 x USB Charging Cable, 1 x Manual

CHARGING YOUR HEADPHONES

1. Use the charging cable provided and plug into the port on the Left earcup.
2. Plug the other end into any USB charging port.
3. LED indicator near the USB input will turn red while charging. Once charging is fully complete, LED will turn off.

NOTE: To prevent damage, it is recommended to use the charging cable that is provided.

POWERING ON & OFF

Press and hold the power button for 3 seconds to turn on or off.

BLUETOOTH PAIRING WITH YOUR DEVICE

1. Fully charge your headphones then press and hold the power button until the LED lights flash blue. ANC-BTHP will automatically enter pairing mode.
2. Pairing mode will last for 2 minutes.
3. While in pairing mode, turn ON the Bluetooth Connection on your device, Scan/Search & select "ANC-BTHP".
4. Once paired, ANC-BTHP will voice prompt 'CONNECTED successfully'.

NOTE: Power on ANC-BTHP and it will automatically connect to the last connected device if available within BT range.

EARBUD FUNCTION GUIDE



1. Multi-Function Button
2. Volume Up Button
3. Volume Down Button
4. ANC (Active Noise Cancelling) Button
5. Aux Port - Plug the provided cable for wired connection
6. Charging Port
7. Mic

MUSIC FUNCTIONS

	Press Once to Play/Pause
-	Press & Hold for 2 Seconds to Lower Volume
+	Press Once for Previous Track
	Press & Hold for 2 Seconds to Raise Volume
	Press Once for Next Track

POWER FUNCTION

	Press & Hold for 3 Seconds to Turn ON or OFF
--	--

CALLING FUNCTIONS

	Press Once to Answer Call
	Press & Hold for 3 Seconds to Reject Call
	Press Twice to Redial

ANC BUTTON

	Press Once to Change MODE from Transparent mode, ANC mode
--	---

TECHNICAL SUPPORT & WARRANTY INFO

This product is backed by a One Year Warranty from any defects. For warranty replacements, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com.

SimplyTech Electronics Inc declared that radio equipment is compliant with Directives 2014/53/EU, 2011/65/EU & 2012/19/EU. EU Declaration of Conformity for this product can be viewed at www.SimplyTechCorp.com/docs.

DISTRIBUTED BY: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018

MADE IN CHINA

Please read before using this product and retain manual for future reference.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirements.

The device can be used in portable exposure condition without restriction.

背



ACTIVE NOISE CANCELLING PREMIUM HEADPHONES

BEDIENUNGSANLEITUNG DUR ARTIKELNUMMER

SPECIFICATIONS

Bluetooth	V5.4	Battery	5000 mAh
Operating Distance	> 10M	Battery Type	Li-Polymer
Driver Unit	40mm	Play Time	12 Hours
Impedance	32Ω	Input	5V 1A Type-C USB
Sensitivity	100dB	Frequency	20-20000 Hz

INHALT: 1 x Kopfhörer, 1 x AUX-Audio Kabel, 1 x USB-Ladekabel, 1 x Handbuch

ANLEITUNG - SICHERHEITSVORSCHRIFTEN

Setzen Sie Teile dieses Produkts KEINEN Flüssigkeiten, Feuchtigkeit, scharfen Gegenständen oder extremen Temperaturen aus, da dies zu Schäden und zum Erlöschen der Garantie führen kann. Versuchen Sie NICHT, die Ohrhörer oder das Ladeetui zu zerlegen oder in irgendeiner Weise zu modifizieren. NUR punktuelle Reinigung. Außerhalb der Reichweite von Kindern aufzubewahren. Dieses Produkt ist kein Spielzeug.

BLUETOOTH-PAIRING MIT IHREM GERÄT


1. Laden Sie Ihre Kopfhörer vollständig auf und drücken Sie dann und halten Sie den Netzschalter gedrückt, bis die LED aufleuchtet. Die LED blinkt blau. ANC-BTHP wird automatisch in den Pairing-Modus wechseln.
2. Stecken Sie das andere Ende in einen beliebigen USB-Anschluss auf der Ladestation.
3. LED-Anzeige neben dem USB-Eingang leuchtet während des Ladevorgangs rot. Sobald der Ladevorgang abgeschlossen ist, ist die LED abgeschlossen, was bedeutet, dass die LED erlischt.

HINWEIS: Um Schäden vorzubeugen, ist es empfohlen, das Ladekabel zu verwenden.

EIN- und AUSSCHALTEN

Halten Sie die Ein-/Aus-Taste 3 Sekunden lang gedrückt, um die Ohrhörer einzuschalten oder auszuschalten.

FUNKTIONSANLEITUNG FÜR OHRHÖRER



1. Multifunktionstaste
2. Lauter-Taste
3. Leiser-Taste
4. ANC-Taste (Active Noise Cancelling)
5. Aux-Anschluss - Schließen Sie das mitgelieferte Kabel an Kabelverbindung
6. Ladeanschluss
7. Mikrofon

MUSIK FUNKTIONEN

	Drücken Sie die Taste einmal abspielen/Halt
-	Halten und drücken Sie die Taste für 2 Sekunden lang zu Vol-/Lautstarker reduzieren. Drücken Sie einmal vorher Lied
+	Halten und drücken Sie die Taste für 2 Sekunden lang Vol-/Lautstarker erhöhen. Drücken Sie einmal nach Lied

POWER-FUNKTIONEN

	Halten und drücken Sie die Taste für 3 Sekunden zu einem oder ausschalten
--	---

ANRUF-FUNKTIONEN

	Drücken Sie einmal zu Anruf annehmen
	Halten und drücken Sie die Taste für 2 Sekunden zu Anruf ablehnen
	Drücken Sie zweimal zu Wählwiederholung

ANC BUTTON

	Drücken Sie einmal, um den MODUS zu ändern. Transparenter Modus, ANC-Modus
--	--

TECHNISCHE HILFE & GARANTIEINFORMATIONEN

Für dieses Produkt gilt eine einjährige Garantie auf jegliche Mängel. Für Garantieleistungen, Fragen oder wenn Sie Probleme mit diesem Produkt haben, kontaktieren Sie uns unter help@SimplyTechCorp.com.

SimplyTech Electronics Inc. erklärt, dass das Funkgerät mit den Richtlinien 2011/65/EU, 2014/53/EU & 2012/19/EU konform ist.

Die EU-Konformitätserklärung für dieses Produkt kann unter www.SimplyTechCorp.com/docs eingesehen werden.

VERTRIEBEN VON: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018

HERGESTELLT IN CHINA

Bitte lesen Sie das Handbuch vor der Verwendung dieses Produkts und bewahren Sie es zum späteren Nachschlagen auf.