

背面

585*86mm

128g铜板，双面印黑色，W折



TECHNISCHE DATEN		LADUNG	
Material	Aluminium 5.3	Drucke/View	LED-ANZEIGE
Abmessungen	58,5 x 86 mm	Abmessungen des Ladegehäuses	27 x 40 x 19 mm
Trichteröffnung	10 mm	Drucke/View	40 mAh
Widerstand	32 Ω	Widerstand des Ladegehäuses	300 Ω
Widerstand des Ladegehäuses	300 Ω	Widerstand des Ladegehäuses	6 V (LITHIUM)
Widerstand des Ladegehäuses	300 Ω	Widerstand des Ladegehäuses	6 V (LITHIUM)

SICHERHEITSVORSCHRIFTEN

Produkt nicht modifizieren, reparieren oder auseinandernehmen, da dies zu Brand, Elektroschock, vollständigem Versagen des Produkts usw. führen kann und die Garantie ungültig macht. Auf Kanten, Unebenheiten, Metallteil, Zubehör und deren Verpackung achten, um mögliche Verletzungen oder Schaden zu vermeiden.

Vorsichtig: Elektroschockgefahr. Nur in trockenen Bereichen verwenden!


EINSCHALTEN DIE REVEL EARBUDS

- Legen Sie jeden Ohrhörer in seinen Ladeschlitz und schließen Sie die Abdeckung.
 - Verwenden Sie das mitgelieferte Ladekabel und schließen Sie das andere Ende an einen beliebigen USB-Ladeanschluss an.
- ** Um Schäden zu vermeiden, wird empfohlen, das mitgelieferte Ladekabel zu verwenden.

Laden Sie das Ladegehäuse und die Ohrhörer mindestens 4,5 Stunden vor dem ersten Gebrauch vollständig auf.

ON/OFF

- Entfernen Sie die Kopfhörer aus dem Gehäuse, sie werden automatisch eingeschaltet.
- Setzen Sie die Kopfhörer wieder in den Ladekoffer, die Kopfhörer schalten sich automatisch aus.
- Um manuell einzuschalten, halten Sie die Taste auf einem der Kopfhörer für 4-5 Sekunden gedrückt, bis die LED-Anzeige ROT blinkt.
- Um manuell auszuschalten, halten Sie die Taste an einem der Ohrhörer 4-5 Sekunden lang gedrückt, bis sich die LED-Anzeige ausschaltet.



KOPPLUNG MIT EINEM MOBILTELEFON

- Öffnen Sie die Ladetasche, entfernen Sie die Ohrhörer und sie werden automatisch einschalten und paaren sich. Stimme wird "CONNECTED" anfordern. Der rechte Ohrhörer wird automatisch mit dem linken Ohrhörer verbunden.
- Der Kopplungsmodus dauert 2 Minuten. Schalten Sie im Kopplungsmodus die Bluetooth-Verbindung auf Ihrem Gerät ein, scannen/suchen & wählen REVEL aus.
- Sobald REVEL gekoppelt ist, wird die Sprachansage "CONNECTED" ansprechacht.

Ein Earbud-Modus: Wenn Bluetooth verbunden ist, können Sie entweder Earbud der Ohrhörer verwenden, indem Sie den anderen wieder in das Ladegehäuse stecken und die Abdeckung schließen.

TAP-TOUCH STEUERUNG



TECHNISCHE HILFE & GARANTIENINFORMATIONEN

Für dieses Produkt gilt eine einjährige Garantie auf Mängel. Für Garantieaustausch Fragen oder Problem mit diesem Produkt wenden Sie sich an help@simplytechcorp.com. GARANTIE 1 JAHR. Hergestellt in China. SimplyTech erklärt, dass Funkt great der EU-Richtlinie 2014/53/EU & 2011/65/EU entspricht. Das Produkt der EU-Konformitätserklärung kann unter eingesehen werden www.SimplyTechCorp.com/docs. VERTRIEB DURCH: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018. Lesen Sie bitte diese Bedienungsanleitung vor Inbetriebnahme dieser Produkte.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

正面



SPECIFICATIONS		CHARGING TIME	
Material	Aluminum 5.3	Charging Case	1 hour
Dimensions	58.5 x 86 mm	Charging Case	1 hour
Trichteröffnung	10 mm	Charging Case	40 mAh
Widerstand	32 Ω	Charging Case	100 Ω
Widerstand des Ladegehäuses	300 Ω	Charging Case	6 V (LITHIUM)
Widerstand des Ladegehäuses	300 Ω	Charging Case	6 V (LITHIUM)

SAFETY & CARE INSTRUCTIONS

Do NOT expose any portion of this product to liquid, humidity, moisture, sharp objects or extreme temperatures as this can damage it and void the warranty. Do NOT attempt to disassemble or modify the Earbuds or Charging Case in any way. Spot Clean ONLY. The earbuds are sweat and water-resistant but should not be submerged into water as it will damage them.

Keep out of reach of children. This product is not a toy.



CHARGING YOUR REVEL EARBUDS

- Place each earbud into its charging slot and close the cover.
 - Use the charging cable provided and plug the other end into any USB charging port.
- **To prevent damage, it is recommended to use the charging cable that is provided. Fully charge the charging case and earbuds for a minimum of 3 hours before first use.

POWERING ON & OFF

- Take the earbuds out from the case, they will automatically power on.
- Place the earbuds back into the charging case, the earbuds will automatically power off.
- To manually power on, press and hold the TOP on either one of earbuds for 4-5 seconds until the LED indicator flashes blue.
- To manually power off, press and hold button on either one of earbuds for 4-5 seconds until the LED indicator turns off.


BLUETOOTH PAIRING WITH YOUR DEVICE

- Open the charging case, remove the earbuds & they will automatically power on and pair to each other, voice will prompt 'CONNECTED'. The right earbud will automatically connect to the left earbud.
- Pairing mode will last for 2 minutes. While in pairing mode, turn ON the Bluetooth Connection on your device, Scan/Search & select "REVEL".
- Once paired, REVEL will voice prompt 'CONNECTED'.

Single Earbud Mode: When Bluetooth connected, you can use either Earbud of the earbuds only by putting the other one back into the charging case and closing the cover. **NOTE:** Power on REVEL and they will automatically connect to the last connected device if available within the Bluetooth range.

EARBUD TAP-TOUCH FUNCTION GUIDE

NOTE: REVEL has a sensitive tap-touch feature. There is a multi-function touch button on each earbud.



CONTENTS: 2 x Earbuds, 1 x Charging Case, 1 x Type C Charging Cable, 1 x Manual

TECHNICAL SUPPORT & WARRANTY INFO

This product is backed by a One Year Warranty from any defects. For warranty replacements, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com. SimplyTech Electronics Inc declared that radio equipment is compliant with Directives 2014/53/EU & 2011/65/EU. EU Declaration of Conformity for this product can be viewed at www.SimplyTech-Corp.com/docs. DISTRIBUTED BY: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018. MADE IN CHINA. Please read before using this product and retain manual for future reference.