



SAFETY & CARE INSTRUCTIONS

Do NOT expose any portion of this product to liquid, humidity, moisture, sharp objects or extreme temperatures as this can damage the product and void the warranty.

Do NOT attempt to modify or disassemble in any way. Spot Clean ONLY.

Only power with the provided cable.

CONTENTS:

Multifunction Speaker, Charging cable, User manual

SPECIFICATIONS:

Bluetooth Version: 5.3
Output Power: 2 x 5W
Speaker Unit: 70mm
Battery Capacity: 1,200mAh
Music Play Time: 5-6 hours at 30% volume
Charging Time: 3-4 Hours
Wireless Range: 33ft/10m
Waterproof Rating: IPX4
Speaker Functions: Bluetooth, FM Radio, MicroSD Slot, True Wireless Connectivity
Frequency Range: 20Hz-20KHz
Frequency Response: 80Hz-15KHz
FM Radio Frequency: 87.5-108MHz
Type C Cable Included: Rechargeable
Material: ABS + Fabric
Product Size: 330 x 133 x 173mm

HOW TO USE SPEAKER: CHARGING & POWERING ON:

- Use the included USB cable to fully charge the speaker for a minimum of 4 hours before first use. When charging, the LED indicator light will be on. Once fully charged, the LED indicator will turn off.
- Press and hold the ON/OFF button for 3 seconds to turn the speaker on or off.

BLUETOOTH PAIRING WITH YOUR DEVICE

- Once powered on, the speaker will automatically go into PAIRING MODE.
- Pairing mode will last for 5 minutes. While in pairing mode, turn on the Bluetooth connection on your device, Scan/Search & select 'CRUISIN XL SPEAKER'.
- Once paired, successfully speaker will voice prompt 'CONNECTED'.

TRUE WIRELESS MODE

CONNECTING TWO CRUISIN' XL SPEAKERS

- Turn both speakers on at the same time and keep in default Bluetooth Mode.
- Press and hold the LED lights button on ONE of the speakers to enter True Wireless Mode.

3. The speakers will then voice-prompt that they have been connected to each other and will sync the audio being played.

HANDS-FREE FUNCTION

NOTE: When in Bluetooth mode, the music will automatically pause when there is an incoming call. Once the call has ended, the music will resume automatically.

FM RADIO MODE

Charging cable must be connected to the charging port of the Speaker during use, Press Once the "M" Mode button to switch to the Radio Mode. Once Radio mode is selected, Press & Hold for 2 Seconds "Pause" button to scan available FM radio stations (please allow 1-2 minutes for the initial scan to be completed, the scan is complete once it remains on one radio station), and then use the "+" and "-" buttons to scroll through the available FM radio stations.

ANSWER CALL
Press Once

END CALL
Press Once

REDIAL LAST CALL
Press Twice

REJECT CALL
Press & Hold for 2 seconds

PREVIOUS SONG
Press & Hold for 2 seconds

NEXT SONG
Press & Hold for 2 seconds

PLAY/PAUSE
Press Once

M MODE
Press Once

POWER ON/OFF
Press & Hold for 3 seconds

FM MODE
Press & Hold for 2 seconds

LED LIGHTS
Press Once

VOLUME DOWN
Press Once

VOLUME UP
Press Once

FCC ID: 2BKTL-XLCRU01

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. **Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.

can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

TECHNICAL SUPPORT & WARRANTY INFO

This product is backed by a One Year Warranty from any defects. For warranty replacement, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com. SimplyTech Electronics Inc. declared that radio equipment is compliant with Directives 2014/5/EU, 2016/5/EU & 2012/19/EU. EU Declaration of Conformity for this product can be viewed at www.SimplyTechCorp.com/docs. DISTRIBUTED BY SimplyTech Electronics, Inc. 147 Broadway New York, NY 10118 MADE IN CHINA. Please read before using this product and retain manual for future reference.

1. Schalten Sie beide Lautsprecher gleichzeitig ein Zeit und bleiben Sie im Standard-Bluetooth-Modus.

2. Drücken und halten Sie die Taste „LED-LEUCHTEN“. Einer der Redner zum Eintreten Echter Wireless-Modus.

3. Die Lautsprecher geben dann eine Sprachansage aus dass sie miteinander verbunden warenanander und synchronisiert den abgespielten Ton.

FREISPRECHFUNKTION

HINWEIS: Im Bluetooth-Modus läuft die Musik automatisch pausieren, wenn es eine gibt eingehender Anruf. Sobald der Anruf beendet ist, erhöht die Musik automatisch fortfahren.

FM-RADIO-MODUS

Das Ladekabel muss während des Gebrauchs an den Ladeanschluss des Lautsprechers angeschlossen sein. Drücken Sie einmal die Taste „M“, um in den Radiomodus zu wechseln. Sobald der Radiomodus ausgewählt ist, halten Sie die Taste „Pause“ 2 Sekunden lang gedrückt, um die verfügbaren FM-Radiosender zu scannen (bitte warten Sie 1-2 Minuten, bis der anfängliche Suchlauf abgeschlossen ist; der Suchlauf ist abgeschlossen, sobald er auf einem Radiosender verbleibt), und verwenden Sie dann die Tasten „+“ und „-“, um durch die verfügbaren FM-Radiosender zu blättern.

FCC ID: 2BKTL-XLCRU01

FCC-ERKLÄRUNG :

Dieses Gerät erfüllt die Anforderungen von Teil 15 der FCC-Vorschriften. Der Betrieb unterliegt den folgenden zwei Bedingungen:

- Dieses Gerät darf keine schädlichen Interferenzen verursachen, und
- Dieses Gerät muss alle empfangenen Interferenzen akzeptieren, einschließlich Interferenzen, die einen unerwünschten Betrieb verursachen können.

Warnung: Änderungen oder Modifikationen, die nicht ausdrücklich von der für die Konformität verantwortlichen Partei genehmigt wurden, können dazu führen, dass der Benutzer die Berechtigung zum Betrieb des Geräts verliert.

HINWEIS: Dieses Gerät wurde getestet und entspricht den Grenzwerten für ein digitales Gerät der Klasse B gemäß Teil 15 der FCC-Vorschriften. Diese Grenzwerte sind so ausgelegt, dass sie einen angemessenen Schutz gegen schädliche Störungen bei der Installation in Wohngebieten bieten. Dieses Gerät erzeugt und verwendet Hochfrequenzenergie und kann diese ausstrahlen.

RF-Warnhinweis:

Das Gerät wurde so bewertet, dass es die allgemeinen RF-Expositionsforderungen erfüllt. Das Gerät kann unter tragbaren Expositionsbedingungen ohne Einschränkungen verwendet werden.

Für dieses Produkt gilt eine einjährige Garantie auf jegliche Mängel. Für Garantieleistungen, Fragen oder wenn Sie Probleme mit diesem Produkt haben, kontaktieren Sie uns unter help@SimplyTechCorp.com. SimplyTech Electronics Inc. erklärt, dass das Funkgerät mit den Richtlinien 2011/6/EU, 2014/5/EU & 2012/19/EU konform ist. Die EU-Konformitätserklärung für dieses Produkt kann unter www.SimplyTechCorp.com/docs eingesehen werden.

VERTRIEBEN VON: SimplyTech Electronics, Inc. 147 Broadway New York, NY 10118

HERGESTELLT IN CHINA:

Bitte lesen Sie das Handbuch vor der Verwendung dieses Produkts und bewahren Sie es zum späteren Nachschlagen auf.