

Warranty terms

DEEPSIRE warrants this product for a period of ONE (1)YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify DEEPSIRE during the warranty period, DEEPSIRE will, at its discretion, replace the product free of charge.

If you have any feedback or need any additional assistance, use the contact form at www.deepsire.com/contact. Someone from the DeepSire team will normally reply within 12-24 hours.




Download the App



www.deepsire.com

•FUNX



Ai Interactive Vibrator
LACE
USER MANUAL

What's included

- LACE
- Charging Cable
- Manual
- Fabric Pouch

Warning

Please comply with the following before using the product:

Never use the vibrator while charging. A full charge is needed before your first use. Clean the vibrator with warm water before and after use. Avoid overheated. Recharge at least once every six months.

Compliance with FCC Regulations:


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No contact with fire

Button Display



Charging

- 1 .Turn off Lace
- 2 . connect the charging port with the magnetic charging cable, only use a USB charger with an output of 5v and 1A.
- 3 . Indicator light breathes while charging. The battery requires approximately 2 hours for a full charge.

Frequency band: 2402-2480MHz Emitted power:<3.59mW Bluetooth Version:V5.0