

User's Manual

AS19

Digital Media Player

Preface


Thank you for purchasing and using our company's products. In order to allow you to operate this machine as quickly and easily as possible, please read this manual carefully before you start using it.

This unit is a stylishly designed portable wireless Bluetooth speaker. This machine supports Bluetooth protocol, supports smart phones, tablet computers, notebooks and other devices with Bluetooth audio function, which allows you to completely get rid of the shackles of cable, and enjoy the fun of music freely. It also supports TF card, U disk and mobile phones without Bluetooth function., Laptop, MP3, MP4 and other equipment audio input playback.

Precautions

Do not hit the main unit severely.

- ◆ Do not contact with chemicals such as benzene, thinner, etc.
- ◆ Please do not use it near strong magnetic field or electric field, >Avoid direct light or heating appliances.
- ◆ Do not disassemble, repair, or modify by yourself.
- ◆ Do not use the player when riding a bicycle, driving a car or a motorcycle to avoid danger.
- ◆ Do not listen at a high volume for a long time to avoid adverse effects on hearing.
- ◆ Do not clean the machine with clean water, please clean the surface of the machine with a slightly moistened cloth.
- ◆ Low-voltage use may cause sound distortion, so please charge it in time, and disconnect the power supply when not in use for a long time.
- ◆ Bluetooth function is compatible with common smart phones, tablet computers, etc., but some functions may not be supported depending on the device or application you are using.



Bluetooth mode

1. Long press the switch to turn on Xiner, after turning on the speaker, the speaker will emit a boot tone, the blue light of the Bluetooth indicator will flash quickly, enter the Bluetooth mode, and the speaker will emit a Bluetooth connection tone.
2. The blue light flashes quickly and enters the pairing state. At this time, open the Bluetooth device and search for the "AS19" device name to confirm the connection. If a password is required, enter (0000). After the connection is successful, the blue light is always on and the speaker emits a beep. The blue light flashes slowly during music playback. The paired Bluetooth device first turns on the Bluetooth, and then turns on the speaker to automatically connect back.

3. Support Bluetooth hands-free call function. You can answer the phone while listening to music via Bluetooth, continue to play the music after you hang up the phone, short press the pause/radio button to answer/end the call, long press to reject the call, double click to redial the previous call, when a call is in progress, short press to answer/end the call, long press to redial the last number to redial.

TF card/U disk mode

1. Insert a TF card or U disk under bluetooth mode to automatically enter TF card or U disk 1 to play. If a TF card or U disk is inserted into the speaker, it will directly enter TF card or U disk playback mode after power on.
2. During playback, the blue indicator light flashes slowly, and the pause blue light is always on.

"Line in" mode

1. In the power-on state, insert the "line in" line and enter the "line in" mode automatically.
2. In "line in" mode, the blue indicator light flashes slowly.

"FM" mode

1. Long press the "I/M" key to enter the "FM" radio mode.
2. Manual search with knob

Charge

1. Insert the USB cable into the speaker and connect to a 5V charger or computer to charge the speaker's built-in battery.

2. The "charging" indicator light is red when charging, and the red light is off when it is fully charged.

The default boot volume in all modes of this machine is 60% of the total volume. When the battery voltage is lower than 3.2V, the speaker will automatically detect and emit a low battery warning tone. When the battery voltage is lower than 3.0V, the speaker will emit a tone and automatically shut down.

List of key functions

No 序号	Button Name	Mode				
		Bluetooth	TF card /U disk	Line in	FM radio	Answer the Phone
1	I/M	Long press mode switch/ short press to play/pause	Long press mode switch/ short press to play/pause	Long press mode switch/ short press to mute	Long press mode switch/ short press to adjust	When a call is in progress, short press to answer/end the call, long press to reject the call, double click to redial the previous call.
2	◀/▶	Short press previous song (Long press volume down)	Short press the previous song	/	/	/
3	▶/+	Short press Long press Volume up	Short press	/	/	/
4	○	Long press to power on /off	Long press to power on /off	Long press to power on /off	Long press to power on /off	/

Technical specifications

1. Bluetooth version: version 5.0
2. Output: Bluetooth TF U disk AUX output
3. Charging source interface: USB interface
4. Speaker power: 3Q*5W
5. Rated power: 5W*1
6. Frequency response: 1 50Hz-20KHz

7. Noise ratio: 80dB
8. Bluetooth output distance: 8-10 m (without obstacles)
9. Power input: DC 5V 1500MA



Part Name	Toxic and harmful substances or elements					
	Pb	Hg	Cd	Cr (VI)	PbB	PbDE
Circuit board	X	○	○	○	○	○
Battery	X	○	○	○	○	○
Cass	○	○	○	○	○	○

○: It means that the content of this toxic and hazardous substance in all homogeneous materials of this part is below the limit requirement of SJ/T 11363-2006.


X: Indicates that the content of the toxic and hazardous substance in at least one homogeneous material of this part exceeds the limit requirement of SJ/T 11363-2006, the parts marked with "X" in the above table cannot be replaced due to technical reasons. Gradually improve.

前言

感谢您购买并使用本公司的产品，为了能让您尽快轻松自如地操作本机，在您开始使用之前请仔细阅读本手册。
本机是一款设计时尚的便携式无线蓝牙音响。本机支持蓝牙协议，支持智能手机、平板电脑、笔记本等带蓝牙音频功能的设备，可让您彻底摆脱有线束缚，无拘无束享受音乐乐趣，同时也支持TF卡、U盘及不带蓝牙功能的手机、笔记本电脑、MP3、MP4等设备的音频输入播放。

注意事项

- 切勿严重撞击主机。
- 切勿接触苯、稀释剂等化学药品。
- 请不要靠近强磁场、电场下使用。
- >请避开直射光线或发热器具。
- 切勿自行拆卸、修理、改造。
- 骑车、驾驶汽车及摩托车时，请勿使用播放器，以免造成危险。
- 切勿以较大音量长时间收听，以免对听力造成不良影响。
- 切勿用清水清洁本机，请用稍稍湿润的布清洁本机表面即可。
- 低电压使用时可能引起声音失真并请及时充电，长时间不使用时请断开电源。
- 蓝牙功能与常见的智能手机、平板电脑等兼容，但根据您所使用的设备或应用程序的不同，可能不支持某些功能。

一、
蓝牙模式

- 长按开关开机，开机后，音箱发出开机提示音，蓝牙指示灯蓝灯快闪，进入蓝牙模式，音箱发出蓝牙模式提示音。
- 蓝灯快闪进，入配对状态，此时打开蓝牙设备搜索“AS19”设备名称确认即可连接，如需密码则输入(0000)，连接成功后蓝灯常亮，音箱发出提示音，音乐播放过程中蓝灯慢闪。已配对过的蓝牙设备先打开蓝牙，再开启音箱则自动连接。
- 支持蓝牙免提通话功能。蓝牙听音乐时可接听电话，挂断电话后继续播放音乐，短按暂停/收音键接听/挂断电话，长按接听/双击重拨上一个电话。

二、TF卡/U盘模式

- 开机蓝牙模式下插入TF卡或U盘自动进入TF卡或U盘播放，如果音箱插有TF卡或U盘，开机后则直接进入TF卡或U盘播放模式。
- 播放过程中指示灯蓝灯慢闪，暂停蓝灯常亮。

三、Line in模式

- 开机状态下，插入line in 线，自动进入line in模式。
- Line in模式下，蓝色指示灯慢闪。

四、FM模式

- 长按 II/M 键，进入FM收音模式。
- 旋钮手动搜台

五、充电

- 将USB连接线插入音箱连接5V充电器或电脑即可对音箱内置电池充电。
- 充电时“充电”指示灯红灯亮，充满后红灯灭。

六、本机所有模式下开机音量默认为总音量大小的60%。电池电压低于3.2V时音箱会自动检测并发出低电报警提示音，电池电压低于3.0V时音箱会发出提示音并自动关机。

七、按键功能一览表

按键	按键名称	模式				
		蓝牙	TF卡/U盘	Line in	FM收音	电话接听
1	II/M	长按模式切歌/短按播放/暂停	长按模式切歌/短按播放/暂停	长按模式切歌/短按播放	长按模式切歌/短按播放	来电时，短按接听键，长按挂断键，长按挂断键
2	◀/▶	短按上一曲 长按音量减	短按上一曲 长按音量减	/	/	/
3	▶/+	短按下一曲 长按音量加	短按下一曲 长按音量加	/	/	/
4	○	长按开机/关机 音量	长按开机/关机 音量	长按开机/关机 音量	长按开机/关机 音量	/

八、技术规格

- 蓝牙版本：版本5.0
- 输出：蓝牙 TF U盘 AUX输出
- 充电电源接口：USB接口
- 喇叭功率：3欧*5W
- 额定功率：5W*1
- 频率响应：150Hz-20KHz
- 噪音比：80dB
- 蓝牙输出距离：80米（无障碍物）
- 电源输入：DC 5V 1500MA



部件 名称	有害有害物质或元素				
	(Pb) (μ g)	(Hg) (μ g)	(Cd) (μ g)	(Cr (VI)) (μ g)	(PbBr) (μ g)
电极板	×	○	○	○	○
电池	×	○	○	○	○
外壳	○	○	○	○	○

(+) 表示该有害有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2008规定的限量要求以下。

(-) 表示该有害有害物质至少在该部件的某一均质材料中的含量超过了SJ/T 11363-2008规定的限量要求，上表中打“×”的部件，由于技术原因目前无法实现替代，后续会逐渐改善。

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning :

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 0 centimeters from the device surface at all times, except for non-repetitive patterns with transient time intervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.