

HOLLOW WHEEL TWIST STUNT CAR

INSTRUCTIONS

THANK YOU FOR YOUR CHOICE. OUR PRODUCT IN ORDER TO UNDERSTAND OUR PRODUCT BETTER, PLEASE READ THE FOLLOWING INSTRUCTIONS BEFORE USE, WHICH CAN BRING YOU DIFFERENT CONVENIENCE EXPERIENCE.

NOTE

(This product is not intended for use only for reference, please refer to the request for the steps.)

BATTERY OPERATE PRODUCT

This product is suitable for children 8 years old and above after assembled / charged by adults. **Play with children again, please use the product under the supervision of adults.**

Warning

Please do not disassemble or modify this product without authorization. Any changes may cause the product to malfunction.

Precautions for use

1. The car body of the product uses rechargeable battery, the number of cells is detailed in the battery diagram of the battery room, the remote control uses 2.5V/4A supercapacitor batteries.

2. Battery removal and loading should be by battery room polarity and voltage correctly operate.

3. Rechargeable battery is not rechargeable.

4. Rechargeable batteries must be charged under adult supervision.

5. The rechargeable battery should be removed from the toy before charging.

6. Different types of batteries or old and new batteries can not be mixed.

7. Only batteries that are the same or equivalent to the supercapacitor battery can be used.

8. Exhausted battery should be removed from the toy. If not used for a long time, please remove the toy battery.

9. Power terminals may not be short-circuited.

10. Use a screwdriver to unscrew the screws on the cover of the battery compartment, insert the batteries according to the correct polarity of the positive and negative poles, and unscrew the screws on the cover of the battery compartment with a screwdriver to remove the battery.

11. Maintenance and maintenance: This product is composed of plastic, hardware and electronic components. It should not enter the water. Regularly check whether the wires, plugs, contacts and other parts are damaged. When defects are found, stop using them until they are repaired.

Product configuration

Product car body X1

Remote control X1

Battery case X2

Water bottle X1

Screwdriver X1

Charging cable X1

Manual X1

(1)

How to install the battery

A. Remote control

1. Close the remote control battery cover, and install AA batteries according to the position and negative direction in the battery compartment of the remote control.

2. Close the battery cover

B. Remote control car

1. Open the battery cover under the car, connect the rechargeable battery pack to the power socket and put it into the battery compartment under the car.

2. Close the battery cover and tighten with a screwdriver.

How to charge

1. Before playing, please charge the new battery pack.

2. First plug the battery pack (plus) in the charger, then (plus) charged in the socket.

3. Using a 3.2V charger, the time required to fully charge the battery is 90 minutes. The charging cable has an indicator light, and the red light is on when charging, and the red light is off when fully charged. Do not overcharge, charging for too long will not increase the power.

Description of automatic code matching

1. After put the batteries in the controls, the motor light flashing, and put the batteries in the car and set on car, starting to connect. Success, the control motor light off. Otherwise repeat the above operation.

2. Each remote control can only be connected to one remote control car. When the connection is successful, each car will not interfere with each other. Note: Multiple cars cannot be connected at the same time.

3. The remote control did not find a signal from the remote control car when it was swapped after one minute, and the power indicator was flashing, and the power switch must be restored to lock the frequency.

4. When you need to use other remote control or remote control car of the same model, you need to turn off the power of the remote control and the remote control car to reset.

How to play remote control car


1. Turn on the remote control car switch.

2. Operate the buttons and direction disk of the remote control to make the remote control car rotate forward and backward, rotate left and right.

3. Turn off the car after playing.

4. After use, you only need to turn off the switch of the remote control car, and the remote control will automatically enter the sleep mode.

Remote control parts description



Features:

1. Short press to change speed press to spray (only for spray function of the remote control car)

2. Light switch, music switch/beat sound

3. Automatic presentation

4. Forward/backward

5. More reference right

Handle remote control

Remote control instructions

1. Press the automatic demonstration button, the remote control car will perform automatic demonstration of functions, including: Forward, Reverse, the control motor light off. Otherwise repeat the above operation.

2. The colorful gradient light produces a slow flash gradient effect with the product status.

3. Forward button plus left button for left turn, forward button plus right button for right turn.

4. Press on and play the play.

5. Play the car start sound and display the lights after the up-response.

6. The rotation and turning/changes of the remote control car during the driving process will play different music sounds.

Operation tips

1. Please make sure that the power switch is at the "ON" position. When you are operating, such as the power switch is at "OFF", the remote control car is off.

2. When the battery power is consumed, the left and right steering becomes insensitive, and the forward and backward will also slow down. At this time, the battery needs to be recharged and charged.

3. The effective control distance of the remote control car is about 40 meters. When the distance is exceeded, the remote control car may stop or become out of control.

1. Open the cover above the spray device.

2. Add water to the water filling port with a water bottle, and fill the back cover Put the lid on, it will be left and right.

3. After adding water, press the spray button, the head car will spray mist. Please do not spray.

4. When adding water, please pay attention to avoid spraying batteries and other places to avoid damage to the body and parts. The operation is suitable for remote control cars with spray function.

General troubleshooting

Failure symptoms	cause of issue	Approach
The vehicle controls do not work	<div>1. The remote control car not connected at the switch of the remote control car and not loaded.</div> <div>2. The remote control car remote control car is not correctly matched the battery.</div> <div>3. The power of the rechargeable battery pack is insufficient.</div>	<div>1. Turn on the remote control car switch and reinsert the remote control.</div> <div>2. Plug the battery into the remote control or remote control car correctly.</div> <div>3. Charge the rechargeable battery pack.</div>
The vehicle is not controlled effectively and cannot respond to control	<div>1. The battery or rechargeable battery pack in the remote control has insufficient power.</div> <div>2. There may be sources of interference near the site.</div>	<div>1. Replace the batteries in the remote control with new ones, or charge the rechargeable battery pack.</div> <div>2. Change the venue.</div>
Exception operation	When the function of the remote control car is changed to forward, reverse and other functions, it will be slow down, or when the coast brake is slow down.	Turn on the power switch again to protect the remote control car from power failure.
Maintenance matters	<div>1. Can not close to the fire, avoid direct sunlight high temperature and humidity or keepers in the car, to avoid short circuit fire.</div> <div>2. Do not play when the car and remote control battery removed and the remote control back into the car for too long packaging to avoid damage or deformation during transport or storage.</div> <div>3. Remote control car with a sharp object to scratch.</div>	
Tips	When the car moves, please do not touch the wheels of the remote control car, so as to avoid injury.	
Do not play on the water or in dangerous places to prevent accidents.	Do not play remote control car in the water.	
Instructions	Battery chargers that use this toy must be regularly checked to prevent damage to the wires and other components and, if damaged, must be repaired for damage.	

To consumers

1. When playing remote control car motors, please be careful not to damage furniture or glass.

2. Please play outside in a safe place, do not play remote control car in the road and the crowd, so as to avoid danger.

3. Play remote control car to bear thunder outdoors, should immediately stop playing.

4. When the wheel is spinning, do not stretch your hands close to avoid injury, and do not get involved in race, debris, etc.

5. Do not drive the remote control using people.

6. Do not throw the remote control car, check the battery.

7. When playing the remote control car, please keep it away from fire and high temperature.

8. The car uses a complex electronic circuit and a large number of components, please do not disassemble or modify the circuit board.

9. Remote control car after playing with dirt, dust must be gently wiped with a damp cloth.

10. Do not put the toy in the water, it will damage the electronic components.

After-sales Service

Warranty Time

12 months from the date of purchase.

Free Service:

If any questions, please kindly feel free to contact us

service@uthcracy.com

100%

To our dear customers

Conforming to relevant certification standards with high-quality materials and components, this product can be recycled and reused, beneficial to protect natural resources and environmental.

https://www.uthcracy.com

(2)

(3)

(4)

(5)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

(6)