

Attention:

2.1 After the machine is powered off, do not perform the firmware upgrade operation. Charge the battery beforehand.

2.2 When the machine is powered off and plugged in, there will be a charging icon.

2.3 When the USB is plugged into the computer, the machine will automatically charge. When the power of the machine is low, don't do any operations.

Suggestions:

When the user uses and upgrades for the first time, the machine is charged to 100% of the power to make sure the battery level is relatively accurate.

D. Basic parameters:

Model	SP1015A
Processor	A133
DDR	2GB
Flash	32GB
WiFi	802.11 b/g/n
Bluetooth	Support
Camera	Front:2MP Rear:5MP
Gravity Sensor	Support
Display Screen	10.1" 800X1280 IPS
Touch method	Capacitive multi touch
Battery	6000mAh
Audio input	Built-in MIC
Audio output	Plug 3.5mm Left/right channel
Speaker	8Q/1.0W
USB	Type-C USB
Function keys	On/Off button, Volume+ Volume-
Power supply	5V: 2A
Micro SD/TF card	Support
System	Android

* All parameters are subject to physical condition.

FCC Warning


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can generate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information: This Tablet PC meets the government's requirements for exposure to radio waves. The SAR limit for this device is 1.6 W/kg. The SAR limit for the device (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Tablet PC has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the tablet PC in close proximity to the body. The FCC RF exposure requirements also permit the use of accessories that maintain an 8mm separation distance between the user's body and the back of the Tablet PC. Use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.



Quick Operating Guide

Introduction

This operation guide is for the user to understand and familiarize with our products as soon as possible. Here, we briefly introduce the key layout and definition of our products in a graphical way, and give some basic instructions for some basic operations.

A. The key layout and definition



Key function description:

- ① Power button: Press and hold 3S to switch on/off, short press again to wake up screen.
- ② Volume button
- ③ Expansion slot
- ④ USB charging interface / USB east / OTG east: USB line interface; OTG line interface; transfer mobile hard disk, keyboard, mouse.
- ⑤ TF Card Block
- ⑥ Front camera
- ⑦ Rear camera
- ⑧ Speaker.


02

B. Desktop introduction

1. Main Interface introduction:



2. Navigation Bar



03

C. Basic operations

1. Boot / shutdown

In the off state, long press the power button (3 seconds) to boot, the machine after the boot LOGO enter the main interface. It is also possible to insert the charger when it is turned on (please use the dedicated 5V2A charger provided by the company).

In the boot state, press and hold the power button for 3 seconds, and the shutdown option will pop up. Touch Shutdown to shutdown.

In the case of crash or inconvenient touch, long press the power button for 10 seconds to force the shutdown.

2. Power / USB charging detection

Battery usage indication

When the battery is in use, as the battery power decreases, the white bar on the desktop's navigation bar battery icon will gradually decrease to the icon .

Charge status indication

Connect the USB cable with the USB charger and then connect it to the USB port of the machine to charge it. The battery icon in the navigation bar of the desktop indicates that the battery is being charged. Do not insert or remove the charger during charging. When the battery icon fills up (go to the navigation bar application shortcut setting interface, the battery level is displayed as "see icon").

04