


# OEH1301说明书

尺寸:85\*75mm

工艺:风琴折,4C

封面

 <p><b>lytm</b> <b>COZYSNUG</b> SLEEPBUDS FOR NIGHT AND DAY <b>USER MANUAL</b> Support Phone: (+1) 2108588666</p>	<h3>PRODUCT OVERVIEW</h3>  <p>Choose the ear tips that fit your ears best. Please note that the Sealed Ear Tips are for noise blocking. To better block out noise, insert the earbuds into your ear canals and turn gently until the ear wings are snug against your ear ridges.</p> <p>3 Sizes of Ear Tips Included: S, M, L</p>	<h3>WEARING</h3> <p>Choose the ear tips that fit your ears best. Please note that the Sealed Ear Tips are for noise blocking. To better block out noise, insert the earbuds into your ear canals and turn gently until the ear wings are snug against your ear ridges.</p> <p>3 Sizes of Ear Tips Included: S, M, L</p>	<h3>CHARGING</h3> <p>Place the earbuds in the charging case and close it. (While the earbuds are charging, the LED light on the case will stay on. The light will turn off once fully charged.)</p> <p><b>Charging Case</b> Connect the charging case to a power source using the USB-C charging cable. (While the charging case is charging, the LED light on the case will flash. Once fully charged, the LED light will stay on. After removing the USB-C charging cable, the LED light will turn off after 10 seconds.)</p>	<h3>POWER ON AND PAIRING</h3> <p>1. Opening the charging case When you open the charging case, the earbuds will automatically power on and enter Bluetooth pairing mode.</p> <p>2. Connecting to your device Select "Lytm Cozysnug" from your device's Bluetooth list to connect. During pairing, the LED indicator on one earbud will start flashing. Once the pairing is successful, you will hear "Ding".</p> <p>3. Automatic Reconnection After the initial pairing, they'll automatically reconnect to your device every time you open the charging case, as long as you haven't deleted the pairing history from your device.</p> 	<h3>POWER OFF</h3> <p>To power off, return the earbuds to the charging case and close it. The earbuds will automatically power off after 5 minutes if they are not connected.</p> <p><b>RESET</b> When the earbuds are powered on but not connected, perform five consecutive touch taps on either earbud to restore factory settings.</p> 
---	--	---	---	---	--

<h3>TOUCH CONTROLS</h3>  <table border="1"><tr><td>L/R</td><td>Volume Down</td><td>Click and then hold</td></tr><tr><td></td><td>Previous Track</td><td>Touch and hold for 2 seconds</td></tr><tr><td></td><td>Volume Up</td><td>Click and then hold</td></tr><tr><td></td><td>Next Track</td><td>Touch and hold for 2 seconds</td></tr></table> <p><b>Sleep Mode Timer Selection:</b> To enter sleep mode and set the timer, touch (left/right) twice. Choose from 30 minutes, 45 minutes, or 60 minutes.</p> <p><b>Sleep Mode Lock Function:</b> When EQ is switched to Sleep Mode, only EQ switching and answering/hanging up calls are operational.</p> <table border="1"><tr><td>L/R</td><td>Answer / End a Call</td><td>Double tap</td></tr><tr><td></td><td>Reject a Call</td><td>Touch and hold for 2 seconds</td></tr><tr><td></td><td>Play / Pause</td><td>Double tap</td></tr><tr><td></td><td>Music Mode / Sleep Mode</td><td>Triple tap</td></tr></table>	L/R	Volume Down	Click and then hold		Previous Track	Touch and hold for 2 seconds		Volume Up	Click and then hold		Next Track	Touch and hold for 2 seconds	L/R	Answer / End a Call	Double tap		Reject a Call	Touch and hold for 2 seconds		Play / Pause	Double tap		Music Mode / Sleep Mode	Triple tap	<h3>SPECIFICATIONS</h3> <table border="1"><tr><td>Brand</td><td>Lytm</td></tr><tr><td>Model</td><td>Lytm Cozysnug</td></tr><tr><td>BT Version</td><td>BT5.3</td></tr><tr><td>Charging Input</td><td>5V=1A</td></tr><tr><td>Battery Capacity</td><td>35mAh*2 (Earbuds) 250mAh (Charging Case)</td></tr><tr><td>Charging Time</td><td>1 Hour (Earbuds) 1 Hour (Charging Case)</td></tr><tr><td>Music Time</td><td>6 Hours</td></tr><tr><td>Waterproof Rating (Earbuds)</td><td>IPX4</td></tr><tr><td>Bluetooth Range</td><td>10 m / 33 ft</td></tr></table>	Brand	Lytm	Model	Lytm Cozysnug	BT Version	BT5.3	Charging Input	5V=1A	Battery Capacity	35mAh*2 (Earbuds) 250mAh (Charging Case)	Charging Time	1 Hour (Earbuds) 1 Hour (Charging Case)	Music Time	6 Hours	Waterproof Rating (Earbuds)	IPX4	Bluetooth Range	10 m / 33 ft	<h3>CLEAN</h3>  <p>Dust, earwax or other debris can accumulate in the earbuds. To maintain optimal sound quality, regularly clean your earbuds using a cotton swab slightly moistened with rubbing alcohol to gently wipe the metal mesh filter under the rubber ear tips.</p> <h3>NOTICE</h3> <ol style="list-style-type: none"><li>Do not charge the device continuously for more than 12 hours.</li><li>Do not disassemble the headset or put the device into the fire to avoid explosion.</li><li>Do not place the magnetic charging cable or</li></ol>	<p>the magnetic charging port or the headset near metal objects.</p> <ol style="list-style-type: none"><li>Use of charging cables not approved by the manufacturer may cause fire, explosion or other hazards.</li><li>Use the product within the temperature range of 32°-95°F and store the product within the temperature range of 14°F-113°F. Excessively high or low temperatures may cause equipment malfunction.</li><li>Do not expose the headset to the sun for a long period of time, otherwise it will be easily deformed, aging and breakage.</li><li>This product has a built-in non-removable lithium battery, the battery is prohibited from disassembly, impact, extrusion or put into the fire, if there is a serious expansion, please do not continue to use.</li></ol>	<p>Warranty: 12-Month Limited Warranty Support: Lifetime Technical Support Email: support@lytm.co Official Website: www.lytm.co Support Phone: (+1) 2108588666 YouTube: youtube@Lytm Instagram: Instagram@lytmofficial Facebook: Facebook@Lytm Tiktok: Tiktok@lytm</p>
L/R	Volume Down	Click and then hold																																												
	Previous Track	Touch and hold for 2 seconds																																												
	Volume Up	Click and then hold																																												
	Next Track	Touch and hold for 2 seconds																																												
L/R	Answer / End a Call	Double tap																																												
	Reject a Call	Touch and hold for 2 seconds																																												
	Play / Pause	Double tap																																												
	Music Mode / Sleep Mode	Triple tap																																												
Brand	Lytm																																													
Model	Lytm Cozysnug																																													
BT Version	BT5.3																																													
Charging Input	5V=1A																																													
Battery Capacity	35mAh*2 (Earbuds) 250mAh (Charging Case)																																													
Charging Time	1 Hour (Earbuds) 1 Hour (Charging Case)																																													
Music Time	6 Hours																																													
Waterproof Rating (Earbuds)	IPX4																																													
Bluetooth Range	10 m / 33 ft																																													

封底

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.