


User Manual




CUSTOMER SERVICE



WORRY-FREE SHOPPING

We always promise all our products are covered **30-Days Hassle-free Refund** & a **1-YEAR Replacement Guarantee**.



PROFESSIONAL CUSTOMER SERVICE TEAM

Our customer support doesn't end after your purchase;

Please contact us if there's anything we can do for you.
You can click "Contact Seller" on your order, and our customer service team will help you asap.

How to Use:

Device Part:

Long press ⚡ for 2 seconds to turn on the device. Then the item is in standby mode and the LED light turns on.

Short press ⚡ to switch among 9 vibrating modes.


Long press ⚡ for 2 seconds to turn off the device.

APP Part:

Download and install the APP:

Scan the QR code below to download the app. Alternatively, search for "Love Spouse" to download the app from the Apple App Store or Google Play Store(Scanning the QR code below is recommended).

Alternatively, you can also click the "+" icon and then click the button "Enter Device Code" to manually enter the code 9134 to bind the device.



Make sure your Bluetooth is on before open this APP.

Rename/delete device:

Long press the device icon to rename or delete the device.



7 Playing Modes on the App:

1. Classic Mode:

Touch the screen to switch among 9 vibrating modes.

2. Video Mode:

Select a local video, then you can watch the video and touch the screen to switch among 9 vibrating modes.

3. Music Mode:

Select music to play. The device will then vibrate based on the music rhythm.

4. Draw Something:

Draw a line on the screen. The device will then vibrate based on what you have drawn.

5. Shake Mode:

Shake your phone to customize the vibration intensity based on your force.

6. Interactive Mode:

Click the "+" icon and search for your partner's Email/ID to add her/his account (Your partner can download and register the app even without the toy. They can then apply to control your toy).

Find your partner's ID under her/his account info after login (Mine-Personal Information-ID).

After verification, your partner will appear in your friend list.

When you are both online, click your friend's name to send an interaction request. After the confirmation, you can control the device via video invite (text, images, voice & video calls). Your partner can control your toy in Classic Mode or make custom vibration in Draw Something or Shake Mode.

7. Game Mode:

Click "START" to begin. When two matching icons collide, vibration is generated and a larger icon

appears. You can play while experiencing the vibration.

Tips: If you don't know how to control your device via the app, you can get help from:

"Mine - Operation Guide"

"Mine - Feedback & FAQ"

Or you can ask for assistance from:

"Message - News - Official Customer Service"


We promise to respond within 24 hours.

How to Clean & Store:

1. Turn off the device before cleaning.
2. Clean the toy with warm water and antimicrobial soap.
3. After washing, dry the item with a towel or tissue.
4. Store the item in a cool, dry place.
5. Avoid sun exposure, heat, high pressure, and wet environments.

How to Charge:

1. We provide a USB cable for charging.
2. Please use the DC charging cable and connect it to the DC charging port on the front of the product for charging.
3. The LED light flashes while charging.
4. After fully charged, the indicator light is always on.



Package List:

1 Vibrator, 1 Charging Cable, 1 User Manual

Notes:




1. Please read the manual before using this product.
2. Fully charged before first use.
3. Please charge it with a matching adapter.
4. Please use the charging cable inside this package.
5. Please don't use the product while charging.

Product Details:

Material	ABS+TPE
Working Noise	≤ 40 dB
Product Modes	9 Vibrating Modes
Charging Time	120 Minutes
Working Time	60 Minutes(Fully Charged)
Waterproof Rating	IPX7

Remote control mode

1. The massager is turned on, the light is long bright, and it is in standby state.
2. Long-press remote control 1.5s, power on, remote control indicator light.
3. Long-press remote control 1.5s, turn it off.
4. Short press Switch to the next frequency, a total of 10 frequency conversion.



Remove the sticker before use

frequency switch

power switch

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.