

## Ipad Pencil



## User manual


Please carefully read the this user manual before using, and keep it well for future reference.

## Specification

Indicator light Press and hold on for 3 seconds to switch on and of

Charging by magnetic to ipad

Built in battery



Replaceable pen nib


Note:Appearance is subject to real object.

2


## Instruction

1.Please hold on the key switch for 3 seconds on the top of the pen , the indicator light will be light up immediatley, when you hold on again for 3 seconds the indicator light will be turn off.In the power on state, idle time for 5 minutes for intelligent shutdown.


Press and hold on for 3 seconds to switch on and of



2.Now you can use the stylus pen instead of finger to tap,sliding and do other operations on IPAD.In some special application software, you can use the stylus pen to write or draw. This stylus pen is not compatible with the ipad models which is not list in the specification.



3.The pen nib is replaceable so that there is no need to worry about normal wear.(The pen nib can be easily screw off and replace with a new one.)




3

## Bluetooth shortcut Function

1.Open the bluetooth panel on ipad,search for bluetooth name:" SKY-PEN" ,click and match it,for the fist time to connect with capacitive stylus pen bluetooth with ipad, please wait for more than 5-10 seconds.




2.After stylus pen connect with bluetooth, sliding from left side to right side on ipad, click edictor to add small battery display components,can show the real time battery.



## Charging


1.Charging by magnetic absorbtion to ipad, after connect with bluetooth it can be absorbdeto ipad,it is going on charging by wireless.The green light on for 30 seconds when itis fully charge,and then It will automaticallyturn off,it means fully charging.(Magneticand absorbed to ipad charging only supportipad models:ipad pro series,ipad mini 6,ipadair 4/5.)




4

## Charging indication


Blue light will turn on when it working



Red light will turn on when it charging



Green light will turn on when it fully charge ,and it will automatically turn off after 30 seconds



## Product Specification

Product Name	Ipad pencil
Functions	Painting,Writing,Note-taking Touching
Materials	Plastic Pen body (Pom plastic pen head)
Measurement	Pen head Φ1.0mm pen body Φ8.8mm
Working Time	9 hours
Color	Multi-color
Battery Model	65430
Charging	Magnetic ipad charging
Using	iPad and capacitive touch screens devices
Package	Giftbox package, user manual

5

## Support Ipad model

Name/Dimensions	Model
iPad mini 6/8.3-inch(2021)	A2567/A2568/A2569
iPad mini 5/7.9-inch(2019)	A2133/A2124/A2126/A2125
iPad Pro 5/12.9-inch(2021)	A2378/A2461/A2379/A2462
iPad Pro 4/12.9-inch(2020)	A2229/A2233/A2069/A2232
iPad Pro 3/12.9-inch(2018)	A1876/A2014/A1895/A1983
iPad Pro 3/11-inch(2021)	A2377/A2459/A2301/A2460
iPad Pro 2/11-inch(2020)	A2228/A2231/A2068/A2030
iPad Pro 1/11-inch(2018)	A1980/A2013/A1934/A1979
iPad Air 5/15.1-inch(2022)	A2588/A2589/A2591
iPad Air 4/10.9-inch(2020)	A2316/A2324/A2325/A2072
iPad Air 3 /10.5-inch(2019)	A2152/A2123/A2153/A2154
iPad 9/10.2-inch(2021)	A2602/A2603/A2604/A2605
iPad 8/10.2-inch(2020)	A2270/A2428/A2429/A2430
iPad 7/10.2-inch(2019)	A2197/A2198/A2200
iPad 6/9.7-inch(2018)	A1893/A1954

Notes:In power on mode,it is applicable to ipads above 2018,not works for earlier version ipad;Pls confirm the above ipad model before purchasing.

## Common faults and exclusion methods

Faults	Exclusion method
Breakage line	1.Check whether the pen nib is placed on position or not, please test it after tighten it again.
Elimination line	2.Pls test it again after replace pen nib, 3.Whether the toughened film is seriously damaged and too thick 4.Restart the ipad
cant write out	1.Check if it open or not. 2.Check whether the ipad model support the stylus pen or not. 3.APP support stylus pen or not
cant open the stylus pen	4.Check if it have connect with origin pencil or not,if connect then disconnect then use it again. 1.Check if the stylus pen have battery power or not 2.Check if it is open or not according to the operation.
Note:if it cant works still then please contact with customer service and replace it accordingly.	

6

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- .Reorient or relocate the receiving antenna.
- .Increase the separation between the equipment and receiver.
- .Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- .Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. RF Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.