

1. 中文英文双面说明书 尺寸: 130*105mm/单面印单黑

◎ 产品示意图

伸缩/调频键
开关机键+震动调频键
加热键
开关键
长按开机/长按3秒关机,短按调频

伸缩调频键:短按调节10倍功能频率,长按3秒关机
开关键+震动调频键:短按调节10倍震动力度,长按3秒关闭所有功能
加热键:短按开启加热/加热关闭功能
备注:1.先长按打开玩具开关,再短按打开遥控总开关(红灯亮),遥控才能进入工作状态。
2.加热点按后,点按关闭。

◎ 使用说明

- 使用前,请用清水或沐浴露冲洗干净,随即擦干;
- 可吮吸本产品,或用产品刺激胸部,还可用品抽插阴部肛部获得快感;
- 可打开您所需要的振频;
- 使用后,请用清水或沐浴露冲洗干净,随即擦干,并存放于阴凉之处。

- 1 -

◎ 遥控供电说明

- 保持遥控运行,需1节3V纽扣电池。如电池失效,请自行更换新电池。电池应以正确的极性放入电池室内。若长时间未使用产品,请及时取出电池。
- 本遥控使用的电池为非充电电池,非充电电池不能充电。不同类型的电池或新旧电池建议不要混用。电池不得暴露在诸如日照,火烤或类似过热环境以及潮湿的环境中,电池应以正确的极性放入。
- 每次使用本产品前后,请将其进行彻底清洗。清洗前确保产品处于关机状态,电池已取出,并且产品处于闭合(Close)状态。

◎ 供电说明

- 将USB线连接到一个USB电源适配器(不含该配件)或USB端口,可以使用任何USB电源适配器进行充电。
- 完整充电一次约需1.5-2.0个小时。根据本器具内部残余电量的具体充电时间或有不同。
- 本器具完全充电后使用时间大约40-60分钟,具体使用时间取决于您选择的震动模式。震动模式频率越高,电池消耗越快。
- 废弃器具前,必须将电池从器具中取出,在取出电池时,器具必须断电,电池应安全地处置。

◎ 保养与维护

- 每次使用前后请使用中性肥皂和水清洗并擦干,远离极端的高温或低温环境。
- 请将本产品贮藏于凉爽、通风、干燥处,保证产品避免阳光直晒、高温、重压、潮湿及污染。

◎ 注意

- 本品仅适合成年人使用,非避孕用品,请远离儿童放置。
- 使用过程中,请勿过度用力,请留意避免受伤。
- 请勿与他人混用本产品。使用过程中如有不适,请立即停用本品。
- 须定期检查产品是否损坏,发现损坏时应立即停止使用。
- 器具具有加热表面,对热不敏感的人使用时必须注意。

- 2 -

◎ Product diagram

Telescopic frequency control button:
Short press to adjust the frequency of the 10-frequency function, long press for 3 seconds to turn off the function.

On key+vibration frequency modulation key:
Short press to adjust the 10-frequency vibration intensity, long press for 3 seconds to turn off all functions.

Heating button:
Short press to turn on heating, short press to turn off the function.

Remarks:

- First, long press and turn on the penis switch, then short press and turn on the remote control main switch (the red light is on), in order to enter the working state of the remote control.
- Press to turn the heating on and off.

operation instructions

- Before use, rinse with water or shower gel and wipe dry immediately;
- This product can be sucked, or used to stimulate the chest, or the product can be inserted into the genital and anal area to obtain pleasure.
- You can turn on the vibration frequency you need.
- After use, rinse thoroughly with water or shower gel, dry immediately, and store in a cool place.

Remote control power supply instructions

- To maintain remote operation, one 3V button battery is required. If the battery fails, please replace it with a new one. The battery should be placed in the battery compartment with the correct polarity. If the product has not been used for a long time, please remove the battery in a timely manner.
- The battery used in this remote control is a non rechargeable battery. Non rechargeable batteries cannot be charged. It is recommended not to mix different types of batteries or old and new batteries. Batteries should not be exposed to environments such as sunlight, fire, or similar overheating and humidity. Batteries should be placed with the correct polarity.
- Before and after each use of this product, please thoroughly clean it. Before cleaning, ensure that the product is turned off, the battery is removed, and the product is in a closed (Close) state.

Power supply instructions

- Connect the USB cable to a USB power adapter (excluding the accessory) or USB port, and you can use any USB power adapter for charging.
- A complete charge takes approximately 1.2-2.0 hours. The specific charging time may vary depending on the amount of residual electricity inside this device.
- After full charging, the usage time of this device is approximately 40 to 60 minutes, depending on the vibration mode you choose. The higher the frequency of the vibration mode, the faster the battery consumption. Before abandoning the appliance, the battery must be removed from the appliance. When removing the battery, the appliance must be powered off and the battery should be disposed of safely.

Maintenance and upkeep

- Before and after each use, please use neutral soap and water to clean and dry, and stay away from extreme high or low temperature environments.
- Please store this product in a cool, ventilated, and dry place, ensuring that it is protected from direct sunlight, high temperature, heavy pressure, humidity, and pollution.

Warning:

- It is recommended to use lubricating fluid for the first time when using it.
- Make sure to turn off the power of the dildo and the remote control after use, so as not to affect the use of the battery.
- Wash with clean water or neutral detergent after use, and dry in a ventilated place after washing.
- The product is waterproof for life, so it is not recommended to use it directly in water.
- The heating time is about 4-5 minutes, please use it with caution for people who are sensitive to heat.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.