



尺寸: 85*125mm 材质: 铜版纸



Bone Conduction
Wireless Headphones
User Manual




Wearing



Spread the headphones apart with both hands and wear them to the appropriate position.

Note:
When using the headphones, it's important to wear them correctly. Incorrect positioning may cause discomfort. The sound-producing parts of the headphones should be in front of both ears without the need to insert them into the ear canal.

Features



Basic Operations

Power on/off

Press and hold the power button for 3 seconds. When the indicator light flashes red and blue alternately, the headphones have been turned on. When the red light turns off, the headphones have been turned off.



3 seconds

Bluetooth Pairing

STEP 1:

Keep the headphones within a 1-meter range for the initial pairing.



1M


STEP 4:

Click to connect. The blue light will flash slowly upon successful connection.

Bluetooth Pairing


STEP 2:

When the red and blue lights flash alternately, it indicates that the headphones have entered automatic Bluetooth pairing mode.




STEP 3:

Open your smart device and locate "X6" in the Bluetooth list.



Factory Reset

1. Press the Power button or ensure the headphones are in the power on state.



3 seconds

①

2. Quadruple clicks on + button. (Red light stay on)




②



x4


③

3. Forget the X6 device name on your phone's Bluetooth settings.



④

4. Connect with your device again.



⑤

5. Open the USB drive on computer and move the music files in or out. Then disconnect the data cable. (If it does not pop up, you can click on [This computer] to see the corresponding disk)



⑥

6. Connect with your device again.




⑦

7. The blue light will flash slowly upon successful connection.


MP3 Transmit Data

1. Utilize the magnetic data & charging cable to connect the computer and headphones.




①

2. Open the USB drive on computer and move the music files in or out. Then disconnect the data cable. (If it does not pop up, you can click on [This computer] to see the corresponding disk)



②



③

3. Connect with your device again.




④

4. The blue light will flash slowly upon successful connection.

MP3 Transmit Data


3. Double clicks on power button(In power on state) will switch MP3 mode.(light off)




①




②



③



④



Frequently Asked Questions (FAQ)

- ① Why can't headphones connect to other devices?
Why can't phone find the Bluetooth headphones?
A Our headphones don't support Multipoint Connection.
You can try three methods:
1. Forget the X6 on the last connected device and then connect to the next device.
2. Turn off the Bluetooth of the last connected device and restart the headphones for new connection.
3. Reset your headphones.(refer to 'Factory Reset' section)
- ② About the following problem:
Unable to pair the headphones with the Phone?
Phone can't search for headphones?
A Try the factory reset process.
Details refer to 'Factory Reset' section.
- ③ How to cancel pairing through headphones?
A Quadruple clicks on + button,(Red light stay on)
- ④ When to charge the headphones?
A The headphone's battery capacity will be displayed on the phone. The headphones will prompt "Low power" when the battery is running low.
- ⑤ Why is the size not suitable?
A This band is elastic and can be bent, but cannot be extended or retracted. The band also reserves space for customers with long hair to wear.(If you still feel it is not suitable, please contact us and we'll solve the problem for you)

Frequently Asked Questions (FAQ)	
<p>① Why do they find it unclear or not loud enough when I call them? A 1. The open ear headphones Mic can pick up surrounding noise during calls. 2. APP calls might lower calling quality of both sides. (If your calls are still not clear in a quiet indoors environment, please contact us and we'll solve the problem for you)</p> <p>② Why the bass is not enough? A 1. Due to the interactivity considerations of open design, it is not possible to turn off the sound in the ear canal, but you can choose to wear earplugs to isolate noise. 2. Too high volume or too strong vibration will cause uncomfortable of your ears, based on health considerations, we choose the balanced mode.</p>	<p>IC Caution:</p> <p>IC Caution: Radio Standards Specification RSS-Gen, issue 5</p> <p>- English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:</p> <p>This device may not cause interference. This device must accept any interference, including interference that may cause undesired operation of the device.</p> <p>RF exposure statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>
<p>Storage & Maintenance</p> <p>1. Store the headphones in a cool and a dry place, the working temperature is 0-45°C. 2. Do not put the headphones at a higher or lower temperature environment. 3. Please charge it before using after a long time storage. 4. Do not charge the headphones in the moist environment. 5. Do not use the headphones during charging. 6. Headphones resistance to water but do not use under water for more than half an hour.</p>	<p>IC Caution: Radio Standards Specification RSS-Gen, issue 5</p> <p>- English: Cet appareil contient des émetteurs / récepteurs exemptes de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:</p> <p>Cet appareil ne doit pas causer d'interférences. Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.</p> <p>Déclaration d'exposition RF: L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.</p>

FCC Compliance		FCC Compliance		Button Function		Specifications		Warranty	
FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.		NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.		Bluetooth Mode		Model	X6	3. The following situations are not covered by the warranty: a. Damage caused by human factors; b. Damage to the machine's production label; c. Damage caused by incorrect operation or installation not following the user manual; d. Damage caused by natural disasters such as floods, fires, and other force majeure factors; e. Failures and damages caused by unauthorized personnel's repair, modification, alteration, or disassembly; f. Serious damage, scratches, or circuit board burnout on the casing; g. Exceeding the specified warranty period; h. All accessories are not covered by the warranty.	
		Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.		Power on/off	Press and hold on power button for 3s	Bluetooth version	V5.3	4. The warranty period for repair and replacement services will not be extended or restarted after services.	
		from that to which the receiver is connected.		Pause/Play	Single click on power button	Bluetooth protocol	HSP/HFP/A2DP/AVRCP	5. For related matters, please email or call for consultation.	
		- Consult the dealer or an experienced radio/TV technician for help.		Volume up/down	Single click on + or - button	Connect distance	10m/33ft	Manufacturer	
				Next track	Double click on + button	Built-in memory	32G	• Manufacturer: Shenzhen Shengde Digital Technology Co., Ltd Dongguan Branch	
				Previous track	Double click on - button	Playback time	Up to 8H	• Address: Building 18, No.99, Hongye North Road, Tangxia Town, Dongguan City, Guangdong Province, China	
				Answer call	Single click on power button when incoming call	Standby time	About 240H		
				Reject call	Press and hold on power button for 2s when incoming call	Charging time	About 2 hours		
				Hang up	Single click on power button during a call	Charging voltage	5V		
				Voice assistant	Press and hold on the + button for 2s	Waterproof level	IP68		
				Reset	Press + button 4 times	Weight	29g		
MP3 Mode		Warranty							
Switch MP3 mode		1. Within the warranty period, if malfunctions are caused by components of this machine during normal use and maintenance, and confirmed by our technical staff, free maintenance and replacement of parts are available.							
		2. We are not responsible for special, accidental, or indirect losses incurred by users and dealers.							