

# **G050L User Manual**

# catalogue

|                                                      |    |
|------------------------------------------------------|----|
| 1 Precautions .....                                  | 2  |
| 2 Basic operations                                   |    |
| 2.1 Dropdown menu and screen closing interface ..... | 3  |
| 2.2 Reverse .....                                    | 4  |
| 3 Main interface operation and mute switch .....     | 5  |
| 4 Bluetooth function operation .....                 | 6  |
| 4.1 Bluetooth calling .....                          | 7  |
| 4.2 Contact list and call records .....              | 8  |
| 4.3 Bluetooth Music and Bluetooth Settings .....     | 9  |
| 5 Multimedia Function Operations .....               | 10 |
| 5.1 Multimedia List and Audio Playback .....         | 11 |
| 5.2 Video and image playback .....                   | 12 |

|                                                 |    |
|-------------------------------------------------|----|
| 6 Calendars .....                               | 13 |
| 7 Mobile Internet .....                         | 14 |
| 8 Air conditioning .....                        | 15 |
| 9 Settings .....                                | 16 |
| 9.1 System Settings .....                       | 17 |
| 9.2 Display settings and network settings ..... | 18 |
| 9.3 Sound Effect Settings .....                 | 19 |
| 9.4 Sound Field and Background .....            | 20 |
| 9.5 System Upgrade and Factory Reset .....      | 21 |
| 10 Car control settings .....                   | 22 |

# 1 Matters needing attention

To keep you, your car and others safe, be sure to meet the following basic requirements:

1.1 You may use the various functions of this car audio only if the traffic permits.

1.2 During driving, please focus your attention first on driving.

1.3. During the use of the stereo, adjust the volume of the stereo to a level that does not prevent you from hearing outside sounds.

1.4. In order to prevent short circuit, please install and connect all the car audio, and then connect the electrode of the car battery.

1.5. Do not open the machine for maintenance, if you need maintenance, please go to the professional maintenance station for maintenance, otherwise, small

The failure causes a big problem and brings you unnecessary property damage.

1.6 When cleaning the car, do not let water droplets splash onto the machine.

1.7 Do not use the machine when the temperature is too high or too low; otherwise, the machine cannot run normally. If this happens, discontinue use until the temperature returns to normal.

1.8 Do not use sharp objects to scratch the display, do not use hard objects to vigorously press the display, otherwise it will cause damage to the display or touch screen.


1.9 After the product is scrapped, please dispose of it properly (for example, discard it in the trash can suitable for electronic products, so as not to pollute the environment) The main functions of the car include: USB music/video/picture, Bluetooth phone, Bluetooth music, reversing, air conditioning, mobile phone interconnection, rear view, calendar and other functions.

## 2.1 Dropdown menu and screen closing interface

Swipe down from the top of the screen to display the drop-down bar, which includes the screen button, day/night mode switch button, Bluetooth button, WIFI button, brightness bar and volume bar. When the drop-down bar appears, swipe up from the bottom of the screen or click the exit button to exit the drop-down bar


It can display the off screen interface on the car's infotainment

Click this button to jump to the Bluetooth interface




Click this button to switch between day and night modes

Click this button to jump to the WIFI interface



Close screen interface

## 2.2 Reverse




After the vehicle is in reverse gear, the screen

### 3 Main interface operation and mute switch

Click to return to the main



Click to turn mute on/off



When on the main interface, click on each function

# 4.1 Bluetooth calling

Click on the number on the dial and enter the phone number to be dialed

This button can be clicked to delete the entered numbers one by

After entering the number, click this button to dial

Clicking the button can switch the call voice between the car phone and the mobile phone.

Click this button to call up the numeric keypad

Click this button to hang up the phone

Bluetooth

14:12

Dial

Telephone Book

Call Log

Bluetooth Music

Bluetooth Settings

1 2 3

4 5 6

7 8 9

\* 0 #

X

Phone icon

Talking

Unknown 10086 0:07


Numeric keypad icon

Car icon

Mobile phone icon

Hang up button

## 4.2 Contact list and call records




## 4.3 Bluetooth Music and Bluetooth Settings

Click the switch to switch the Bluetooth switch status. When the switch is turned on, the Bluetooth function is used normally. When the switch is

Click on unconnected devices to connect


Click to disconnect Bluetooth connection, click to delete device



Click this button to switch to the previous track

Click this button to switch between playback/pause status

Click this button to switch to the next track



Click to modify the Bluetooth name

Automatic answer switch, when the switch is turned on, incoming calls will be automatically answered; when the switch is turned off, manual operation is required to answer or reject incoming calls.

Automatic connection switch. When the switch is turned on, the host automatically connects to the phone within a certain range. When the switch is

## 4 Bluetooth function operation



Clicking on the main interface will enter the Bluetooth operation interface

Note: 1. There are differences in the Bluetooth modules and software used by different brands of mobile phones, and some phones are not compatible.

2. Third party mobile application software and mobile voice function are not fully compatible; 2 does not support answering and hanging up voice calls from third-party application software;

3. For driving safety, other functional operations are not allowed during calls.

### Pairing Connection Steps

1. Set the Bluetooth switch on the host to the on state.

2. Turn on the Bluetooth function on the Bluetooth phone, and the Bluetooth phone will start searching for the Bluetooth device model. When the Bluetooth name of the host is displayed on the phone, click on the Bluetooth name, and a Bluetooth pairing request will appear. Click pairing, and once pairing is successful, the phone will automatically connect to the host.

# 5.1 Multimedia List and Audio Playback

Select the media list to display



Click the button to scan the files in the USB drive

Click to play the selected media file



Click to switch order /random play

Click to show /hide lyrics

Click to play the previous song

Click to play the next song

Clicking will bring you back to the media list

Click to switch between loop/single playback

Click to switch playback/pause status

Click to open the equalizer

## 5.2 Video and image playback

Click on the playback bar to quickly redirect the video



Click to switch between sequence/random

Click to play the previous song


Click to play the next song

Clicking will bring you back to the media list

Click to switch between loop/single playback

Click to switch playback/pause status

Click to open the equalizer



Click to switch between sequence/random

Click to rotate the image

Click to switch playback/pause status

Click to adapt the image to the screen

Clicking will bring you back to the media list

Click to play the previous picture

Click to play the previous picture

Click to fill the screen with images

# 5 Multimedia function operations

The multimedia function interface includes music function interface, video function interface, and image function interface.

1.The formats that can support audio playback include: MP3, WMA, OGG, WAV, AMR, APE, FLAC, M4A.

2.The formats that can support video playback include: MP4, MKV, ASF, 3GP, MPG, AVI, M4V, MOV, AVI, FLV, F4V, WMV, RMVB.

3.The formats that can support image playback include BMP, JPEG, PNG, and GIF formats.


If the selected file cannot be played, it will automatically switch to the next playable file.

The platform cannot be compatible with all USB drives. Due to the different standards of different brands and manufacturers of USB drives, some USB drives may not be able to play.


# 6 Calendars

Display the currently selected date, click to enter the year view

Clicking will return to the current date



Click on the optional date and swipe left and right to switch months




Swipe left and right to switch years, click to enter month view

# 7 Mobile phone interconnection



Click on the main interface to enter the mobile internet interface

- 1.Supports both Android and Apple phones simultaneously.
- 2.You can scan the code to connect, or use a data cable to connect your phone and car's USB port (Android phones require debugging mode to be turned on)
- 3.Only when the car is connected to Bluetooth can the sound be played through the car.
- 4.Features include navigation, music, mirroring, TV, and phone



## 8 Air conditioning



Click on the second page of the main interface to enter the air conditioning interface.


1. When there is a change in air conditioning information, it will automatically jump to the air conditioning interface.

2. If there is no operation in the air conditioning interface for 7S, it will automatically jump out of the air conditioning interface.




# 9.1 System Settings

After connecting to the network, when the automatic synchronization network time switch is turned on, the network time will be automatically synchronized. When manually setting the time and synchronizing GPS time, the automatic synchronization network time will be turned off



Synchronizing GPS time, selecting the corresponding region will synchronize the time of the corresponding region


Manually setting time/date



Time selection in 12/24 hour format


Language options: English, Spanish, Chinese, French, German, Spanish, Korean, Burmese, Vietnamese

Adjustable media volume, call volume, navigation volume, and button volume, with a range of 0-30



The input method can be either Google Input Method or System Input Method

## 9.2 Display settings and network settings




Select the display content of the screen shutdown interface

WiFi list, click to connect, forget, and other operations

Optional day/night mode

The brightness is divided into 10 levels and can be adjusted by dragging. When turning on the small light, the default brightness is 8

WiFi switch, entering the mobile internet will automatically turn on WiFi




## 9.3 Sound Effect Settings

Click to select preset values




Drag to adjust low/medium/high tones, ranging from -7 to 7

Click to select preset values, including Standard, Pop, Rock, Jazz, Classic, and can also be customized




## 9.4 Sound Field and Background

Drag the square to adjust the sound field, with the square centered by default




Click to return the block to its default position



You can click on any image to replace the background

## 9.5 System Upgrade and Factory Reset


Display OS/APP/MCu/Bluetooth version information and UUID



Click to upgrade OS and APP

Click to upgrade MCU

Click to upgrade Bluetooth



Click to restore factory settings, the data set by the car will be restored to default, and the car will restart

## 9 Settings




Click on the main interface to enter the settings interface

# 10 car control settings



You can click  on the second page of the main interface to enter the car control settings interface



When the switch is turned on, the AEB function is activated. Confirmation is required to turn off the switch, and after confirmation, the AEB function can be turned off

When the switch is turned on, the rear AEB function is enabled. Confirm when turning off the switch. After confirming, you can turn off the rear AEB function

Turn on the switch, turn on the front and rear radars. Turn off the switch. Turn off the front and rear radars

Turn on the switch, the rearview mirror will automatically fold. Turn off the switch, the rearview mirror will not automatically fold

Turn on the switch to activate the lane keeping function. Turn off the switch to deactivate the lane keeping function

#### FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Reorient or relocate the receiving antenna.
- Reorient or relocate the receiving antenna.
- Consult the dealer or an experienced radio/TV technician for help important announcements

#### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.