

Maintenance

- Clean your Strapless before and after each use with an antibacterial toy cleaner, or warm water and antibacterial hand soap
- Air dry or towel dry thoroughly before storing
- To prolong the life of your Strapless, store away from heat and sunlight, and away from other silicone toys
- Use water-based lubricant with this toy. Silicone-based lubricant may damage the toy.

Warranty Details

- All Bellesa products come with a 1-year warranty from the date of purchase
- This toy is designed as a novelty only, not as a medical device. We don't recommend using it for any other purpose.
- If you experience any issue with your product, please email care@bellesa.co with your order number and a video of the issue.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Strapless


by Bellesa



boutique
bellesa

Controls

To connect your Strapless to its remote, hold down the circular power button on both the remote and toy to sync.



How to Operate Toy

- To power on/off the toy, press the power button for 3 seconds
- To control functions A and B, quickly press the power button. To pause these functions, quickly press the power button twice
- To control function C, quickly press the vibration button (below the power button). To pause this function, quickly press the vibration button twice

How to Operate Remote

- To power on/off the toy, press the power button for 3 seconds
- To control functions A and B, quickly press the remote's power button. To pause these functions, quickly press the remote's power button twice
- To control function C, quickly press the vibration button (below the power button). To pause this function, quickly press the vibration button twice

Specifications

- 5 vibrations modes
- 100% waterproof
- USB rechargeable battery
- CR2032 remote battery included
- ~2 hours of charge time; ~45 minutes of play time
- Size: 9" x 1.5"; Weight: 285g

Charging

- Charge toy before use
- To charge, fully insert the charger into the charging port on the backside of the toy above the control buttons
- During charging, the LED light will flash. When fully charged, the LED light will stop flashing and remain lit
- When the battery level is below 10%, the power light will quickly flash