


封面  
90mm

# User Manual

## Model: MK358



Note: Please read the manual carefully before using.

EN

Made in China

### Preface:

Dear customer, thank you for purchasing our products. In order to have a better understanding of the product, please read this user manual carefully before using. Have a nice experience.

### Product Warranty Service:

1. Thank you very much for your purchase. Hope it can bring a comfortable experience. We provide 12 Months Warranty.
2. If you have any questions about products please contact our customer support directly via our Email.

### EDJO Team:

Service Email: [Service@sz-deying.com](mailto:Service@sz-deying.com)

### You will receive:

① Wireless Keyboard X 1	② Wireless Mouse X 1
③ USB Receiver X 1	④ User Manual X 1

### Notice:

1. When not used for a long time, it's recommended to turn off the power to prolong the battery life of the keyboard and mouse.
2. Do not use liquid to clean the keyboard directly. Clean the keyboard with alcohol or similar volatile disinfectant.

EN1-

### Electrical Specifications

#### 2.4GHz Wireless Keyboard Parameters

Number of Keys	110 Keys
Working Frequency	2.4GHz
Key life	10 Millions Strokes
Operating Current	3.0V = 2mA
Working Distance	Within 10 meters
Compatibility	95/98/2000ME XP Vista Win7 Win 8 Win 10 above Mac OS
Sleep Mode	Without used for 10 min
Wake up Button	Any buttons
Dimensions	17.09 x 5.47 x 0.86 inches
Weight	1.16 pounds
Material	ABS

#### 2.4GHz Wireless Mouse Parameters


Number of Keys	4 Keys
Mouse DPI	800-1200-1600
Initial DPI	1600 DPI
Sleep Mode	Without used for 10 min
Wake up Button	Any Button
Operation Voltage	DC 1.5V
Current Dissipation	<16mA
Dimensions	4.15 x 2.36 x 1.14 inches
Weight	0.11 pounds

EN2-

### How to connect


**Step 1:** Find the wireless mouse and keyboard and one Nano receiver in the box.

Please note that USB receiver is stored in the battery compartment of the mouse, which can be found by opening the mouse lid.




EN3-

### Step 2: Open the battery cover of the keyboard



**Step 3: Insert the battery. (2xAA batteries)**  
(Please check the positive and negative poles of the battery before inserting.)




EN4-

**Step 4: Turn on the power switch.**



**Step 5: Insert the battery.(1xAA battery)**



**Step 6: Take out the USB receiver.**  
NOTE: The USB Receiver stored in the battery compartment of the mouse.



**Step 7: Plug the USB receiver to your computer.**

EN5-

### Function Keys:



① Num Lock indicator  
The Num Lock indicator will turn Green when Num Lock is activated.

② Caps Lock indicator  
The Caps Lock indicator will turn Green when Caps Lock is activated.

③ Power indicator  
Low battery warning: The Power indicator will turn Red, the light flashes slowly for 5 seconds (one flash per second).

### Function Keys:

①	Screen Brightness(-)	Fn+ ① =F1	②	Volume(+)	Fn+ ② =F7
①	Screen Brightness(+)	Fn+ ① =F2	②	Mute	Fn+ ② =F8
②	My Computer	Fn+ ② =F3	②	Previous Track	Fn+ ② =F9
②	Home Page	Fn+ ② =F4	②	Next Track	Fn+ ② =F10
②	Music	Fn+ ② =F5	②	Play/Pause	Fn+ ② =F11
②	Volume(-)	Fn+ ② =F6	②	E-Mail	Fn+ ② =F12

EN6-

### Keyboard Instructions:

Power supply instructions: Switch the power to the ON position, the power indicator light is red, indicating successful startup. If the power indicator keeps flashing red light during use, it means that the battery is low and need to replace battery.

Keyboard connection method: Take out the USB receiver and plug it into the computer's USB port to connect it.

### Mouse Instruction

1. Do not put this optical mouse on the mirror/glass or uneven surface, which will seriously affect the function of the mouse.
2. Please keep this wireless Mouse away from sources of strong interference, such as: household microwave ovens and so on.
3. Please clean the Mouse with small amount of anhydrous alcohol by wiping when there is dirt, do not put the Mouse fully into liquid.
4. When you use the product, if the cursor does not move or bad behavior, please check your mouse or keyboard Electricity is sufficient.

EN7-

### Troubleshooting

#### Unable to connect the device

First, Please install batteries in the keyboard and mouse, unplug the receiver, restart the computer, and re-plug the receiver. If it can't be connected, please perform the following actions to fix it.

#### 1. Keyboard can not be connected

Switch on the keyboard, press the + .

Put the keyboard at 10 cm from the receiver for pairing.

Plug the 2.4GHz USB receiver into the computer within 10 seconds.

When the connection indicator is off, the keyboard pairing succeeds.

#### 2. Mouse can not be connected

Plug the receiver into the computer and turn on the mouse.

Put the mouse at 10 cm from the receiver for pairing. Press and hold the left button, right button and scroll wheel of the mouse for more than 3-5 seconds to pair successfully.

#### Keyboard typing delayed/not working

1. Make sure there is no 2.4GHz device (e.g. router) nearby to interfere with the connection.

2. Make sure the keyboard and mouse batteries are good.

3. Make sure there is no full metal case that may block the signal.

4. The computer is running too many tasks and the CPU memory is full to handle the signal from the receiving end.

EN8-

90mm

90mm

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.