

# WiFi 摆头机摄像头

产品型号: TY-01



使用说明书

## 1. APP 下载及安装

使用微信/浏览器等,扫描二维码下载应用并安装;

## 2. APP 连接



APP 图标: “联了么/Linkemo”

- (1) 打开 APP 并注册登录;
- (2) 打开手机设置连接 2.4G wifi 并打开手机蓝牙;
- (3) 进入配网模式

a. 上电开机后,长按 5 秒复位键直到蓝色指示灯快闪进入配网模式;

蓝牙配网:在 APP 中点击添加设备自动扫描设备,直至扫描到设备后(图 1),点立即绑定对应设备点击下一步

(图 2),添加成功后蓝色指示灯长亮,可自定义设备名称(图 3)即添加成功。

设备名称




图 1

图 2

图 3

\*若长时间添加不上设备需长按 MODE 键

5 秒重新进入配网模式

AP 热点:在手机设置中打开 wifi 设置,选择 LLM\_ 开头的名称点击输入密码:12345678 并连接,连接成功后打开 APP,(图 4)即完成连接可点击查看实时直播视频



### 注意事项

AP 热点:

1. 不能远程监控视频画面,每次需要观看时手机靠近摄像机 10 米左右(空旷距离无遮挡);
2. 手机设置里面连接 LLM\_ 开头的 Wifi 后打开 APP 观看;
3. 连接摄像机 Wifi 期间,无法正常上网是正常的断开连接的 Wifi 即可恢复。

蓝牙配网:

1. 摄像机距离路由器 Wifi 不能超过 5 米;
2. 不能使用带有 5G 名称的 Wifi;
3. 尽量不要靠近金属门安装(会影响 Wifi 信号缩短连接距离);
4. 确保摄像机接通充电电源;
5. 安装完成请撕下镜片保护膜再使用。
6. 输出电压: AC120v

# WIFI moving camera

Product model: TY-01



[Instruction Manual](#)

## 1. Download and Install the APP

Using WeChat/browser, etc., scan the QR code to download and install the APP;



APP icon:Linkemo

## 2. APP Connection

- (1) Open the APP, register and log in;
- (2) Open the mobile phone settings to connect to 2.4G WiFi(wireless fidelity) and turn on the mobile phone Bluetooth;
- (3) Enter the distribution network mode
  - a. After powering on the device, press and hold the reset button for 5 seconds until the blue finger The indicator blinks quickly to enter the distribution mode.

Bluetooth distribution network: Click "Add Device" in APP to automatically scan devices until the device " is scanned (FIG.1), click "Bind Now" corresponding device and click "Next" (FIG. 2). After adding the successful blue indicator lights on, you can customize the device name (FIG.3), which means successful addition.




FIG.1



FIG.2




FIG.2

\* If the device cannot be added for a long time, long press the MODE key for 5 seconds to re-enter the distribution network mode

AP Hotspot: Turn on wifi Settings in your phone's Settings

Select a name starting with LLM\_ and click Enter

Password :12345678 (Figure 4) and connect, the connection is successful

Open the APP (Figure 5) and click to view the real-time connection

Live video




Figure 4




Figure 5

Matters Needing Attention

AP Hotspot::

1.Unable to remotely monitor video footage.

Every time you need to watch, your phone is about 10 meters closer to the camera (open and unobstructed)

2.Connect to LLM\_ in the WiFi and then open the APP to watch

3.During the connection of the camera's WiFi, it is normal to not be able to access the

internet normally. Disconnect the WiFi and it can be restored

Bluetooth distribution network:

- 1.The camera distance from the router Wifi shall not exceed 5meters;
- 2.Wifi with a 5G name cannot be used;
- 3.Try not to be close to the metal door installation (it will affect the Wifi signal to shorten the connection distance);
- 4.Ensure that the camera is connected to the charging power supply;
- 5.When the installation is completed, please remove the lens protective film before use.
6. Output voltage: AC120v

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **RF Exposure Information**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.