

名称：N20说明书 尺寸：68x105mm(展开尺寸：408x105mm) 材质：80g书纸

正面

Quick Start Guide

Smart Label Printer

N12



01 Package Contents

 Smart Label Printer *1

 Label Paper Roll *1

 USB Type-C Cable *1


 Quick Start Guide *1

02 Installation

01 Slide left to open the lid.



02 Insert the print paper into the compartment with the printed side facing down, and ensure the first label paper extends out of the tear-off opening.



Tear-off Blade

Print Side

Note: The printed content is below the label

Danger ! Beware of shape blade when the paper compartment is open.

03 App Download

01 Before using the printer, please install the "Nada Print" app from Google Play or the App Store.

 Nada Print

 Nada Print

More information available on the "Nada Print" app.

04 Connecting and Printing

01 Turn on bluetooth on your phone.



02 Long press the power button to start the machine.



03 Open the "Nada Print" app.



04 Tap [Start Connecting].



05 Grant permissions.



06 Waiting for the printer to be connected.



07 In the searched printer list, click N12 to connect.



08 Connected.



背面

08 Edit your first label, and tap [Print] after you finish editing.



The default label size for the first edit is 15mm * 40mm.

09 Print Successfully.



05 Basic Functions

Function	Operation
Switch on	Hold down the Power button for 3 seconds.
Switch off	Hold down the Power button for 3 seconds when the device is on.
Print	Press the Power button once when the device is on.
Print a test page	Double-press the Power button when the device is on.

06 Specifications

Product	Label Printer	Model	N12
Dimensions	109 × 77 × 22mm	Weight	135g
Charging Time	3-4 hours	Input	5V DC, 2A
Battery Capacity	1200mAh	Printing Method	Thermal printing
Printing Resolution	203dpi	Printing Width	12mm
Connectivity	Bluetooth	Charge	Type-C
Transmit Power	4dBm(Maximum)	Operating Temperature	0°C-40°C

07 Safety Precautions

Please read all the instructions and warnings in this manual carefully before using this product to ensure the proper functioning of the device and your safety.

*Warnings



Don't disassemble the product without authorization. Unauthorized products can not be returned or exchanged.



Do not wipe the product with corrosive chemicals or cleaning agents.



Do not use the product near places with flammable products such as gas stations or fuel depots.

1. Please keep the product and accessories out of the reach of children or they must be used under the supervision and guidance of a guardian;
2. Turn off the power immediately when water gets into the product;
3. Turn off the power immediately in case of any product malfunction;
4. If you want to use a power adapter, always use one that is safe, regulatory-compliant, and compatible;
5. Do not disassemble the product to replace the battery. Improper operation may cause an explosion;

08 Related Statements

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Notice: If the device cannot be turned on, please charge for one hour

Zhuhai Jiuyin Technology Co., Ltd

Support Email: xxxxxxxx

Official Website: xxxxxxxx

Address: Room 302, Building 2, No. 90 Chuangzhi Road, Tangjiaowan Town, High tech Zone, Zhuhai, Guangdong Province, China