

 <h1 data-bbox="384 509 698 605">INSTRUCTION MANUAL</h1> <p data-bbox="399 628 682 652">Intelligent Anti-loss Device</p> <p data-bbox="480 779 608 827">GTAG Global locator</p>	<h2 data-bbox="759 314 1006 338">INSTRUCTION MANUAL</h2> <p>The device is powered on and enters the pairing state.</p> <ol style="list-style-type: none"> When using it for the first time, please install button batteries on the product. Hearing a "drop" sound indicates that the product has entered pairing mode. The button function of this product. <table border="1" data-bbox="765 485 1073 774"> <thead> <tr> <th>Status</th><th>Key</th><th>Function</th><th>Buzzer</th></tr> </thead> <tbody> <tr> <td rowspan="2">sleep</td><td>click</td><td>wake up</td><td>"Di Di" sounds</td></tr> <tr> <td>double-click</td><td>advanced settings Status</td><td>"Di" sounds</td></tr> <tr> <td rowspan="2">power off</td><td>five click</td><td>power off</td><td>"Di" sounds for one second</td></tr> <tr> <td>press for 5 seconds</td><td>power on</td><td>"Di Di" sounds</td></tr> <tr> <td rowspan="4">power on</td><td>press for 5 seconds</td><td>Read SN</td><td>"Di" sounds</td></tr> <tr> <td rowspan="3">advanced settings</td><td rowspan="3">press for 8 seconds</td><td>The sixth second "Di Di Di" sounds</td></tr> <tr> <td>The third second, "Di Di" sounds</td></tr> <tr> <td>The eighth second, "Di Di Di Di" sounds</td></tr> </tbody> </table> <p>※Rotate the back cover counterclockwise, open the battery cover, take out the CR2032 button battery that comes with the package, install the CR2032 button battery, then slide the battery cover clockwise to fully close.</p>	Status	Key	Function	Buzzer	sleep	click	wake up	"Di Di" sounds	double-click	advanced settings Status	"Di" sounds	power off	five click	power off	"Di" sounds for one second	press for 5 seconds	power on	"Di Di" sounds	power on	press for 5 seconds	Read SN	"Di" sounds	advanced settings	press for 8 seconds	The sixth second "Di Di Di" sounds	The third second, "Di Di" sounds	The eighth second, "Di Di Di Di" sounds	<h2 data-bbox="1140 314 1477 338">FIND AND BIND YOUR PRODUCT</h2> <p>※ Please make sure that you have an iPhone, iPad, or iPod touch with iOS 14.5 or iPad OS 14.5 or later and two-factor authentication enabled.</p> <ol style="list-style-type: none"> Turn on 【Bluetooth】 on your Apple device, and go to 【Settings】 - 【Privacy&Security】 - Turn on 【Location Services】 and swipe down and tap 【FindMy】 to allow access to the location and turn on 【Precise Location】. Go back to main screen of the apple device,click the 【FindMy】 app, and the select the 【Items】 tab. Click 【+】 , and then click 【Add Other Items】 . Find the item name "GTAG", click 【Connect】,fill in the "Name Item" custom product name, and click 【Continue】 ."Choose an emoji",click to continue to show"This item is linked to your Apple ID",please check that the email address and mobile phone number are correct, then tap 【Agree】 , and then tap 【Finish】 to add successfully. 	<h2 data-bbox="1522 314 1769 366">VIEW LOCATOR LOCATION ON THE MAP</h2> <p>1.Open the Find My app, then click the Items tab. Select the locator you want to locate in the Items list. If the locator is within the coverage area of your device or the Find My network where the locator was recently detected, you can see it on the map. Below its name, you'll see the location and time of the update.</p> <p>2. If the base station is not within range of your device or any device on the Find My network, you can see its last known location and time. If you want to receive notifications when the tracker comes within range of your device or can be detected by the Find My network, please turn on [Notify when found] under [Notifications].</p> <h2 data-bbox="1522 632 1686 655">PLAY A SOUND</h2> <p>Open the 【Find My】 app, select the 【Item】 tab,click the product you need to use, the mobile phone interface will display the 【Play Sound】 button, click the 【Play Sound】 button, and then you will hear a piece of music,indicating that the product can be used normally.</p> <p>※When the device and the product are out of the distance, the 【Find My】 app cannot connect to the product and the product cannot play sound normally.</p>
Status	Key	Function	Buzzer																											
sleep	click	wake up	"Di Di" sounds																											
	double-click	advanced settings Status	"Di" sounds																											
power off	five click	power off	"Di" sounds for one second																											
	press for 5 seconds	power on	"Di Di" sounds																											
power on	press for 5 seconds	Read SN	"Di" sounds																											
	advanced settings	press for 8 seconds	The sixth second "Di Di Di" sounds																											
			The third second, "Di Di" sounds																											
			The eighth second, "Di Di Di Di" sounds																											

<h2 data-bbox="384 955 586 1008">PREVENT UNAUTHORIZED TRACKING</h2> <p>1.If any of the locators and other Find My network accessory products leave their owners and move with you for a period of time, you can send a notification to your Apple through the Find My app device, and be able to observe the walking path as you move and in time.</p> <p>2.These features are designed to prevent people from tying to track you without your knowledge, so if you feel your safety is at risk, contact your local law enforcement officer.</p> <p>※This product has a function to prevent unauthorized tracking, and should not be used to track others, nor should it be used to track property that does not belong to you. In many countries and regions around the world, it is an offence to use these products to track someone without their consent.</p> <h2 data-bbox="384 1310 608 1333">REPLACE THE BATTERY</h2> <p>1.Rotate the back cover counterclockwise, open the battery cover.</p> <p>2.Remove the battery, replace it with the prepared new battery "CR2032 3v" and install the battery.</p> <p>3.After installing the battery, you can hear the product make a "drop" sound, indicating that the battery has been successfully replaced. Then slide the battery cover clockwise to fully close it.</p>	<h2 data-bbox="759 955 923 979">PRODUCT RESET</h2> <p>1.When you need to replace/unbind the product bound to your Apple device, in the 【Find My】 app, in the item tab, find the product that needs to be unbound,slide to the bottom of the page, click 【Remove Item】 ,click 【Remove】 , and click 【Remove】 again to confirm that the product is no longer available in the 【Item】 tab.</p> <p>2.Press the switch twice in a row, and when you hear a "Di Di" sound, press and hold for 8 seconds (at 3 seconds, there will be "Di Di" sound; at 6 seconds, there will be "Di Di Di" sound; at 8 seconds, there will be "Di Di Di Di" sound), and then restore the factory settings.</p> <p>3.If you are unable to use the base station, make sure the product is ready to be set up, remove and replace the battery, place the base station close to the portable device you want to connect to, or reset the product before attempting to connect the base station.</p> <p>※If you physically reset the product before unbinding, it will take longer for the Apple device to remove the product.</p>	<h2 data-bbox="1140 955 1298 979">SPECIFICATION</h2> <p>MODEL: GTAG Battery: CR2032 Bluetooth version: BLE 5.3 Material: PC+ABS Size: 32x32x9.5mm Weight: 8g±2g Compatibility: Compatible with Apple device only,iPhone and iPod touch models with iOS 14.5 or later; iPad models with iPad OS 14.5 or later, iMac and MacBook with mac OS 12.5 or later.</p> <h2 data-bbox="1140 1191 1298 1214">FCC WARNING</h2> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and</p>	<p>used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>FCC ID: 2BM4J-GTAG</p>
--	--	---	---