

**MJ-08**

Digital Players | Marker Lyrics  
Karaoke Speaker



# user manual

- Please read this manual carefully before using the product and follow the instructions for proper operation of the product.
- Please keep this instruction manual in a safe place for reference.
- Warm Tip:
  - We are constantly working to improve the quality and functionality of our products, and product designs are subject to update without notice.
  - The instructions have been carefully checked and we are not responsible for the consequences of any errors.
  - Purchase is subject to the physical specifications, schematic diagrams are for reference only, the Company reserves the right to interpret the contents of this information.
  - Non-professionals should not disassemble the machine by themselves to avoid unnecessary damage to the machine. It must not be left in an overheated or humid environment.
  - When the machine is not used for a long time, please charge the machine once a month to ensure that the battery power is sufficient and the machine can be used normally when it needs to be used!

# Functionality Profile:

- 1. The TF card is compatible with multiple formats of music playback.
- 2. High-speed wireless 5.3 Bluetooth music playback.
- 3. Lyrics are displayed during playback on Bluetooth connection.
- 4. Dual wireless microphones, sing whenever and wherever you want.
- 5. The wireless microphone comes with one-touch acoustic cancellation.
- 6. The wireless microphone has a variety of voice modes (Goddess Mode / Uncle Mode / Monster Voice / Baby Voice / KTV).
- 7. Cool seven-color ambient lighting.
- 8. Clock display, connected to Bluetooth time is automatically synchronized.
- 9. 5.2MM high quality speakers x 2PCS.
- 10. Built-in 2400MAH dual-component large battery, working time 6-8 hours.

# Bluetooth Speaker Features



- ① : Short press phantom light effect switching, long press phantom light sleep setting.
- ② : Short press to toggle lyrics/time display interface, long press for white noise sleep setting.
- ③  : Short press ~ to switch Bluetooth/TF card playback mode (Note: default Bluetooth mode at power on) Long press ~ to force clear Bluetooth pairing.
- ④  : Short press ~ volume down, long press ~ previous song.
- ⑤  : Short press ~ volume up, long press ~ next song.
- ⑥ : Long press ~ on/off, short press ~ pause/play.
- ⑦ Lyrics/time display.
- ⑧ Colorful ambient lighting.
- ⑨ DC 5V charging.
- ⑩ TF card socket.



## Microphone Functions Introduction

- ① : Long press to turn on/off, short press to pause/play music
- ② : Short press ~ microphone volume up, long press ~ music next track
- ③ : Short press ~ microphone volume down, long press ~ music up one song
- ④ : Short press ~ Switch Bluetooth/TF card, Long press ~ One cancellation of the original sound on/off
- ⑤ : Short press ~ to switch modes (Goddess Mode / Uncle Mode / Monster Tone / Doll Voice / KTV)

Note: Red light for charging, green light for full charge, blue light for good pairing (blue light flashes slowly when waiting for pairing).

### Bluetooth connection method

- (1) Long press the speaker to turn it on, the power on is in Bluetooth mode by default.
- (2) Cell phone search for MJ-08 click on the connection, Bluetooth pairing to select the authorized items, (do not select the function will be restricted can not be used normally) long press M can be forced to clear the Bluetooth pairing.

Note: If the lyrics are not displayed, please check whether the song has lyrics. If so, please go to the settings of the app playing the song to find “external device bluetooth lyrics” or “car bluetooth lyrics” and so on to turn on the option.

### TF card playback

- (1) Insert a TF card with music files into the speaker to play.

### Light/white noise sleep setting

- (1) Press lightly  $\textcircled{Q}_1$  key to switch the phantom lighting effect mode, long press to enter the phantom lighting sleep time setting (RGB 30/60/90/120/OFF).
- (2) Long press  $\textcircled{Q}_2$  key to enter White Noise and enter the White Noise sleep time setting (L0d 30/60/90/120/OFF) (the White Noise sound source must be stored in the TF card and inserted correctly into the stereo TF card slot).

# fault resolution

trouble spot	Causes and solutions
Bluetooth pairing not successful	*Bluetooth pairing is unsuccessful *There are too many Bluetooth devices in the neighborhood, causing searching difficulties, turn off other Bluetooth devices and search again.
Small or distorted sound	*Adjust the volume to the right level.
Bluetooth music playback appears broken	* Whether it is beyond the effective connection distance of the speaker (ten meters effective distance). *There is an obstacle between the speaker and the cell phone tone.

Note: If the above method fails to solve the problem, please contact the merchant, do not disassemble and repair the machine by yourself, otherwise no warranty.

# Charging Instructions

\* Please use a power adapter with standard or equivalent parameters!

\*Products in the use of low power or insufficient power, the speaker will issue a low-power tone after the automatic shutdown, at this time should be charged as soon as possible to the speaker, charging until the charging indicator green light, indicating that the battery is full.

\*It is recommended to charge the machine once a month when not in use for a long period of time.

\* The charging cable should not be squeezed, pulled, bent, knotted, hung with heavy objects or stepped on to prevent the insulation of the charging cable from being damaged, resulting in electric shock.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.