



Instruction manual

Model: T25
Describe Wireless headset

1. Product appearance



2. Product description



Charging bay light display

3. Product parameter

Transmission distance: ≥10 m
Power pool capacity: 40 mAh
Duration: about 5 hours (headphones)
Charging time: about 1.5h (headphones)
Input Specification: 5V=30mA

Charging Case Specifications
Power pool capacity: 300 mAh

Charging time: about 2 hours

Charging parameters: 5V=300mA

Definition of charging bin lamp:

1 Charging compartment indicator:	White
2 Earphone charging:	White light is always on, full of lights out
3 Charging compartment charging:	White light flashes when charging, full white light often bright

4. Definition of sound

Project

Prompt tone

Volume tone

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

5. Operation Instructions

Project	Headset operation method
1 Switchgear	Take out the earphones from the charging bin to automatically turn on the left ear, or long press the button for 25s to turn on the left ear, or long press the button for 25s to turn on the right ear, or long press the button for 25s to turn off both ears can operate
2 pairing	Open the phone, find the matching name of the corresponding headset "T25", click Connect
3 Disconnected from cell phone	Disconnect / ignore the device and disconnect the headset
4 Answer the phone	Click on either side of the headset (or button) while talking
5 Hang up the phone	Click on either side of the headset (or button) during incoming call
6 Refused call	Hold either headset for 25s (or a button)
7 Play music	
8 Previous song	Double click the left earphone button
9 Next song	Double click the right earphone button
10 Volume Plus	Press the left earphone button three times 11. Volume reduction: Press the right earphone button three times
11 Pause/Play	You can press the button on either headset
12 Voice wake	Press and hold for two seconds to release the wake-up

Android OR Code Download	IOS Code Download
--------------------------	-------------------

Before using the translation headset, please follow these steps:
Scan the QR code of the manual/packaging box to download and install.
In all major mobile APP store, search for "one-click" app.
Make sure your headphones are fully charged.

6. "One-Click" Instructions

1. Prepare before use
First scan the QR code or the APP store to download the app

2. Use the procedure
Open the "One-Click" app and tap on "Translation Earbuds" to access the main interface. Click "Disconnect" in the upper right corner of the "Translate Earphones" interface, find the earbuds name corresponding to your earbuds in the "Settings of the mobile phone system and connect it, and return to the "Translate earbuds"

3. Setting
Go to the app's main interface and tap the icon in the top-right corner to open "My profile". In the "Settings" configuration page, select "System language" (Android adaptive mobile phone system language).

4. Connecting to the network
First of all, in the case of connecting to the network, download the source language and target language required for translation in advance, wear headphones to enter the offline translation, and click the microphone button to start speaking.

5. Translation
Depending on your needs, the app offers three translation modes. Select a mode by tapping its name, and follow the on-screen instructions to proceed.

6. Touch Mode
First of all, in the case of connecting to the network, download the source language and target language required for translation in advance, wear headphones to enter the offline translation, and click the microphone button to start speaking.

7. Audio/video call translation
To speak, touch the earbud and wait for a "beep" sound before starting. Both users will hear the translation simultaneously. When the other person wants to speak they can touch their earbud and wait for the "beep" before beginning.

8. Speaker Mode
Fully charge the earbuds before use for the first time. Make sure that the connection is successful. Open a music APP, check whether the earbuds are in the left or right ear. Connection: Place the translation earbuds into the charging base, then remove and reinsert them. Ensure the earbuds are charged correctly, indicated by the translation earbuds lighting up. Once charged, take them out, wear both earbuds and search for the earbuds on your phone's settings.

9. Photography
Click the "Audio/Video Call Translation" function, users can choose video call translation or voice call translation according to their needs in this interface, set the language of both parties, and then click Invite friends to call, share the link to friends to translate the audio and video call with friends as shown.

10. Free talk Mode
You tap/double tap the headset (or tap the bottom half screen of the phone) to start talking, and then the phone will play the translated content. Tap the top half screen of the phone, indicating that the other person is talking into the phone, and you will hear the translated content from the earbuds.

11. Let language have no borders and make communication easier
The translation results can be displayed in two ways: graphic comparison and text comparison. You can choose according to your preferences, and it can be used for taking photos of tourist signs, ordering menus, learning and other scenes.

12. Note: Offline translation, audio/video call translation, photo translation (online/offline), are value-added service items, and users can pay for the service based on their individual needs.

13. Product warranty card
Warranty terms
1. To purchase this product, please fill in the card carefully and read the following warranty terms carefully to ensure that the product is guaranteed.
1) Users should carefully keep this card when purchasing products, and the seller should seal it.
2) This warranty card shall be provided at the time of warranty.
3) The information added in this warranty card is true, otherwise it will be invalid.
4) The product warranty period is one year. During the warranty period, if the product fails due to poor quality or manufacturing problems of the original components, the company will provide free maintenance and parts replacement.
2. The product is damaged and cannot be used normally due to the following reasons, which is not within the scope of warranty:
1) Damage caused by use in violation of the instructions.
2) Any damage caused by accident or use.
3) Repair, modification or break product sealing sticker not approved by the company.
4) Aging, breakage or scratch product surface shell.
5) After the warranty period expires, users can still get the maintenance services provided by our company, but they have to pay corresponding fees.

14. Product warranty card
Warranty terms
1. To purchase this product, please fill in the card carefully and read the following warranty terms carefully to ensure that the product is guaranteed.
1) Users should carefully keep this card when purchasing products, and the seller should seal it.
2) This warranty card shall be provided at the time of warranty.
3) The information added in this warranty card is true, otherwise it will be invalid.
4) The product warranty period is one year. During the warranty period, if the product fails due to poor quality or manufacturing problems of the original components, the company will provide free maintenance and parts replacement.
2. The product is damaged and cannot be used normally due to the following reasons, which is not within the scope of warranty:
1) Damage caused by use in violation of the instructions.
2) Any damage caused by accident or use.
3) Repair, modification or break product sealing sticker not approved by the company.
4) Aging, breakage or scratch product surface shell.
5) After the warranty period expires, users can still get the maintenance services provided by our company, but they have to pay corresponding fees.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.