

Settings
Move to [Settings] icon, press [OK] button to enter into system settings. You will see the menu on the screen.

WIFI
When Wi-Fi enabled, you'll need to select your network's name and enter the password. An on-screen keyboard should appear if you're using the standard infrared remote control.

Ethernet
If you will use a network cable instead of Wi-Fi, please select this option (DHCP) instead.

Troubleshooting
Warning
Under any circumstances, never try to repair the device by yourself. It voids the warranty. If any issue occur, read the following instructions on how to troubleshoot the device. If you are unable to resolve the issue, please consult your dealer for help.

Problem	Solution
No signal on the TV	1) Check if the HDMI or AV cable is securely connected. 2) Check if you have selected the correct input source on your TV.
Can not turn on your Smart TV Box	1) Check if the power connector is completely inserted into the DC socket of your Smart TV Box. 2) Check if the power supply is stable. 3) Check if you have selected the correct input source on your TV.
Can not connect to network.	1) Make sure that the network cable is securely connected and the Ethernet works well. 2) Make sure that WiFi network is connected and the security key for the encrypted network is correct. 3) Make sure that you select the correct IP address settings.
Remote Control does not respond	1) Make sure that the batteries are good. 2) Make sure that the remote control and your Smart TV Box are within 8 meters. 3) Make sure that the remote control and your Smart TV Box are within 8 meters.
Smart TV can not display entire screen	Setup the screen display position of your Smart TV Box. Settings > Display > Display position

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

User Guide

X1PRO



Preface

Thank you for choosing our Smart Media Player. For your convenience and ease of use, we created this manual. Please read it as a reference on how to properly use TV box.

Disclaimer

We make sure to provide the most current information about the product. We do not guarantee the contents are fail-proof. We do not claim any implied guarantees concerning market value or suitability for specific purposes. The information written here are instructions for users to use the product correctly and maintain it.

We reserve all rights to amend, change or translate the user manual without prior notice. Thus, we recommend that you regularly visit our website to obtain the latest information.

Package Contents


NO	Picture	Name	Piece
1		Smart Media Player	1
2		IRremote control	1
3		Power Adaptor	1
4		HDMI Cable	1
5		User Guide	1

Note: Other controls are optional.

Specification

- Andivid 12
- Processor H618 Quad-Core ARM Cortex-A53
- GPU Quad-Core Mali-T760 MP2
- Memory GDDR3 2GB
- Internal Storage 64 GB EMMC
- Support Video Decoder: H.265 10bit up to H.265 Level 5.1 / 6.4Kx2K@30fps Up to 250Mbps
- Support audio formats: MP3,WMA, AAC,FLAC,etc
- Support photo formats: JPG,PNG,BMP,GIF,PNG
- USB2.0 x1,USB3.0 x1 (Hot Connectors) and SD/MMC card reader.
- Network: RJ45 10/100M Ethernet,Support 802.1ac, 2.4GHz/5GHz 2T2R Wi-Fi
- Composite/Audio-Video output, support all television
- Support all standard SD/HD/4K video output formats: 480i/p, 576i/p, 720p, 1080i/p, 4K
- HDMI Support 4K@60fps SupportHDMI Audio@1CH

Connection Diagram



HDMI connection

- a. Connect HDMI cable into the product interface, the other side into a TV set.
- b. Set the TV Output Display Settings to 720p or 1080p and then transduced to the corresponding TV HDMI Connector it video status.

A/V connection

If your TV have no HDMI connector. Don't worry you can connect your TV via A/V cable. Connect A/V cable into the product interface, the other side into a TV set.

Tip:
The pairing process should take about 15 seconds. If it fails, try these solutions:

- Move the remote control closer to the box.
- Replace the batteries in the remote control if they are low or dead.

成品110x205mm,正反印刷，对折再对折。折页，切成品。