




10.1" Smart Calendar Frame

Ver: 1.0

# User Manual



Model :VT01001A&VT01001B&VT01001C&  
VT01001D&VT01001E&VT01001F&VT01001G

	<b>Page</b>
1 . Contents of Box -----	3
2 . Product Features -----	4
3 . Overview -----	4
4 . Setup -----	5
5 . Getting Started -----	6
6 . FCC Warning -----	8
7 . Warranty -----	9

Thank you for choosing our product. If you have any questions, please feel free to contact our customer service at **support@vtimes.net.cn**


## 1. Contents of Box

Digital Calendar Frame × 1


Power Adapter × 1

Stand and Screw Kit × 1


User Manual × 1




Digital Calendar Frame × 1



Power Adapter × 1



Stand and Screw Kit × 1



User Manual × 1

Note: All pictures and illustrations in this document are for your reference only and may differ from the final product.

## 2. Product Features

### 1. Smart Calendar Hub

Switch views Day/Week/Month with a tap. Syncs with your phone's calendar and add family members to events.

\*Compatibility limitations on some Android models

### 2. Digital Photo Frame

Send photos/videos from phone to frame for slideshow displays. Automatic rotation & brightness adjustment.




### 3. Greeting Creator

Design custom messages on phone and share to frame. Use preset templates or create your own!

### 4. AI Art Studio

Generate unique artworks from text and picture prompts. Unlock creative styles with subscription.

## 3. Overview




- ① Power on/off button
- ② Lock button
- ③ Removable bracket
- ④ Wall-mounted hole
- ⑤ Loudspeaker
- ⑥ Reset slot
- ⑦ Micro USB
- ⑧ Micro SD
- ⑨ DC

## 4. Setup


### 1. Install the stand

Hook on the frame stand on the back. You can place the frame either in landscape or portrait (we recommend you place it in landscape during the first setup). You can also mount the frame on the wall with the Wall Mount Hole on the back.



### 2. Power on

Connect the Power Cable to your frame and plug the Power Adapter into the wall socket, the frame will enter the system in seconds.



## 5. Getting Started

### Download Vtimes Smart APP

Scan the code to download “VTimes Smart” APP. You can download it by scanning the product manual or going to the APP Store / Google Play market.



VTimes APP




Scan to Download

### Add device


Power On → Select device language → Review the Privacy Policy → Select a Wi-Fi network and connect → Choose time zone.




1. Select device language



## 2. Review the Privacy Policy



## 3. Select a Wi-Fi network and connect



## 4. Choose time zone.

**Note:** If your network is not visible, wait 30 seconds and refresh to check again.

Next, the device will display an instruction to assist you in adding it via mobile.

There will be two ways:


## 1. QR Code

In the VTimes App, tap the scan icon in the top-right corner.

Scan the QR code to add the device automatically.

## 2. Pairing Code

In the VTimes App, tap the icon in the top-right corner, navigate to 'Add Device', scroll down to the device list and select "Smart Calendar Frame". Tap "Pairing code binding", enter the pairing code shown on the device, and complete the pairing.



## 6. FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

## 7. Warranty

### What does this warranty cover?

The manufacturer of this product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions.

### How long is the limited warranty period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. What is not covered by this warranty? This limited warranty does not cover:

1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion.
2. Product that has been subjected to contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like.
3. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of manufacturer.
4. Product to the extent that the problem is caused by use with non-manufacturer accessories.
5. Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible.
6. Product purchased, used, serviced, or shipped for repair from outside the United States of America.
7. Product returned without a valid proof of purchase (see item 2 below).

### What must you return with the Product to get warranty service?

1. Return the entire original package and contents including the Product to the manufacturer service location along with a description of the malfunction or difficulty.
2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt.
3. Provide your name, complete and correct mailing address, and telephone number. Please retain your original sales receipt as proof of purchase.

## **Warning! Important Safety Instructions**

Please read the Safety and Maintenance Instructions before using your Vtimes Smart Calendar Frame. Applied operation procedures not specified in this user manual may result in shock, electrical hazards, or mechanical hazards.

1. Do not expose the product to direct sunlight and keep it away from heat register, or over a radiator and any heat sources.
2. The slots and openings on the back or bottom of the frame are provided for necessary ventilation. To ensure reliable operation of the Vtimes frame and to protect it from overheating, these slots and openings must never be blocked or covered. Do not place the frame in a confined space, such as a book case or built-in cabinet unless proper ventilation is provided.
3. Do not expose the frame to rain or place it near water (near kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.).
4. If you have just turned off the device by unplugging the power cord, wait 6 seconds before re-plug the power cord to ensure normal operation.
5. Use only the power cord provided by Vtimes. If the power cord is missing, please contact your local service center or authorized dealer.
6. If the digital frame accidentally gets wet, unplug it and contact your local service center or an authorized dealer.
7. To avoid the frame to severe vibration or collision.
8. Do not strike or drop the frame.

## **Important Maintenance Instructions:**

1. For frame is not in use for a long time, unplug the power plug.
2. Unplug the power cord while cleaning the frame with a slightly damp cloth. Do not place your hands or fingers on the LCD panel and lifting it by holding the frame edge. Wipe the screen with a dry cloth and do not use organic solvents (such as alcohol) or liquids containing ammonia to clean it.
3. If the frame gets wet or damp, wipe it clean with a dry cloth as soon as possible.
4. To maintain the best performance of the frame and ensure a longer service life, we strongly recommend using it in a location that meets the following temperature and humidity conditions.
  - Temperature: 0-40°C / 32-104°F
  - Humidity: 20-80% RH

## **Vtimes Smart Technology Co., Ltd**

Room 2104, Building 11, Tianan Yungu Phase II, Bantian Street, Longgang District, Shenzhen, Guangdong, China



Made in China