

RIICHI-STYLE (Board)

①Dice box rise sensor board (The dice box moves up and down, allowing tiles to be dropped into the table)	②Elevator sensor board •Place the tile on the EL (4 positions for returning the tile to its original position)	③Extrusion sensor board (return to home position sensor) 4 locations	④Count sensor board (Detects tiles and counts them. Pushes them out to the EL and returns them to their original position) 4 locations	⑤Dice board (Roll the dice, start the game, etc.)	⑥Control board (game selection)	⑦Main board
JT30 VER.2.05	SF01 VER:3.30	JT30 VER:1.03	SENS-001 REV.1	YB430 VER:1.02	KEY-5 VER.1.03	LX2300+ VER: 2.00
  	  	  	  	  	  	  