


自带线移动电源 MC502说明书

材质:80g双铜

成品尺寸:65*90mm，展开尺寸:260*90mm，3折痕，(公差±0.5mm)

<div><div>ARKEEP</div><div>Power Bank Manual</div><div>MC502</div></div>	<div>Read this manual carefully before use, and retain it for future reference</div> <div><div>Product Overview</div><div><div><div>Wireless Output</div><div>Type-C input/output</div><div>Battery level indicator</div></div></div><div>The button is not a power button. The power bank detects charging and discharging automatically. Safety: The power bank is provided with safety functions to prevent overcharging, over-discharging, overheating, and short circuits under any working condition. Efficiency: Supports a maximum of 20W fast charging.</div><div><div>Charging</div><div>1.The product can be charged by connecting a power bank through an adapter with the charging cable that comes with the product or the charging cable that matches the corresponding interface. 2.The indicator displays the current power level when charging, the charging finished when the indicator stops flashing.</div><div><div>Discharging</div><div>1.Using the USB cable of the corresponding interface to connect the digital product to realize the charging. 2. The corresponding indicator keeps lighting When charging digital products, and displays the remaining power of power bank.</div></div></div></div>	<div>3.When the power bank displays lower power, please charge it in time. 4.When the power bank is charged without load output, it will automatically be off within 60 seconds.</div> <div><div>Warnings</div><div>Improper use may result in battery failure, overheating, and even fire or explosion. To ensure your safety and minimize the risk of personal injury and property damage, please observe the following precautions: • This power bank is not a toy. Please keep it away from children. Do not let children use or play with this power bank to avoid accidents. • Make sure you use a charger that complies with the local safety standards • When charging this power bank, so as to prevent electric shocks or damage to battery. • Do not expose this power bank to pressure, impact, strong vibrations, or liquids. Any of these occurrences may lead to a short circuit or cause damage to the battery or its electrical circuit. When this happens, stop using the power bank immediately, and dispose of it in a proper manner. • When this power bank becomes swollen, deformed, starts to leak, or its capacity is significantly reduced, please stop using it immediately and dispose of it in a proper manner. • Do not charge or discharge this power bank in places where its heat dissipation may be affected, such as in your pants pocket, a closed bag, or on a bed or sofa. Make sure that the power bank is not covered by clothing, pillows, bedding, or other miscellaneous items during this process. • Do not disassemble, or expose this power bank to pressure, impact, strong vibrations, liquids, fire, and other heat sources such as stoves, heaters, or environments with ambient temperatures higher than 60°C (140°F). When it is hot, do not leave this power bank in a car or other place that is exposed to direct sunlight. • This power bank contains a lithium-ion battery. Do not open its casing under any circumstance to avoid baery damage or safety hazards. • Do not replace the baery by yourself. Replacing the baery with the wrong type may result in a failure of safety protection, causing an explosion or fire.</div></div>	<div><div>Fire:</div><div>• The battery pack subjected to extremely low air pressure during use, storage or transportation may result in explosions or leakage of flammable liquids or gases. • Do not dispose of batteries as household waste. Dispose of them safely as per local laws and regulations.</div><div><div>Precautions</div><div>• Please fully charge this power bank before using it for the first time. • Use qualified charger and charging cable. When charging the power bank or using it to charge other devices. • Do not leave this power bank unattended while charging, and unplug it from the power supply before going out or leaving it unattended for a long time. • Once this power bank is fully charged, or after it is used to fully charge another device, unplug the charging cable in a timely manner to prevent damage. • When the battery level is not displayed after pressing the button, it may be because the power bank is in protective mode. Try plugging in an external charger to restore the power bank. • When not using this power bank for a long time, please keep its battery level in the range of about 25~50%, and store it in a cool and dry environment. Avoid long-term storage when the power bank is fully charged or empty, so as to extend its battery life. • Illustrations of product, accessories, and user interface in the user manual</div></div></div>
--	--	---	--

<div><div>Specifications</div><div>Name: Power Bank Model: MC502 Battery capacity: 5000mAh/19.25Wh Rated capacity: 2750mAh(5V=3A) Wireless output: 5W/7.5W/10W/15W(MAX) Type-C input: 5V=3A 9V=2A Type-C output: 5V=3A 9V=2.22A 12V=1.67A Total output: 5V=3A Max output: 20W</div><div><div>EU Declaration of Conformity</div><div><div>CE</div><div>The manufacturer hereby declares that this equipment is in compliance with the applicable Directives and European Norms, and amendments.</div></div><div><div>WEEE Information</div><div><div><div>WEEE</div><div>All products bearing this symbol are waste electrical and electronic equipment (WEEE) as in directive 2012/19/EU which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by hand over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information, as well as the terms and conditions of such collection points.</div></div><div><div>EC</div><div>REP</div><div>PRODUCED IN FRANCE 8 Rue Abel 75012 Paris, France</div></div></div></div></div></div>	<div><div>Federal Communications Commission Supplier's Declaration of Conformity</div><div>This supplier's declaration of conformity is hereby for Product: Power Bank Model Number(s): MC502 Brand/Trade: Arkeep We declare that the above mentioned device has been tested and found in compliance with CFR 47 Part 15 Regulation. This device complies with Part 15 of the FCC Rules. Operation is subject to the following (1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure equipment. The device can be used in portable exposure condition without restriction.</div></div>	<div><div>US REP</div><div>ALLOY MOVIE INC. 3 E EVERGREEN RD #312 NEW CITY 10289 NEW YORK United States</div><div>Manufacturer: Liaoning Jiuyi Energy Technology Co.,LTD Address: No.751 Anqian Road, Lishan District, Anshan Liaoning Factory: Shenzhen Lexiang Technolongy Smart Manufacturing Co.,LTD Address: 201, Building A1, Fuhai B2 District, Fuyong Community, Fuyong Street, Bao'an District, Shenzhen Email: service@arkeeptech.com</div></div>	
--	---	---	--



成品要求平整，封面切口与折痕对齐。

图纸提供单位		上海安诺芯科技有限公司	
材质工艺要求	字体: 标题—思源黑体 正文—思源黑体		
	材质:80g双铜		
	制作工序:印刷+压痕+折叠 印刷要求:单色印刷、颜色正确、位置正确、尺寸正确、印迹牢固清晰。 工艺要求:切断处完全切透。切口整齐，无毛边、模切不错位(<1mm)折痕处宽度深浅一致。折叠方式正确，成品平整，封面切口与折痕对齐		
纹理方向			
备注			
材料名称		说明书	
料号			
版本号		V00	
设计时间		2024.12.03	
设计师			
审核人			
批准人			
比例	1:1	单位	mm毫米

历史版本

版本号：
修改点：
修改人：

版本号：
修改点：
修改人：

版本号：
修改点：
修改人：

版本号：
修改点：
修改人：

版本号：
修改点：
修改人：