


Dahe Tag



1. **Turn on the device**
Quickly press and release the **Power** button to turn on your iPad.
2. **Pair the device**
Open the **Apple ID** app.
Hold the device close to your iPhone, tap the **Items** tab, tap + and then **Add Other Item**.
Tap **Connect**.
Type a name for your device, select an email.
Tap **Agree to acknowledge that this item will be linked to your Apple ID**.
Tap **Finish**.
Tap **Enable Lost Mode**.
3. **Open the Find My app**, tap the **Items** tab, then tap your item.
Under **Lost Mode**, tap **Enable**.
Read the instructions, tap **Continue** and enter a phone number or email address.
Confirm the information, customize the lost message, and tap **Activate to complete the setup**.
4. **Remove the device**
Open the **Find My** app, tap the **Items** tab, then tap your item.
Tap **Remove Item** and tap **Remove to complete the operation**.
Note: After removing the device in the app, it will not send out and will not be in the pairing mode. If you have not removed it within 10 minutes, the device will leave the pairing state, and the new device and app cannot be paired within it. If you need to pair the device, you need to click the **Set default** button on the device settings. At this point, the device enters the pairing state and can be paired.

- 1. Find Item and Set its Nearby:**
Open Find My app and select the "Items" tab or open the Find items app on your Apple Watch.
Tap on your item from the list.
Tap "Play Sound" to make your item beep.
Tap "Sound Source" to step the beeps once you find.
- 2. Find item's Location:**
Open Find My app and select the "Items" tab or open the Find items app on your Apple Watch.
Tap on your item from the list.
Tap on the location you want to mark on the map with a time stamp when the item was located.
To navigate to the item's location, tap "Directions" to open Apple Maps.
- 3. Enabling "Notify When Left Behind":**
Open Find My app and select the "Items" tab or open the Find items app on your Apple Watch.
Tap on your item from the list.
Tap on "Notifications" enable the "Notify When Left Behind" toggle.
You will receive a notification when you leave your item left behind and it's no longer in range of your device.
- 3. Enabling "Notify When Found":**
Tap on "Notifications" enable the "Notify When Found" toggle.
When your item is seen by another Find My network device, you will receive a notification of its location.
- Note** "Notify When Found" can only be activated when your item is out of range.

Important tips: When pairing a device with Findmy app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:

1. Change the phone's network, such as switching between WiFi and network;
2. Restore the device to factory Settings: After the device is powered on, press the key five times and hold it for the fifth time, then the device will play a tune and finish the factory reset. Release the button to complete the reset.
3. Pair with Findmy app.

1. Locate your item
If your missing item isn't nearby, the Find My app can still help you track it down using the location history. Nearby devices can find your item, and then relay its location to you. Find My can also find items that are nearby devices securely using the location of your missing device to iCloud, then send you an alert if it is in the Find My app. It's all anonymous and encrypted to protect everyone's privacy.

2. Play Sound
Open the Find My app, tap the items tab, then tap your item.
Click Play Sound, and the device will beep, so you can find the item easily.

Instructions for device button

1. Power on the device
Press the device button once, the device will make a sound, and the device will turn on.

2. Device on the screen
If you double-click the device button, the device makes a beep sound, indicating that the device is on the screen. If you click the device button and the device is not powered on, Press the button once to turn it on.

3. Device on the screen again
After removing the device from the app, the device will beep, will not shut down, and will be in pairing mode. If it is not paired within 10 minutes, the device will be in pairing mode again. If you click the device button again, the device will beep and the device beeps. At this point, therefore enters the pairing mode again.

Following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not properly installed and used, may cause harmful interference to nearby wireless devices. However, there is no guarantee that interference will not occur in a particular installation. If interference is determined to be caused by this equipment to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following suggestions:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general FCC performance requirements. The device can be used in portable equipment conditions without restriction.



兼容 苹果“查找我的”

[illegible]

4. 当物品在列表中时, 可执行的操作:

- 打开“查找我的物品”: 再次选择“物品”标签或在顶部 Apple Watch 上打开查找我的物品。点击物品从列表中移出。物品上播放声音以让其他物品发出响声。我执行后“发出声音”停止发声。
- 打开“查找我的物品”: 应用选择“物品”标签或在顶部 Apple Watch 上打开查找我的物品。点击物品从列表中移出。物品的位置会在地图上显示。如有定时任务提醒, 要单击物品顶部, 单击“导航”以打开 Apple Maps。
- 关闭“关闭我的物品”: 打开“查找我的物品”应用并选择“物品”标签或在顶部 Apple Watch 上打开查找我的物品。在“通知”下方点击“关闭我的物品”。当关闭物品时, 物品不能与设备同步数据, 无法收到提醒。
- 查看“物品使用统计”: 打开“查找我的物品”应用并选择“物品”标签或在顶部 Apple Watch 上打开查找我的物品。在“通知”下方, 点击“物品使用统计”, 查看您的物品被查看统计中的其他设备看到时, 您收到几次位置的查看。

注意: “找到我的物品”只能在物品不在关机或关机模式下使用。

重要提示：在使用查找我的应用配对设备时，手机将与 Apple 服务器链接。配对可能因网络问题而失败，以下是一些恢复措施：

1. 更换手机的网络，例如在 WiFi 和移动网络之间切换。
2. 恢复设备到出厂设置：当设备开启时，按下重置键五次并在第五次按下，设备将被放一段旋转，然后释放按钮完成重置。
3. 与查找我的应用重新配对。

4. 位置传感器的物品

如果设备支持物品跟踪功能，使用“位置传感器”选项页可以跟踪设备是否按照我们指定的位置到达。例如，如果设备在指定的位置（如商店和仓库）没有检测到，这时您可以轻松找到设备或重新定位它。这可以帮助您减少丢失，并避免设备被窃或个人丢失的风险。

5. 继续设置

在“开始使用设备”选项卡，点击物品和标签，然后选择跟踪的物品。

物品跟踪功能，需要设备发出信号，这时您可以轻松找到设备或重新定位它。

设备使用须知

1. 开始使用设备

第一次使用，设备将发出声音，并开机。

2. 设备使用须知

设备使用须知，设备将会发出声音，表明设备正在工作。如果设备没有声音，那么设备没有电，请第一时间给设备充电。

3. 重新定位物品和标签

重新定位物品和标签，设备会响一次，不会发出声音，并重新进入定位模式。如果在 10 分钟内未重新定位，则设备将失去定位功能。设备使用须知，可以查看设备使用须知。设备使用须知，请点击设备使用须知，查看设备使用须知，设备使用须知，可以查看设备使用须知。

[illegible]