



BLUETOOTH VOICE LED CLOCK CONTROL RECEIVER MANUAL

ELECTRONIC PARAMETERS

Adapter: 5V2A
Rated power: 9w
Rechargeable battery: 1200mAH/3.7V (normal)
Wet tips: LED products consume more power, it is recommended to plug in!




MAIN FUNCTIONS

1. Bluetooth speaker, FM radio, TF, U disk, AUX
2. Year, month, day, hour, minute, week, 12/24 hours system (date and time can be set to automatically switch)
3. Group alarm, 6 ringtones, snooze function
4. Screen brightness 4 manual adjustment
5. Voice control function
6. Night light, seven color light mode

Long press the power on and off button
Short press the radio, Bluetooth beep, TF mode to set the shutdown time

ON/OFF SETTING COUNTDOWN TO SHUTDOWN

Long press the device **ON-OFF** key for 3 seconds, turn on or off the short button, in the radio, Bluetooth audio, TF mode, you can set the shutdown time



CONNECT YOUR PHONE'S BLUETOOTH SETTINGS

1. After turning on the phone, short press the BT Bluetooth key to turn on the Bluetooth mode. "BT" will appear on the screen to turn on the phone Bluetooth and find the XM6606 Bluetooth. The name can be paired and connected. Play Pause
2. In Bluetooth mode
Up key **-I◀** Volume - / Previous song
Silver: Short press this key Up song:
Long press volume reduction **II** Move
Pause key: Short press this body to capture and play intelligent stop
Receiver **II+I** Volume + / Down key:
Short press this key to the next song; Long press volume plus
3. In Bluetooth mode
volume-/Previous song
Bluetooth / switch
volume-/next song
Radio



FM RECEIVER USE METHOD

1. In the boot state, short button **FM**, open the radio mode
2. long press the self-key **FM** for 3 seconds, the radio automatically search station, save station
3. in the radio mode:
-I◀ Pu - / Up key: short press this key on a channel:
long technology volume reduction **II** Play grinding stop key:
short press this key to play pause **II+I** + Volume + down key:
Short press this key Next channel: long press volume plus

TF CARD, U DISK USE METHOD

1. When the TF card is on, plug it in
2. Short press BT key to switch to TF card, the screen shows "TF" symbol
3. In TF card mode:
-I◀ Volume one/Up warp key: Short technique on this key:
Long press volume less **II** Play Pause key: Short press this key to play pause **II+I** Volume + Down warp key: Short press this key
Next: Long press volume plus
Follow this method to play USB stick songs



YEAR, MONTH, DAY, HOUR, MINUTE, WEEK SETTING METHOD

1. Bluetooth automatic timing
(some mobile phones do not support this function, please set it manually) After starting up, press the BT Bluetooth key to open the Bluetooth mode, the screen appears "BT" to open the Bluetooth of the mobile phone, find the XM6606 Bluetooth name to pair and connect, and the time will be automatically timed.
2. Manual setting

In the time mode, long press the SET key, the screen will

appear a number blink, short press the **-I◀** key or **II+I** key,

set the "year"; In this way, respectively set "month", "day",

"12/24" hour system, "hour" and "minute".

3. Date and time switch automatically

In time mode, press the set key to set the date and time

switch automatically

2 GROUP ALARM, 6 RINGTONES, SNOOZE FUNCTION SETTINGS

1. In the time state, press the **①** key to turn on or off the alarm; Long press the **①** key, the screen "hour" appears flashing, then short press **-I◀** key or **II+I** key, adjust "then short press back **①** key, screen "minutes" began to flash, then short **①** press **-I◀** key or **II+I** key, adjust "minutes"; Then short press the back **①** key, the screen appears **④...④** move, and then short press the **-I◀** key or **II+I** key, select the corresponding alarm track. Follow this method to set the alarm 2
2. When the alarm rings, touch the **LIGHT-SNOOZE** button to start the snooze function, 5 minutes later, the alarm rings again; In this way, you

can operate repeatedly, press any other key to cancel the alarm.

SCREEN 4 BRIGHTNESS ADJUSTMENT VOICE CONTROL ON AND OFF

1. In the time state, press the **-I◀** key to set the brightness of screen 4.
2. In the time state, press the **II+I** key and "ON" or "OFF" will appear on the screen to indicate voice control on or off. When the voice control is turned on, the screen will automatically light up after 80 decibels of sound appears in the surrounding environment. When the voice control is turned off, the screen lights up.



Screen display in time state

NIGHT LIGHT, SEVEN COLOR LIGHT MODE

1. Touch the **LIGHT-SNOOZE** Nightlight key and Nightlight Large - Medium - Small - Magic Light 1 - Magic Light 21 Magic Light 31 Magic Light 4 - Off.

CHARGE SYMBOL DEFINITION

When the product lacks power, the screen charging symbol "■" long bright, charging symbol "■" flashes when charging, fully charged, charging symbol "■" disappear.



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

背面