



70x85mm 128g双铜纸 风琴折 5折页

 <p>CXP 畅想派</p>	<p>包装清单</p>  <p>耳帽 充电盒 用户手册 备用耳帽 Type-C 充电线</p>	<p>耳机穿戴</p>  <p>FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<p>使用说明</p> <p>开/关电源 打开充电盒，耳塞就会自动打开，开始转动。然后把耳塞放回充电盒里，合上耳机。</p> <p>蓝牙配对 打开充电盒，在你的蓝色牙齿设备上搜索“肌肉活力”。在第一个蓝牙连接连接建立后，耳塞将每当充电盒打开时，将自动重新连接。如果5分钟内未建立蓝牙连接，耳机将自动关闭。</p> <p>电池显示 如果充电≤30%，红色的光闪烁三次充电盒≥30%，白光闪烁3次 充电盒≥70%，绿灯闪烁3次，充电盒=100%，指示灯熄灭</p> <p>耳机充电 把耳塞放回充电盒里。恒定的红灯意味着耳机正在充电。当耳塞充满电时，耳塞就会自动关闭。</p> <p>注意：</p> <ol style="list-style-type: none"> 不要让耳塞长期不充电，以免损坏耳机电池。 如果耳塞上有汗液或液体，请在充电前进行干燥，以免损坏耳塞。 	<p>操作说明</p>  <p>上一首歌 连续两次接触 下一个轨道 连续两次接触 音乐播放/暂停 点击L/R按钮一次 ANC切换 按住右耳，保持3秒</p>
 <p>CXP 畅想派</p>	<p>Operation</p>  <p>Game mode on/off Touch L three times in a row</p> <p>Voice dialing (Google/SIRI Feature) Touch the right earphone three times to enable the voice assistant</p> <p>Answer the phone Click once L/R</p> <p>Hang up/Reject a call Double click L/R once</p> <p>Audio switching Press and hold the L for 3S</p>	<p>Specification</p> <p>Product model: Musungo ZenVibe Bluetooth version: V5.4 Charging case voltage: 5V/1A Charging time for case: 2 hours Charging time for earbud: 1 hour Frequency response: 20Hz-20KHz Transmission distance: 10 meters (open environment) Music time: Up to 8HRS per charge / Up to 50HRS additional with case (at 60% volume) Standby time: 6 months Speaker size: Ø 10mm Charging input: Type-C Charging case battery: 500mAh Earbud battery: 40mAh Water Resistance: IPX5 Noise Cancellation: ANC (Active Noise Cancellation) Number of Mics: 4</p>	<p>Frequently Asked Questions</p> <ol style="list-style-type: none"> The charging box has power, but why can't the earbuds be charged? A. Please confirm if the earbuds are correctly placed in the charging box, if the charging contact of the earbuds is not in full contact, the earbuds will not charge. Wipe the charging contacts of the earbuds with a clean cotton cloth to ensure there is no foreign object interfering with the earbuds from charging. If there is sweat or liquid on the charging contact of the charging box, the earbuds may corrode, please clean it before inserting the earbuds into the charging box. You placed the earbuds in the charging box and closed the charging box, why are the earbuds still in the connection status? It should be that the earbuds were not properly placed in the charging box, and check point 1B. Why do the earbuds suddenly stall when using them? Due to the characteristics of Bluetooth earphones, electromagnetic interference in the area may cause temporary time lag, you can change the location of use. 	<p>Cautions</p> <ol style="list-style-type: none"> Please use this product with safety guarantee. Do not discard the product in fire or high temperature. Please use original accessories. Faults caused by other accessories will not be covered by the warranty. Please charge the charging case with the charger of DC5V/1A to avoid burning the product. Please disconnect the charger as soon as charging is completed and avoid leaving the product in the state of charging for a long time. You may experience interference or even disconnection when using the earbuds near high frequency devices such as big wifi routers. The effective operating distance of the earbuds is 10 metres, walls and big objects between your bluetooth device and the earbuds can reduce the effective operating distance. Do not expose the earbuds to liquids. It's recommended to use the earbuds below the maximum volume to protect hearing.

正面

背面