



#### HOW TO CHARGE?

1 Unscrew the ball shell, take out the control box and plug in the USB charging cable to charge it.

2 When charging, red light will turn on. When fully charged, the green light will turn on. (It takes approximately 40 Minutes to fully charge.)

#### HOW TO USE?

1 Press and hold the transparent button on the ball shell for 3 seconds, the red light indicates power on.

2 Control the rotation speed of the toy ball using the remote control, with a total of 3 gears. The toy ball can be turned on by vibrating it, and it can be paused by the pause button on the remote control.

3 After a period of inactivity, the toy ball enters a dormant state, which can be activated by remote control or by shaking.

4 Press and hold the transparent button on the ball shell for 3 seconds, the green light indicates power off.

Name: Puppy Toy Ball

Model: 688Q

Diameter: 3.3in

Weight: 0.36lb

Material: PC

Battery: 500mAh

Package includes:

Puppy Toy Ball


Remote Control

Type C Cable

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The device has been evaluated to meet general RF exposure requirement. The distance between the user and antenna should be no less than 30mm.

2.4GHz



Note: Remote control limit distance is 40 meters

MADE IN CHINA



## PUPPY TOY BALL

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

2.4GHz

USB Charge

Press and hold for 3 seconds, red light on to power on, green light on to power off

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



spinning ball



USB Rechargeable



Remote Control



Cool lighting

FCC CE

RoHS

