


Desktop Digital Display

INSTRUCTIONS MANUAL

D - Series



! Please read this manual before using the product and follow the instructions it contains !

CONTENT

GENERAL

FOREWORD.....	2
ATTENTION.....	2
SAFETY WARNINGS	3
TECHNICAL DATA	4
OVERVIEW OF MAIN COMPONENTS	6
FCC Attention	7

MAINTENANCE

REGULAR INSPECTION	8
TROUBLESHOOTING	8
SERVICE & CONTACT	8

FOREWORD

Congratulations on the purchase of your new digital display. This unit has been manufactured from high quality materials specifically designed for long-lasting and reliable use. For your own safety and to ensure correct operation of the digital display, be sure to read and follow these operating instructions before using it. Keep these operating instructions.

Check the unit for transport damage. Damaged displays must not be put into use. The digital display is used to display in a customer-effective manner. Improper handling may result in injury or damage to the unit.

Any liability for damage resulting from improper use of the unit or disregard of the specifications and rules of conduct in this operating manual is excluded. The operator is responsible for ensuring correct use by trained and authorised personnel.

ATTENTION

Content Requirement:

- Supported Video Formats:
 - MP4 (Video: AVC , Audio: AAC-LC)
 - MKV (Video: AVC / HEVC , Audio: AAC-LC)
 - VOB (Video: MPEG Video , Audio: AC-3)
 - MOV (Video: AVC , Audio: AAC-LC)
 - AVI (Video: MPEG-4 Visual , Audio: MPEG Video)
- Supported Image Formats: JPG, PNG
- Aspect Ratio: 16:9
- Resolution: Not exceeding 1920x1080
- Data Rates: Less than 10000 kbps
- Total Bit Rate: Less than 10000 kbps

SAFETY WARNINGS ▲

- Do not use or store the unit in a humid environment. Make sure that the ambient temperature is between 32 - 122 °F.
- The digital display is only suitable for INDOOR use. Do not use it near water.
- Make sure that the surface is level.
- Switch off and unplug the power supply before cleaning the display. Spray cleaning solution on a microfibre cloth to clean the unit. Never spray cleaning solution directly on the unit.
- Do not block the ventilation slots or place the unit near a heat source or other equipment that may affect ventilation.
- Do not carry out repair work on your own. In case of problems, contact our customer service.
- Use the unit with a stable power supply. Use only the power cord supplied with the unit.
- Overloaded mains sockets and extension cords are a source of danger. This also applies to damaged mains cables and plugs. This may result in a risk of electric shock or cable fire.
- Do not drop any objects on the unit.
- Do not subject the unit to shocks.
- Disconnect the unit from the power supply when not in use. Never leave the display switched on when you leave the premises.
- Never touch the power cord during a thunderstorm. There is a risk of electric shock.
- Modifications and alterations to the unit not approved by the manufacturer will void the warranty.



TECHNICAL DATA

DISPLAY


Type	LCD185S - D01A	Unit
Material	Aluminum Profile / Sheet Metal	
Screen Diagonal	18.5"	Inch
Screen Dimensions (W*H)	16.1" x 9.06" (409mm x 230.1mm)	Inch / mm
Format	16:9	
Resolution	1920x1080	Pixel
Luminosity	300 Nits	Nits
Contrast	1200:1	
Colors	16.7 M	Mio.
Touchscreen	Optional	

GENERAL


Type	LCD185S - D01A	Unit
Screen Color	White / Black	
Dimensions (W*H*D)	17.36" x 10.44" x 0.65" (441mm x 265.2mm x 16.5mm)	Inch / mm
Net Weight	12.35 (5.6 kg)	lb / kg
Range of Use	Indoor	
Power Consumption (ON)	≤ 36	W
Power Consumption (Standby)	≤ 3	W
Usage Time	50000	Hour
Operating System	Android	
Random Access Memory (RAM)	1 / 2 / 4 / 8	GB
Flash Memory (ROM)	8 / 16 / 32 / 64 / 128	GB
Loudspeaker	optional	
Connections / Interfaces	USB / WIFI / RJ45 / HDMI	
Operation	Remote Control	
Screen Direction	Switchable between landscape and portrait mode	



OVERVIEW OF MAIN COMPONENTS



- ① The interface diagram provided is for reference only; all interface configurations should be based on the actual product configuration when placing the order.



- ① Buttons ③、④、⑤、⑥、⑧ are only used in specific screens.

FCC Attention

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator &your body.

REGULAR INSPECTION

Carry out regular visual inspections. Pay particular attention to the display and the power cable.

Clean the display regularly. Spray cleaning solution on a microfibre cloth to clean the unit. Never spray cleaning solution directly onto the unit. Regularly check the ventilation slots at the back of the display.


TROUBLESHOOTING

Problem	Cause	Solution
No picture is displayed and no sound is played back	The mains plug is not plugged in	Plug in the mains plug
	The ON/OFF toggle switch on the back of the unit has not been flipped.	Flip the switch
	The sound is set to silent	silent Increase the volume
The remote control does not work	The distance between the display and the remote control is too far.	Reduce the distance between the display and the remote control.
	The batteries are flat	Replace the batteries (2 x AAA)
The display crashes	The remote control is held incorrectly	Aim the remote control directly at the centre of the display.
	Unstable internet connection	Ensure a stable internet connection
	Roaming activated	Deactivate roaming
Some colors are not displayed correctly	Cables at the back of the display have slipped out	Open the control box at the back and check the cable connections

SERVICE & CONTACT

Contact our product experts and find help and solutions for your product.

- ◎ Here you will find all contact information: info@fj-imgs.com
- ◎ Responsible for the content: [Xiamen iMGS Technologies Co., Ltd.](#)
- ◎ Website: www.imgstech.com



Xiamen iMGS Technologies Co., Ltd.



(+86) 188-5015-1946



info@fj-imgs.com



www.imgstech.com