

User Manual

Product Name: Little tail jumping egg

1. Power On/Off:

- To power on the device, press the travel lock button once.
- To power off the device, press and hold the power button for three seconds.

2. Remote Control Operation:

- **Change Mode:** Press the first button on the remote once to switch between vibration modes.
- **Pause/Resume:** Press the second button once to pause the vibration. Press it again to resume.

3. Auto-Lock Feature:

- If the device is not used for a certain period, it will automatically enter lock mode. To unlock, press the travel lock button once.

4. Remote Control Battery:

- The remote control requires an external battery (not included). Please refer to the battery compartment for installation instructions.

5. Charging:

- **Charging Time:** Approximately 90 minutes via USB.
- **Usage Time:** Up to 100 minutes on a full charge.
- **Charging Indicator:** The LED light will flash while charging and remain steadily lit when fully charged.

6. Maintenance:

- Ensure the device is turned off before charging.
- Clean the device with a soft, damp cloth and mild soap. Do not submerge in water.

Note: Always store the device in a safe and dry place. Keep out of reach of children.

To avoid injury or aggravation of pre-existing conditions, this device should not be used on swollen or inflamed areas of the skin. Use a toy cleaner for all your cleaning needs, before and after

every use. Do not share with other sexual partners. Help to prevent sexual diseases through the use of proper

contraceptives, judgement, education and care.

Safety Information:

- Do not use the device if it is damaged.
- Consult a physician if you have any medical conditions that may be affected by the use of this device.

FCC Statement

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.
-
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
-
- Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

Please read this manual carefully before using the product to ensure safe and proper operation.