



REMOTE CONTROL

OPERATING



Guangdong ZHIJIAYOUPIN Sanitary Ware Technology Co., Ltd

PRECAUTIONS

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Installation Preparation


Method 1

(Apply for smooth tiles, glass and smooth wall).


1. Choose proper installation location (Not easy to get wet , easy to takeout or operate).
2. Clean the dust, oil stains, water droplets etc. on the installation wall.
3. Peel off the adhesive tape on the back of the remote control bracket, align the position, and press evenly for 1-2 minutes to make it stick tightly, Place the remote control after 12 hours from installation.

Method 2

1. Choose proper installation location .
2. Fix the bracket on the wall by using the screws and plugs provided.
3. Place the remote control on the bracket.



Remote Control Operating



Usage Instruction

FUNCTION	FUNCTION DESCRIPTION
Remote code matching	Within 10s after the toilet is powered on, long press the " Rear Wash " and " Foam Shield " buttons at the same time. The toilet will make a long beep, indicating that the code matching is successful.
1/2 	During washing mode, short press the " + " key to increase the washing intensity; short press the " - " key to decrease the washing intensity. (There are 3 levels for adjustment).
3 	1 - Please seat before starting washing. 2 - Short press " Rear Wash " button to start the rear washing function. 3 - Short press again to turn on/off the reciprocating movement of the boom.
4 	1 - Please seat before starting washing. 2 - Short press " Front Wash " button to start the front washing function. 3 - Short press again to turn on/off the reciprocating movement of the boom. 4 - Long press " Front Wash " button to start Kid mode (Under Kid mode, washing intensity is fixed at the 1st levels and not adjustable , Washing position is fixed at the furthest position and not adjustable. Air temperature is fixed at the Low Level and not adjustable. Water temp are available for OFF / Low / Mid level only.
5 	1 - If any function is in operation, short press the " Stop/Flush " button to stop the current function. (Except open the cover/seat and flushing). 2 - If no function is in operation, short press the " Stop/Flush " button to start the flushing function.
6 	While seated, short press the " Drying " button to start the drying function.
7 	1 - If no function is in operation, short press the " Foam Shield " button to start the foaming function. (Only for the model with this feature.) 2 - Long press the " Auto Temp " button to turn on/off the Auto-temperature. Auto-temp: Water temperature, air temperature, and seat temperature are automatically adjusted according to the ambient temperature. (While seat , it is available to adjust the temperature grades of functions. it return to Auto Temp mode when function stop. While not seat , temperature is not adjustable.)
8/9 	During washing mode,short press the " ^ " key, to move forward; short press the " v " key, to move backward. (There are 5 positions for adjustment).
10 	During washing or Manual-temperatune mode,Short press the " Water temp " button to select the temperatune level from OFF / Low / Mid / High level.
11 	During seated or Manual-temperatune mode,Short press the " Seat temp " button to select the temperatune level from OFF / Low / Mid / High level.
12 	During drying or Manual-temperatune mode,Short press the " Air temp " button to select the temperatune level from OFF / Low / Mid / High level.

Usage Instruction

13		1 - While not seated , short press the “ Lid / Seat ” button to open the Lid, or open / close the seat. 2 - While not seated and lid is open , long press the “ Lid/Seat ” button to close lid (Only for the model with this feature)
14		Short press the “ Night Light ” button to turn on/off the night light.
15		Short press the “ Ambient Light ” button to switch on/off the ambient light mode.
16		1 - While not seated,short press “ Self-Cleaning ” to start automatic cleaning of the wand and nozzle. 2 - Short press again to start/close the reciprocating movement wand. 3 - Long press “ Self-Cleaning ” button to start/close the automatic UV sterilization; Under automatic UV sterilization mode, the UV sterilization is automatically turned on when the lid is closed, and it will automatically end after about 2 minutes or when other functions are operated or human body is sensed. 4 - During washing mode,short press “ Self-Cleaning ” button to switch on/off massage washing.

Guangdong ZHIJIAYOUPIN Sanitary Ware Technology Co., Ltd

H area, the original eel farm self-compiled,
Waihuanxi Road, Guxiang Third Village, Guxiang Town,
Chaoan District, Chaozhou, Guangdong, China

Made in china