


# User Manual



## How to Use:

### Device Part:

Long press  to turn on the product, then the item is on standby and the LED Light turns on.

Short press  to activate and switch 10 vibrating and 10 Thrusting modes.

Long press  to turn off the product, then the LED light is off.

### Remote Control Part:

When the product is on standby

Long press  on the remote control to turn on the remote, then the LED light is on.

Short press  on the remote control to activate and switch 10 vibrating modes. Long press  to turn off vibration

Short press  on the remote control to activate and switch 10 Thrusting modes.

Long press  on the remote control to turn off the vibrating and Thrusting, then the device and the product are turned off simultaneously.

## How to Clean & Store:

1.Turn off the device before cleaning. Do not clean the remote control

2.Clean the toy with warm water and antimicrobial soap.

3.After washing, dry the item with a towel or tissue.

4.Store the item in a cool, dry place.

5.Avoid sun exposure, heat, high pressure, and wet environments

## Charging Instructions and Maintenance:

1. We provide USB charging cable.

2. The port marked with "DC" is the charging port. Please use a charging cable to connect it.

3. When charging, the button indicator light will flash.

4. After fully charged, the indicator light is always on.

## Product Details:

Material

Silicone

Product Mode

10 Vibrating Modes  
10 Thrusting Modes

Size

6.28\*2.04\*2.03 Inches

Charging Time

120 Minutes

Battery Life

45-60Minutes

Maximum Noise

≤50 dB

Wasserfestigkeit

IPX7

## Notes:

1. Please read the manual before using this product.

2. Fully charged before first use.

3. Please charge it with a matching adapter.

4. Don't use the product if the silicon is cracked.

5. Please don't use the product while charging.

6. Please keep the vibrator out of the reach of children and pets.

## FCC STATEMENT:

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.